



m-Six Wireless

Getting started, safety and warranty

Important safety instructions

1. Read, follow and keep these instructions.
2. For the best possible experience, always use the product as described by the manufacturer.
3. Always handle your earphones with care and protect them from external damage.
4. Clean your earphones using a soft dry cloth. Never use water, cleaning detergent, leather polish or other substances as they may damage your earphones permanently.
5. Avoid exposure to extreme conditions such as very cold or hot temperatures, magnetic fields or damp environments.
6. Listening to music at high volume for prolonged periods of time can cause permanent damage to your hearing.
7. Contains small parts and are not suitable for children age three (3) and below.
8. The earphones contain magnetic material.
9. The earphones contain a Lithium battery. If misused or damaged it can become a hazard and is at risk of explosion.
10. Should a battery cell leak, do not allow the liquid to come in contact with skin or eyes.
11. The earphones must be switched off before boarding an aircraft.
12. The earphones must not be disposed of with regular household waste. Please dispose of in accordance with local regulations.
13. Do not use your earphones in the immediate proximity (10 cm) of a pacemaker.
14. Do not subject the product and included accessories to abnormal wear and tear.
15. Do not expose the earphones to temperatures below -20°C or above +45°C.
16. Do not charge the earphones in temperatures below 0°C or above +45°C.
17. Do not attempt to burn the earphones. The battery could explode causing injury and death.
18. Do not attempt to open, modify, disassemble, repair or in other way access the internal structure of the earphones. They are not user serviceable.
19. Do not use or store the earphones near to a vehicle airbag due to risk of injury.
20. Do not use earphones while driving, jogging or walking through traffic areas. Earphones effectively isolate external sound and noise, which means that when in use, you might not be able to hear your surroundings.
21. Do not drop, sit on or cause other unusual impact to the earphones.
22. Do not expose to fire, water or high voltage equipment.
23. Do not expose the product to rain or moisture.
24. Do not use the earphones near water, bathtubs, sinks, saunas, pools, other liquids or moist areas.

Model name: M6W01



Complies with
IMDA Standards
DA106614

Statements

US FCC interference statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MODIFICATION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

US FCC radiation exposure statement

FCC ID: 2AJ00-M6W01. The product comply with the US portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

EU Declaration of conformity

Hereby Jays Group AB declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other EU directive requirements. The complete declaration of conformity can be found at www.jaysheadphones.com.

Caution

Risk of explosions if battery box is damaged or opened. Dispose of used battery according to your local waste disposal authority.

KC KC statement

해당 무선설비는 운용중 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할수 없습니다.

1. 기기의 명칭/모델명: 특정소출력 무선기기(무선스테리오톤시스템용 무선기기) M6W01
2. 인증번호: R-C-UJW-M6W01
3. 인증 받은 자의 상호: Jays Group AB
4. 제조연월: 2018.10
5. 제조자/제조국가: Jays Group AB /중국

Getting started

Power on/off and pairing

To power on, press and hold the button for 2s. A voice assistant will tell you the current battery status. Pairing mode will automatically be initiated, indicated by the LED blinking slowly. Go to Bluetooth® settings on your device and select "JAYS m-Six Wireless". The blinking LED will turn off upon a successful connection followed by a short audio beep.

To power off, press and hold the button for 2s.

Reconnecting and additional pairing

Next time you power on, the earphones will automatically try to reconnect to the most recently used device. If not found, or if you manually disconnect through your device, pairing mode will automatically be initiated again. To force pairing mode, press and hold button for 4s from off state.

Battery status and fast charging

When powering up, the voice assistant will tell you the current status.

Battery high: 70-100%

Battery medium: 30-70%

Battery low: 0-30%

When battery is below 5%, "Battery low" will be announced automatically.

Charge using the included m-Six magnetic fast charge cable and connect it to any certified USB power output. The fast charge will charge your m-Six battery up to 25% in 15 minutes, and 50% in 30 minutes. A full 100% charge will take around 1 hour and 45 minutes (depending on temperature and charger).

Charging is indicated by a blinking red light, and a full charge is indicated by a solid white light.

Troubleshooting

Problem pairing and connecting

- Make sure the earphones are not connected to another device.
- Disable and enable Bluetooth on your device.
- Move the earphones closer to the device or alter their positions to avoid Bluetooth interference.
- Verify no other wireless equipment interfere with your earphone Bluetooth signal.

Problem with sound transmission

Move the streaming device to another position. Your body, distance, different materials and other wireless equipment can interfere with the wireless signal between your device and earphone.

Legal & Warranty

Environmental information

This product complies with international directives, including but not limited to WEEE Directive (2012/19/EU). Do not dispose with normal household waste. Please consult your local waste disposal authority for guidance on how to properly recycle or dispose of this product.



Manufacturer's limited warranty

Your original Jays Group AB product is covered by a warranty of twelve (12) months from the date of purchase of a brand new, unused Jays Group AB product by the original purchaser. Jays Group AB guarantees that the product is free from faults in the materials, design and workmanship when it was sold to the purchaser. If you are not able to submit the receipt when making a warranty claim you may be obliged to pay for any repairs carried out. Proof of purchase must clearly state the date of purchase, name of the product and authorized resellers' details.

The Warranty Period cannot be extended or renewed due to subsequent resale or replacement of the product. This Limited Warranty does not affect your legal rights under your applicable national laws relating to the sale of consumer electronic products. Defective parts replaced within the Limited Warranty Claim shall become the property of Jays Group AB.

What is not covered by the limited warranty?

- Faults caused by wear and tear, age-related battery capacity loss, accidents, dropping, mechanical damage, moisture, chemical products, abnormal impact damage or force majeure.
- Modifications or repairs performed by yourself or third party without Jays Group AB approval.

How to get warranty service

If you wish to make a Warranty Claim within the Limited Warranty Period, please contact the reseller of your product for further help. You will need to provide the proof of purchase and the affected part. Any defective parts covered by the Limited Warranty will be repaired or replaced free of charge. Replaced or repaired parts provided during the Warranty Period will be warranted for the remainder of the original Warranty Period or for sixty (60) days from the date of repair or replacement, whichever is longer. For FAQ please visit www.jaysheadphones.com.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

Qualcomm aptX is a product of Qualcomm Technologies, Inc. and/or its subsidiaries.



Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries.

Komma igång

Starta, stänga av samt parkopping

Tryck och håll nere knappen 1s för att starta hörlurarna. En röst kommer ge information om aktuell batterinivå. Parkopping aktiveras automatiskt och detta indikeras genom att lysdioden blinkar långsamt. Gå till Bluetooth®-inställningar på din enhet och välj "JAYS m-Six Wireless". När parkoppingen är slutförd slöcknar lysdioden och efterföljs av en kort ljudton.

Håll nere knappen 2s för att stänga av hörlurarna.

Återanslutning och ytterligare parkopping

Hörlurarna kommer automatiskt att återansluta till den senast använda enheten nästa gång de slås på. Hörlurarna kommer automatiskt att söka efter en ny enhet om den parkopplade enheten inte hittas eller om du manuellt fränkopplar hörlurarna. Håll nere knappen i 4s från avstängt läge för att manuellt aktivera parkopplingsläget.

Batteristatus samt snabbbladdning

Röstassistenten anger automatiskt nuvarande batterinivå vid uppstart.

Battery high: 70-100%

Battery medium: 30-70%

Battery low: 0-30%

"Battery low" kommer automatiskt att höras när batterinivån är under 5%.

Ladda med den medföljande magnetiska snabbbladdningskabeln ansluten till en certifierad och godkänd USB-port. Snabbbladdning tillåter dig att ladda dina m-Six up till 25% på 15 minuter och 50% på 30 minuter. En full 100% laddning tar ungefär 1 timme och 45 minuter (beroende på temperatur och laddare).

Pågående laddning indikeras av lysdioden med ett blinkande rött sken och full laddning indikeras med ett fast vitt sken.

Felsökning

Problem med att parkopping

- Säkerställ att hörlurarna inte är anslutna till en annan enhet.
- Inaktivera och aktivera Bluetooth på din enhet.
- Flytta hörlurarna närmare enheten eller ändra båsads position för att undvika störningar eller hinder.
- Säkerställ att inga andra trådlösa produkter stör dina hörlurars Bluetooth-signal.

Problem med ljudöverföring

Flytta den spelande enheten till en annan position. Din kropp, avståndet, olika material samt annan trådlös utrustning kan påverka signalen mellan din enhet och dina hörlurar.

Villkor & Garantier

Miljöinformation

Den här produkten följer internationella direktiv inklusive men inte begränsat till WEEE Directive (2012/19/EU). För ej slängas tillsammans med vanligt hushållsavfall. Vänligen kontakta dina lokala myndigheter för råd om hur du lämpligen återvinner eller slänger produkten.



Tillverkarens begränsade garantivillkor

Din Jays Group AB-produkt täcks av en 12-månadersgaranti som gäller från och med inköpsdatumet av en ny, oanvänd Jays-produkt, inköpt via en auktoriserad Jays Group AB-återförsäljare. Jays Group AB garanterar att produkten är fri från defekter vid tidpunkten för ditt inköp. Om du inte kan styrka ditt inköp med ett kvitto så kan du bli ombudat att betala för eventuell reparation. Ett kvitto måste tydligt visa datum för inköp, namn på produkt samt återförsäljarens uppgifter.

Garantiperioden kan inte förlängas eller förnyas genom att på nytt säljas vidare eller bli utbyt. Den begränsade garantin påverkar inte dina lagstadgade rättigheter i landet för ditt inköp. Utbyta produkter och tillbehör inom den begränsade garantiperioden tillhör Jays Group AB.

Vad täcks inte av garantin?

- Fel orsakade av slitage, minskad batterikapacitet p.g.a ålder, olyckor, fall, mekanisk skada, fukt, oaktansamhet, kemiska vätskor samt okontrollerbara händelser.
- Modifiering eller reparation utförd av dig eller annan part utan godkännande av Jays Group AB.

Hur garantin hanteras

Kontakta i första hand inköpsstället om du önskar reklamera din produkt inom den begränsade garantiperioden. Du måste kunna uppvisa ett giltigt kvitto samt produkten du önskar reklamera. Produkten och de delar som innefattas av garantin kommer att bytas ut eller repareras. Produkt eller tillbehör som byts ut eller repareras under garantiperioden täcks av kvarvarande garantiperioden eller 60 dagar från och med utbytes- eller reparationsdatumet beroende av vilket som är längst. För FAQ vänligen besök www.jaysheadphones.com.