

Plus TR-110

Remote Control Transmitters

User Manual



1. Doors Lock

Press button .the vehicle doors are locked.

2. Doors Unlock

Press button .the vehicle doors are unlocked.

FCC Caution :To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.