


## ***Operators Manual for the TR4 Transmitter***

The TR4 is an extremely easy transmitter to use. The following will explain each of the button functions of the transmitter.



### **Button 1 :Arm/Disarm**

Pressing this button for 1 second will indicate to your receiver to arm your home security panel. Pressing this button again will indicate to the receiver that you wish to disarm your panel.

### **Button 2: Panic**

Pressing this button for 1 second will indicate to your receiver to send a panic signal to your home security panel.

### **Button 3: Garage/Door**

Pressing this button for 1 second will indicate to your receiver to send an open garage./door signal to your home security panel.

### **Button 4: Medic Alert**

Pressing this button for 1 second will indicate to your receiver to send a medic alert signal to your home security panel.

**NOTE:** Pressing any button for 3 seconds will generate a PANIC alarm signal.

Your transmitter also has the capability to send a battery low condition to your receiver unit. This signal will be generated when pressing any of the 4 transmitter buttons.