VIVITAR

BLUETOOTH

SOUNDBAR

24 INCH WIRELESS SPEAKER







Important Safety Precautions

When using your Vivitar Bluetooth Sound Bar Speaker, basic safety precautions should always be followed, including the following:

- 1. READ ALL INSTRUCTIONS BEFORE USING YOUR SPEAKER.
- 2. Do not use your speaker near water. Clean using a soft cloth or paper towel.
- 3. Do not place your speaker on any wet surfaces.
- 4. Do not allow children or the infirm to play with your speaker without adult supervision.
- 5. Do not expose your speaker to excessive heat, flames or fire.
- $\hbox{6. Always press all buttons or switches carefully. Do not manhandle your speaker.}\\$
- 7. Do not use in extremely dry environments, as this can lead to static discharge during usage.
- 8. Do not expose your speaker to temperatures above 40°C. Keep out of direct sunlight.
- 9. Do not attempt to repair this product yourself. Contact a qualified service center if your speaker is in need of service.
- 10. Do not drop, puncture or expose your speaker to excessive trauma.
- 11. Your speaker is not intended for commercial use.
- 12. Do not place near objects that generate a strong magnetic field.
- 13. Only use the included power supply to power on your speaker.
- 14. Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information.



Introduction

Thank you for purchasing the Vivitar Bluetooth Sound Bar Speaker, item VSB24200. You can connect your speaker directly to a television, or use your speaker with most types of smartphones and Bluetooth devices to stream music wirelessly. In order to get the best results, please read this guide first before using your device.

Package Contents

- -Vivitar VSB24200 Bluetooth Sound Bar Speaker
- -Power Adapter
- -Quick Start Guide with Warranty Information

Specifications

Bluetooth Range: Up to 33 feet (10 meters)


Output: $3W \times 2$

Dimensions: 610 x 60 x 60 mm

Ports: RCA Output

Power Supply: Input: 100-240V Output: 5V==1.5A

A Quick Look at Your Speaker



Powering On Your Speaker

1.Plug one end of the included power adapter into a suitable wall outlet in your home.



2. Plug the other end into the DC 5V power port on the rear of your speaker




3.Once plugged, in the power LED indicator light will turn red. Your speaker is now in standby mode.

Power LED Indicator Light


4. To power on your speaker you can do one of the following:

--Press & hold the power button on the side of your speaker.



Pairing Your Speaker with a Bluetooth Device

Your speaker can be paired with most smartphones and tablets. In order to pair your speaker with a smartphone, follow the steps below:



1. Press and hold the power button on the side of your speaker to power it on. 2. The Bluetooth LED indicator light will illuminate when you are in Bluetooth mode.

3.Go to your phones Bluetooth settings menu, make sure to turn Bluetooth on, and select the device listed as Vivitar VSB24200.

NOTES:

- --By default, your phone will go into Bluetooth mode when powered on. If it does not, press the mode button on the side of your speaker repeatedly to switch modes until Bluetooth mode is selected.
- --Press and hold the pair button on the side of your speaker to disconnect the Bluetooth connection between your speaker and smartphone.


Connecting to a TV

Your speaker can also be connected to most televisions using the included RCA cable. To do so, follow the steps below.



- Insert the suitable plugs on one end your AV cable into the right and left RCA ports on your speaker.
- 2. Insert the suitable plugs on the other end your AV cable into the right and left audio out jacks on your TV.
- 3. Press and hold the power/mode button to power on your speaker. Then, tap the power/mode button repeatedly to go to AUX mode.







Listening to Music

Once your speaker is connected to an audio source you can proceed to listen to music.


--Playing or Pausing a Track



--Increasing or Decreasing Volume



--Next Track/Last Track



FCC Statement

FCC ID: LMZ-VSB24200

Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 in the U.S. or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

Vivitar One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE, NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTORS SOLE DISCRETION -ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAG-ES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE. MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMERS RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR, THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

