Calls & Messages

Call Log

View Call Logs


- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Call Logs.
- Select In tab to display Incoming Calls.
 OR
 Select Out tab to display Outgoing
- - Newest First
 - Oldest First
- 6. Tap the phone entry you want to view.


You're done!

Delete a Call

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Call Logs.
- Select In tab to display Incoming Calls.
 OR
 Select Out tab to display Outgoing Calls.
- 5. Touch the entry you want to delete.
- 6. Tap Delete Call.

You're done! The call will be removed from your Call Logs.





Calls & Messages (cont'd)

Call Log (cont'd)

Delete All Calls

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Call Logs.
- Select In tab to display Incoming Calls.
 OR
 Select Out tab to display Outgoing Calls.
- 5. Tap **Delete All** to clear all entries.

You're done! All calls will be removed from your Call Log.

Add Caller to Address Book

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Call Logs.
- Select In tab to display Incoming Calls.
 OR
 Select Out tab to display Outgoing Calls.
- 5. Touch the call log entry for the person you want to add.
- 6. Click Add Contact.
- Update the entry in the First Name and Last Name field, if necessary.
- 8. Enter the Email Address.



Calls & Messages (cont'd)

Call Log (cont'd)

Add Caller to Address Book (cont'd)

9. Touch Save if you're done.

OR

Touch **Next** to enter more information.

- 10. Enter:
 - Home Phone
 - Work Phone
 - Cell Phone
- 11. Touch Save if you're done.

OR

Touch **Next** to enter more information.

- 12. Enter Address Information for the contact.
- 13. Touch **Save** if you're done.

OR

Touch **Next** to enter more information.

- 14. Select a **Group** from the list.
- 15. Touch **Change** to choose a Picture for this contact.
- 16. Touch Save.
- 17. Click Done.


You're done! This caller will be added to your Address Book.

Calls & Messages (cont'd)

Call Log (cont'd)

Call a Person in Call Log

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Call Logs.
- Select In tab to display Incoming Calls.
 OR
 - Select Out tab to display Outgoing Calls.
- 5. Select the person you wish to call.
- 6. Click **Dial** or **1 + Dial** to dial the person.
- 7. During the call, you can:
 - Put the person on **Hold**.
 - Mute your phone.
 - Touch # Dial Pad to initiate 3-Way Calling.
- 8. Click **End Call** when you have finished talking.



Calls & Messages (cont'd)


Message Center

Memo Pad

Create Memo

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Message Center.
- 4. Touch Memo Pad.
- 5. The Memo Pad will open.
- 6. Touch Add.
- 7. Touch **For** to enter the name of the memo recipient.
- 8. Choose the type of memo you want to leave:
 - Aa to type a message.
 - to draw a message.
- 9. Other options include:
 - Touch to change background color.
 - Touch to change font color.
 - Touch to erase.
 - Touch to add emoticons.
- 10. Touch **Done** to save the memo.

You're done! A sticky note will appear on the Home screen indicating a new Memo.



Calls & Messages (cont'd)

Message Center (cont'd)

Memo Pad (cont'd)

Delete Memo

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Message Center.
- 4. Touch Memo Pad.
- 5. The Memo Pad will open.
- 6. Select the Memo and after it opens, click Delete.


You're done! The Memo will be deleted from the device.

Verizon Messages

View Verizon Messages

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch **Message Center**.
- 4. Touch Verizon Messages.
- 5. A list of messages will appear.





Calls & Messages (cont'd)

Message Center (cont'd)

Verizon Messages (cont'd)

Delete Verizon Messages

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Message Center.
- 4. Touch Verizon Messages.
- 5. A list of messages will appear.
- 6. Select the message you want to delete.
- 7. Touch Delete.

You're done!

Delete All Verizon Messages

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Message Center.
- 4. Touch Verizon Messages.
- 5. A list of messages will appear.
- 6. Touch **Delete All**.

You're done! The Verizon Messages will be deleted from the list.



Calls & Messages (cont'd)

Address Book

View Address Book

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Address Book.
- 4. All of your contacts will appear.
- 5. Select **A-F**, **G-L**, **M-S** or **T-Z** to find a contact according to his/her last name.

You're done!


Add Person

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Address Book.
- 4. Touch Add.
- 5. Select Add Person.
- 6. Tap the **Name** field to launch the keyboard to enter:
 - First name
 - Last name
 - Email address
- 7. Touch **Save** if you're done.

OR

Touch **Next** to enter more information.





Calls & Messages (cont'd)

Address Book (cont'd)

Add Person (cont'd)

- 8. Enter:
 - Home Phone
 - Work Phone
 - Cell Phone
- 9. Touch Save if you're done.

OR

Touch **Next** to enter more information.

- 10. Enter Address Information for the contact.
- 11. Touch **Save** if you're done.

OR


Touch **Next** to enter more information.

- 12. Select a **Group** from the list.
- 13. Touch **Change** to choose a Picture for this contact.
- 14. Touch Save.

You're done! The contact will be added to your Address Book.

Add Business

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Address Book.
- 4. Touch Add.
- 5. Select Add Business.



Calls & Messages (cont'd)

Address Book (cont'd)

Add Business (cont'd)

- 6. Tap the **Name** field to launch the keyboard to enter:
 - First name
 - Last name
 - Email address
 - Primary phone number
- 7. Touch **Save** if you're done.

OR

Touch **Next** to enter more information.

- 8. Enter:
 - Home Phone
 - Work Phone
 - Cell Phone
- 9. Touch Save if you're done.

OR

Touch **Next** to enter more information.

- Enter Address Information for the contact.
- 11. Touch **Save** if you're done.

OR

Touch **Next** to enter more information.

- 12. Select a **Group** from the list.
- 13. Touch **Change** to choose a Picture for this contact.
- 14. Touch Save.

You're done! The Contact will be added to your Address Book.



Calls & Messages (cont'd)

Address Book (cont'd)

Add Group

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Address Book.
- 4. Touch Add.
- 5. Select Add Group.
- 6. Tap the **Name** field to launch the keyboard to enter the group name.
- 7. Touch **Change** to choose a Picture for this group.
- 8. Touch Save.

You're done! The Group will be added to your Address Book.


Phone Book

Yellow Pages

Search for a Business

- 1. Touch Menu
- 2. Touch Calls & Messages.
- 3. Touch Phone Book.
- 4. Touch Yellow Pages.
- 5. Enter the **Keyword** or **Business** Name.
- 6. Enter the City and State.
- 7. Click Find It.





Calls & Messages (cont'd)

Phone Book (cont'd)

Yellow Pages (cont'd)

Search for a Business (cont'd)

- 8. Your results will appear.
- 9. Touch:
 - to call them.
 - 1+ Dial to call them (if the number is long distance).
 - Map to generate a map of their location.

Get Directions to a Business

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Phone Book.
- 4. Touch Yellow Pages.
- 5. Enter the **Keyword** or **Business** Name.
- 6. Enter the City and State.
- 7. Click Find It.
- 8. Your results will appear.
- 9. Touch **Map** to generate a map of their location.
- 10. Touch Get Directions.
- 11. Enter your starting address:
 - Address
 - City
 - State
 - ZIP Code



Calls & Messages (cont'd)

Phone Book (cont'd)

Yellow Pages (cont'd)

Get Directions to a Business (cont'd)

- 12. Touch **Show** to generate directions.
- 13. Touch **Back** to return to the previous screen.

You're done!

White Pages

Search for a Person

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Phone Book.
- 4. Touch White Pages.
- 5. Enter the Name, City and State.
- 6. Click Find It.
- 7. Your results will appear.
- 8. Touch:
 - a. to call them.
 - b. **1+ Dial** to call them (if the number is long distance).
 - c. **Map** to generate a map of their location.



Calls & Messages (cont'd)

Phone Book (cont'd)

Speed Dial


Add Speed Dial Entry

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Speed Dial.
- 4. Touch one of the entries labeled **(Empty)**.
- Enter the Name and Number of the person.
- 6. Click Done.

You're done! This person will be added to your Speed Dial List.

Call Person on Speed Dial List

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Speed Dial.
- 4. The Speed Dial list will appear.
- 5. Touch next to the person you want to call.
- 6. The call will be placed using the Speakerphone. If you want to switch to the handset, simply pick it up and press **Talk**.





Calls & Messages (cont'd)

Phone Book (cont'd)

Speed Dial (cont'd)

Delete Person on Speed Dial List


- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Speed Dial.
- 4. The Speed Dial list will appear.
- 5. Select the person and touch **Delete**.


You're done! The person will be deleted from your Speed Dial List.

Reverse Lookup

Find a Person or Phone Number

- 1. Touch Menu.
- 2. Touch Calls & Messages.
- 3. Touch Phone Book.
- 4. Touch Reverse Lookup.
- 5. Enter the **phone number** and touch **Find It**.
- 6. Your results will appear.





News & Info

Weather

Check Current Weather

1. Touch the **Weather** at the top-right of the screen.

OR

Touch **Menu**, **News & Info** and then **Weather**.

2. The Weather will open.

You're done!

View 5-Day Forecast

1. Touch the **Weather** at the top-right of the screen.

OR

Touch **Menu**, **News & Info** and then **Weather**.

- 2. The Weather will open.
- 3. Touch **5-Day Forecast**.





News & Info (cont'd)

Weather (cont'd)

My Locations


1. Touch the **Weather** at the top-right of the screen.

OR

Touch **Menu**, **News & Info** and then **Weather**.

- 2. The Weather will open.
- 3. Touch My Locations.
- 4. To enter a location in the U.S.:
 - Touch the National tab.
 - Enter the **ZIP**, **City** and **State**.
 - Touch Add.
- 5. To enter an international location:
 - Touch the International tab.
 - Enter the City and Country.
 - Touch Add.

You're done! The locations you added will also be displayed when you open the Weather screen.



News & Info (cont'd)

News

Check Top Headlines


- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch News.
- Touch **Top Headlines** to view the day's top stories.
- 5. Select the headline you want to read.
- 6. Scroll down to read the entire story.
- 7. Touch **Top Stories** to return to the previous screen.
- 8. Touch **Back** to return to the News screen.

You're done!

Read Entertainment News

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch News.
- 4. Touch Entertainment News.
- 5. Select the **headline** you want to read.
- 6. Scroll down to read the entire story.
- 7. Touch **Top Stories** to return to the previous screen.
- 8. Touch **Back** to return to the News screen.





News & Info (cont'd)

Sports

Read Sports News

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Sports.
- 4. Touch Sports News.
- 5. Select the **headline** you want to read.
- 6. **Scroll** down to read the entire story.
- 7. Touch **Top Stories** to return to the previous screen.
- 8. Touch **Back** to return to the Sports screen.

You're done!

Check Scores

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Sports.
- 4. Touch Scores & Schedules.
- 5. Select the sport you want to look up.
- The scores of completed games will appear – if scheduled games haven't yet been played, only the game time will appear.
- 7. Touch **Change Day** to display scores from another date.





News & Info (cont'd)

Sports (cont'd)

Check Scores (cont'd)

- 8. Touch **Change Sport** to view scores for a different sport.
- 9. Touch **Back** to return to the **Sports** screen.

You're done!

Check Schedules

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Sports.
- 4. Touch Scores & Schedules.
- 5. Select the sport you want to look up.
- The scores of completed games will appear – if scheduled games haven't yet been played, only the game time will appear.
- 7. Touch **Change Day** to display schedules for upcoming games.
- 8. Touch **Change Sport** to view schedules for a different sport.
- 9. Touch **Back** to return to the **Sports** screen.



News & Info (cont'd)

Information

Lottery

Check Lottery Results

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Information.
- 4. Touch Lottery.
- 5. Lottery results for your area will appear.
- Select a Lottery Name to view the details.

You're done!

Change Lottery Location

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Information.
- 4. Touch Lottery.
- 5. Lottery results for your area will appear.
- 6. Touch Change Region.
- 7. Select a Region.
- 8. The Lottery results for the new region will appear.





News & Info (cont'd)

Information (cont'd)

Horoscope

Check Horoscope

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Information.
- 4. Touch Horoscopes.
- 5. Select a **Sign** they are listed alphabetically.
- 6. The daily Horoscope for that sign will appear.

You're done!

Change Horoscope Sign

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Information.
- 4. Touch **Horoscopes**.
- 5. Select a **Sign** they are listed alphabetically.
- 6. Touch **Change Sign** to select another horoscope to read.





News & Info (cont'd)

Information (cont'd)

Stocks

Check Stocks

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Information.
- 4. Touch Stocks.
- 5. A list of your favorite stocks will appear

You're done!

Search/Add Stocks

- 1. Touch Menu.
- 2. Touch News & Info.
- 3. Touch Information.
- 4. Touch Stocks.
- 5. A list of your favorite stocks will appear.
- 6. Touch Add.
- 7. Enter the **Ticker Symbol** and touch **Add**.


OR

Enter the **Company Name** and touch **Search**.

8. Touch Done.

You're done! This Stock will be added to your favorites list and will appear on the Stocks screen.





Food & Entertainment

Restaurants

Search Restaurants Near Me


- 1. Touch Menu.
- 2. Touch Food & Entertainment.
- 3. Touch Restaurants.
- 4. Touch Restaurants Near Me.
- 5. A list of Restaurants in your ZIP Code will appear. (Your default ZIP code is in the top of the screen.)
- 6. Scroll through the list of restaurants.
- 7. Select a **Restaurant** to find its address.

You're done!

Search Restaurants in Other Areas

- 1. Touch Menu.
- 2. Touch Food & Entertainment.
- 3. Touch Restaurants.
- 4. Touch Restaurants Near Me.
- 5. A list of Restaurants in your ZIP Code will appear.
- 6. Touch the **Location** field.
- 7. Enter another **ZIP Code** and touch **Enter**.
- 8. A list of Restaurants in that area will appear.





► Food & Entertainment (cont'd)

Restaurants (cont'd)

Search Restaurants By Cuisine

- 1. Touch Menu.
- 2. Touch Food & Entertainment.
- 3. Touch Restaurants.
- 4. Scroll through the list and select a **Cuisine**.
- 5. A list of those restaurants will appear.

You're done!

Get Map to Restaurant

- 1. Touch Menu.
- 2. Touch Food & Entertainment.
- 3. Touch Restaurants.
- 4. Touch Restaurants Near Me.
- 5. A list of Restaurants in your ZIP Code will appear.
- 6. Select a Restaurant.
- 7. Touch Map to see where it's located.

You're done!

Get Directions to Restaurant

- 1. Touch Menu.
- 2. Touch Food & Entertainment.
- 3. Touch Restaurants.
- 4. Touch Restaurants Near Me.






► Food & Entertainment (cont'd)

Restaurants (cont'd)

Get Directions to Restaurant (cont'd)

- 5. A list of Restaurants in your ZIP Code will appear.
- 6. Select a Restaurant.
- 7. Touch Map.
- 8. Touch **Directions** and they will appear.

You're done!



Movies

Watch Movie Trailers

- 1. Touch Menu.
- 2. Touch Food & Entertainment.
- 3. Touch Movies.
- 4. A list of Movies Now Playing in your area will appear.
- 5. Touch the **Movie** you want to preview.
- 6. Touch Watch Trailer.
- 7. The Trailer will appear in full-screen.
- 8. Tap the screen with the stylus to return to the Home screen.



► Food & Entertainment (cont'd)

Movies (cont'd)

Look Up Movies in Other Areas

- 1. Touch Menu.
- 2. Touch Food & Entertainment.
- 3. Touch Movies.
- 4. A list of Theaters in your ZIP Code will appear.
- 5. Touch the Location field.
- 6. Enter another **ZIP Code** and touch **Enter**.
- 7. A list of Movies in that area will appear.



Tools & Settings

Tools & Calendar

Calculator

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Calculator.
- Use the electronic keypad to perform calculations just as you would on any other calculator.

You're done!

Calendar

View Event


- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Calendar.
- 4. Touch the Month, Week or Day tab.
- 5. Touch the **Event** in the day's listing.

You're done!

Add Event

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Calendar.
- 4. Click Add Event.





► Tools & Settings (cont'd)

Tools & Calendar (cont'd)

Calendar (cont'd)

Add Event (cont'd)

- 5. Enter:
 - Subject
 - Location
 - Start Date/Time
 - End Date/Time
- 6. Touch More
- 7. Select **Reminder** from the menu.
- 8. Touch Done.

You're done! The event will appear on your Calendar.

Edit Event

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Calendar.
- 4. Select the **Event** you want to delete.
- 5. The Event details will appear.
- 6. Touch Edit.
- 7. Make the changes you want and select **Done**.

You're done! The event will be edited on your Calendar.





► Tools & Settings (cont'd)

Tools & Calendar (cont'd)

Calendar (cont'd)

Delete Event

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Calendar.
- 4. Select the **Event** you want to delete.
- 5. The Event details will appear.
- 6. Touch **Delete**.

You're done! The event will be deleted from your Calendar.

CALENDAR / View Appointment Ter MAR 1 12:30PM to 12:45PM Delete Back

Sound Settings

Ringtones

Change Ringtone

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch **Sound Settings**
- 4. Touch Ringtones.
- 5. A list of available Ringtones will appear. Your current Ringtone is highlighted in green.
- 6. Select a new Ringtone.
- 7. Touch Set Ringtone.

You're done! Your new Ringtone will be effective immediately.



► Tools & Settings (cont'd)

Sound Settings (cont'd)

Ringtones (cont'd)

Preview Ringtone

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Sound Settings.
- 4. Touch Ringtones.
- 5. A list of available Ringtones will appear. Your current Ringtone is highlighted in green.
- 6. Select a new Ringtone.
- 7. Touch Play.

You're done!

Volume

Adjust Volume

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Sound Settings.
- 4. Touch Volume.
- 5. Press + and to adjust volume for:
 - Master
 - Speakerphone
 - Media
 - Alarm
 - Ringer





► Tools & Settings (cont'd)

Display Settings

Brightness & Contrast

Adjust Brightness & Contrast

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Display Settings.
- 4. Touch Brightness & Contrast.
- Use the ⟨⟩ arrows to adjust the Brightness.
- Use the ⟨⟩ arrows to adjust the Contrast.
- 7. Click Done.

You're done!

Wallpaper

Change Wallpaper

- 1. Touch Menu.
- 2. Touch **Tools & Settings**.
- 3. Touch **Display Settings**.
- 4. Touch Wallpaper.
- 5. The current Wallpaper will appear.
- 6. Touch **Change**.
- 7. Scroll through the Wallpaper options using **Next** and **Previous**.
- 8. Select the Wallpaper and touch **Done**.

You're done! The new Wallpaper will appear as your background.





► Tools & Settings (cont'd)

Display Settings (cont'd)

Screen Saver

Change Screen Saver


- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Display Settings.
- 4. Touch Screen Saver.
- 5. The current Screen Saver will appear.
- 6. Touch Change.
- 7. Scroll through the Screen Saver options using **Next** and **Previous**.
- 8. Select the Screen Saver and touch **Done**.

You're done! The new Screen Saver will appear the next time your device rests.

Touch Screen Tune-Up Calibrate Touch Screen

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch **Display Settings**.
- 4. Touch Touch Screen Tune-Up.
- 5. Touch Calibrate.
- 6. The Touch Screen will calibrate itself. This may take a minute.





► Tools & Settings (cont'd)

Network & Phone Settings

Date/Time

Change Time Zone

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch Date/Time.
- 5. Select a Time Zone.
- 6. Touch Done.


You're done!

Network Setup

Set Up Wireless Network

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch Network Setup.
- 5. Touch Wireless Settings.
- 6. Touch Change.
- 7. Select a Wireless Network from the list.
- 8. **If it's secure-enabled**, enter the **Encryption Key** or **Pass Phrase** and touch **Next**.
- 9. Touch Done.

You're done! You are now connected to a wireless network and can connect to the Internet.





► Tools & Settings (cont'd)

Network & Phone Settings (cont'd)

Network Setup (cont'd)

Set Up Wireless Network via Static IP

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch Network Setup.
- 5. Touch Wireless Settings.
- 6. Touch Advanced.
- 7. Enter the **IP Address**, **Subnet** and **Gateway** address.
- 8. Touch Advanced.
- 9. Touch Done.

You're done!

Connect to Wireless Network

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch **Network & Phone Settings**.
- 4. Touch Network Setup.
- 5. Touch Wireless Enable.
- 6. Once your device connects, your status will be updated.





► Tools & Settings (cont'd)

Network & Phone Settings (cont'd)

Network Setup (cont'd)

Connect to Wired Network

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch Network Setup.
- 5. Touch Wired Enable.
- 6. Once your device connects, your status will be updated.

You're done!

Voice Mail Setup Set Up Voice Mail

- 1. Touch **Menu**.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch Voice Mail Setup.
- 5. Enter your Verizon **Phone Number**.
- 6. Enter your 4-digit Verizon Home Voice Mail **PIN**.
- 7. Touch Done.





► Tools & Settings (cont'd)

Network & Phone Settings (cont'd)

Handsets

Register Handsets

- First, you must activate registration mode on the base unit.
- 2. Touch Menu.
- 3. Tap Tools & Settings.
- 4. Touch Handset Registration.
- 5. Tap Register Handset.
- 6. Now the base unit is ready to accept the cordless handset registration.
- 7. Press the **OK** button on the handset.
- Use the navigation button to select Register Handset and press OK.
- 9. Select **Subscription** and press **OK**.
- 10. Select Base #1 and press OK.
- 11. Enter 1111 as your PIN and press OK.
- 12. After 3 seconds, the handset will automatically register to the base unit.
- 13. To verify successful registration, press 1. A dial tone will be emitted from the handset and it's ready to place a call.

Note: If there is no dial tone but the handset successfully registered with the base, verify that the base unit is connected to an active telephone line and that this line is plugged into the phone port on the back of the base unit.





► Tools & Settings (cont'd)

Network & Phone Settings (cont'd)

System Info


View System Information

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch **System Info**.
- 5. Touch Version Info.
- 6. The version information will appear.

You're done!

Update System Information

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch System Info.
- 5. Touch **Update**.
- 6. The device will update itself from the server. This may take a minute.





► Tools & Settings (cont'd)

Account Settings

Reset to Factory Defaults

- 1. Touch Menu.
- 2. Touch Tools & Settings.
- 3. Touch Network & Phone Settings.
- 4. Touch Account Settings.
- 5. Touch Reset to Factory Defaults.
- 6. Touch **Yes** if you want to continue.

Note: This will erase all data from your Verizon One.



Regulatory Information

FCC Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

FCC RF Radiation Exposure Statement

The installation of the base unit should allow at least 20 centimeter between the base and persons to be in compliance with FCC RF exposure guidelines. For body worn operation, the portable part (handset) has been tested and meets FCC RF exposure guidelines.

This device must not be co-located or operating in conjunction with any other antenna or transmitter. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Troubleshooting

If you need help with your Verizon One, try these troubleshooting tips.

Restart your Verizon One

- 1. Unplug the power supply cord from the outlet.
- 2. Wait for 15 seconds, and then plug the cord back into the outlet.
- 3. The base unit screen will power up.

Call Customer Support

If you are unable to solve your issue by restarting or referencing the User Guide, please call Customer Support.

Verizon FiOS Customers: 1-888-553-1555

Verizon High Speed Internet (DSL)

Customers: 1-800-567-6789



www.verizon.com/verizon-one

Bar Code