

FRONT

## WIRELESS SPEAKER USER MANUAL


### KEY FEATURES

- Two channel stereo amplifying audio circuit
- Dual NdFeB magnetic speakers
- Touch sensitive key controls
- Up to 20 hours playing time
- Built-in 1800 mAh lithium battery
- Connect to most audio devices using the 3.5mm audio cable
- Speaker phone and conference call function
- Audible function alerts

### OPERATING INSTRUCTIONS

- ① Indicator Light
- ② Volume Down [Hold]  
Previous Track [Double Touch]
- ③ Answer [Touch] / Hang Up [Hold]  
Play / Pause
- ④ Volume Up [Hold]  
Next Track [Double Touch]
- ⑤ 3.5mm Audio Port
- ⑥ USB Charging Port
- ⑦ Power On/Off

### OPERATING INSTRUCTIONS



#### Turning the speaker on

Slide the Power Switch [7] to the ON position

#### Charging the speaker

Connect the speaker to your computer or other 1Amp USB charger using the supplied USB cable. The indicator Light [1] will flash red whilst charging and turn off when fully charged. Charging time is approximately 6 to 8 hours.

### CONNECT

#### Wireless

1. When turned on, the Speaker will automatically start in wireless Bluetooth mode and will either:
  - a) Connect to an already paired device
  - b) Search for a compatible device by saying "Waiting for connection" and the indicator light will flash rapidly green and blue.
2. Access the Bluetooth menu on your audio device and search for the speaker. Once selected and connected, the indicator will turn blue and flash slowly.
3. Some devices may request a password, enter "0000" and confirm the connection.

#### Wired

Connect the speaker to any Audio device headphone port using the supplied 3.5mm audio cable.

Note: Bluetooth function is disabled when using the 3.5mm cable and wireless devices will not be connected.

BACK

## AUDIO & PHONE CONTROLS

### Wireless Audio

When connected wirelessly the audio device will automatically begin playing. If the audio is not audible then check or re-establish the Bluetooth connection.

### Wired

When connected by the 3.5mm audio cable, the indicator light will alternately flash green and blue. Playback controlled by the audio player.

### Music Control [see Operating Instructions]

Hold the + and - keys to adjust volume and double-touch to skip tracks forward or backward. Press the Call key once to Play or Pause playback. In wired mode this will only silence the audio.

### Phone Control

Incoming calls will be transferred to the Speaker when connected in Bluetooth mode. The indicator light will flash blue and a voice prompt will announce the call.

Press the Call button to answer or hold down to reject.

Music play is automatically paused during a call.

## SUPPORT

### Frequently Asked Questions

Q: I can't hear my music.

A: 1. Check the speaker volume  
2. Check the speaker is paired correctly or connected by the audio cable to a device playing music.

Q: I can't answer or end a call.

A: Some mobile devices do not support hands free calling. Check your mobile device manual.

Q: I can't connect two devices at once.

A: This speaker does not support multiple connections.

Q: I can't wirelessly connect to the speaker.

A: 1. Check your device has Bluetooth enabled and that the device and speaker are paired.

2. Disconnect any previously connected device.

Q: I hear a crackling noise.

A: Objects can interfere with the wireless Bluetooth signal. Ensure that the speaker is within 10 metres of the connect device and no major objects (walls, etc.) are obstructing the signal.

### Caring for your speaker

Always store the speaker with the power off and in a clean, dust free environment, and away from children.

Avoid storing at extreme temperatures that may affect battery life and speaker performance.

## TECHNICAL INFORMATION

Weight: 240 grams

Dimensions: 122 x 60 x 48mm

Speaker: Omnidirectional

Power Supply: DC 5V via USB

Power: 2 x 3 Watt

Speaker Unit: 2 x 40mm NdFeb full band speakers

Audio Port: 3.5mm audio input jack

Battery: 1800mAh rechargeable lithium battery

Operating Range: Up to 10 metres (33 feet)

Bluetooth: Version 2.1

Bluetooth Profile: HFPV1.5, HSPV1.2, AVRCP

Playing Time: Up to 20 hours depending on volume

Charging Time: Approx. 6 to 8 hours

Stored Temperature: -10°C to 55°C

Pairing Password Key: 0000

Accessories: User manual, USB cable, audio cable

All information contained herein is true and correct at the time of print. Any further queries can be directed through our website. Thank you.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.