

PHONE

TO:	DO:
Answer a call	Press Send key If you are connected to a call and you receive another call, press Send key to place the current call on hold and answer the incoming call
Open your call log	Hold Send key
Insert (+) into a phone number	Hold 0
Add an extension to a phone number	Press X and type the extension number
Turn speakerphone on or off during a call	Press OP
Check your voicemail	Hold 1
Use Voice Activated Dialing (VAD)	In VAD, wait for the sound Say "call" and a contact name or phone number
Increase volume during a call	Press Volume up key (on the right side of the smartphone)
Decrease volume during a call	Press Volume down key (on the right side of the smartphone)
Call a speed dial number	Hold assigned number key
Call your voicemail access number	Hold 1

CAMERA

TO:	DO:
Get to viewfinder mode	Press the Camera key (on the right side of the smartphone)
Take a picture	Click Trackball or the Camera key
Zoom in on a subject	In viewfinder mode, press Volume up key or roll Trackball up
Zoom out from a subject	In viewfinder mode, press Volume down key or roll Trackball down

MEDIA PLAYER

TO:	DO:
Pause a video or song	Press Mute key
Resume playing a video or song	Press Mute key again
Move to next item	Press 6
Move to previous item	Press 4
Zoom in to a picture	Press 3
Zoom out from a picture	Press 9
Zoom to original picture size	Press 5
Pause or resume a slide show	Press Space key

MESSAGES

TO:	DO:
Compose a message	Press Comma (,) key
Reply to a message	Press Exclamation point (!) key
Forward a message	Press Period (.) key
Reply to all	Press Question mark (?) key
View received messages	Press Alt key + 3
View phone call logs	Press Alt key + Period (.) key
View voicemail messages	Press Alt key + 7
View SMS messages	Press Alt key + Question mark (?) key
View all messages again	Press Escape key
Move up a message	Press 2
Move down a message	Press 8
Move up a screen	Press 3
Move down a screen	Press 9
Move to top of a screen	Press 1

Move to bottom of a screen	Press 7
Move to next item	Press 6
Move to previous item	Press 4
Create Voice Notes	Click OK in the Send Voice Note application and record a Voice Note
Send Voice Notes	Click Trackball and click Send as MMS

CALENDAR

TO:	DO:
Schedule an appointment quickly in Day view	In calendar options, set the Enable Quick Entry field to Yes Type the subject of the appointment beside start time Type a location in parentheses and click Trackball
Change the start time quickly in Day view	Type the subject and location of appointment Hold the Shift key and roll Trackball
Change the end time quickly in Day view	Type the subject and location of appointment Roll Trackball

For the following tips to work in Day view, go to calendar options and set the **Enable Quick Entry** field to **No**

Schedule an appointment	Press Period (.) key
Move to the next day, week or month	Press 6
Move to the previous day, week or month	Press 4
Move up an hour	Press 2
Move down an hour	Press 8

BROWSER

TO:	DO:
Insert a period (.) in the Go To dialog box	Press Space key
Insert a slash (/) in the Go To dialog box	Press Shift key + Space key
Open bookmarks list on a web page	Press 5
Add a bookmark on a web page	Press Question mark (?) key
View a thumbnail version of a web page	Press X To return to normal view, press any key
Stop loading a web page	Press Escape key
Move to a specific web page	Press Period (.) key
View or hide a web page banner	Press Exclamation point (!) key
Close the browser	Hold Escape key


BLACKBERRY MAPS™ 1

TO:	DO:
Zoom in to a map	Press Comma (,) key
Zoom out from a map	Press 0
View or hide status information at top of map	Press Exclamation point (!) key

BlackBerry Pearl



Tips and Tricks



Small. Smart and Stylish.

So you can live large.

BlackBerry® Pearl™ 8100™ smartphone



BLACKBERRY BASICS

TO:	DO:
Exit a screen or move back a page	Press Escape key
Delete highlighted items	Press Backspace/Delete key
Switch applications	Hold Alt key and press Escape key Continue to hold Alt key and select application Release Alt key
Return to Home screen	Press End key
Lock the keyboard	Hold (*)
Unlock the keyboard if no password is set	Press Send key + (*)
Password protect your smartphone	Set a password by choosing Options, Security Options, General Settings Hold (*) to password lock smartphone
Unlock the smartphone when it's locked with a password	Press Send key + (*) Type your password
Switch between Default and Vibrate notification profiles	Hold (#) on the Home screen
Turn on a theme	Highlight a theme and click Trackball
Turn on a notification profile	Highlight a notification profile and click Trackball

TRACKBALL

Move the cursor	Roll Trackball
Select or clear a check box	Click Trackball
Highlight adjacent items	Hold Shift key and roll Trackball

TYPING

Type an alternate character on a key	Hold Alt key and press character key
Type a symbol	Press Symbol key To view more symbols press Symbol key again Type letter shown below symbol or click on the symbol with the Trackball
Type an accent or special character	Hold letter key and roll Trackball Click selected character
Insert a period	Press Space key twice – the next letter is capitalized
Capitalize a letter	Hold letter key until capitalized letter appears
Type numbers	Hold Shift key and press Alt key
Insert a period or at sign (@) in an email address	Press Space key
Type a number in a number field	Press a number key
Type a number in a password field	Hold Alt key and press a number key
Type a letter in a number field	Hold Alt key and use the multi-tap input method
Switch typing input languages	On the Language screen, set Use Input Method Shortcut field to Yes Hold Alt key and press Enter key Highlight a language Release Alt key
Highlight a line of text	Press Shift key and roll Trackball
Highlight text character by character	Hold Shift key and roll Trackball left or right
Cancel a text selection	Press Escape key
Cut selected text	Press Shift key + Backspace/Delete key
Copy selected text	Press Alt key and click Trackball
Paste selected text	Press Shift key and click Trackball

SEARCH

Search for a contact in a list of contacts	Type contact name or initials separated by a space
--	--

ATTACHMENTS

Play a .wav attachment	Open .wav file Press Menu key Click Play
Zoom in to a picture or image attachment	Press 3
Zoom out of a picture	Press 9
Zoom to the original picture or image attachment size	Press 5
Rotate a picture	Press Comma (,) key
Open an attachment	In a message, click Trackball Click Open Attachment
Open the file attachment	Click Full Content
Search for text in an attachment	Press Exclamation point (!) key
Switch between table of contents and full content of an attachment	Press Period (.) key
Change the size of a column in a spreadsheet	Press At sign (@) key
Move to a specific cell in a spreadsheet	Press Question mark (?) key
View the content of a cell in a spreadsheet	Press Space key
View a presentation as a slide show	Press Question mark (?) key
Stop a slide show	Hold Escape key
Switch presentation views	Press At sign (@) key
Open a table of contents for the file attachment	Click Table of Contents

NAVIGATING SCREENS

Move cursor	Roll Trackball
Exit a screen or dialog box	Press Escape key
Click an icon or menu item	Roll Trackball to select item Click Trackball
Move to top of screen	Press 1
Move to bottom of screen	Press 7

GENERAL TIPS

Reboot	Remove battery
Save battery	Turn off BlackBerry smartphone in fringe or no-coverage areas – Press and hold End key Exit camera viewfinder mode when not in use Keep your camera flash set to automatic or off Keep your backlight setting on a lower setting Turn off Bluetooth® when not in use Use a BlackBerry Authentic Accessories™ carrying solution which automatically triggers the LCD to turn off

www.blackberrypearl.com **BlackBerry Pearl™**

Check with service provider for roaming arrangements, service plans and supported features and services. RIM makes no representation, warranty or guarantee and assumes no liability whatsoever in relation to third party products and services.
1. The BlackBerry Maps application is currently available in the United States and Canada. Check with your service provider for availability.
©2006 Research In Motion Limited. All Rights Reserved. The BlackBerry family of related marks, images and symbols are the exclusive properties and trademarks of Research In Motion Limited. BlackBerry is registered with the U.S. Patent and Trademark Office and may be pending or registered in other countries. ®Rogers, the Mobius design and YOUR WORLD RIGHT NOW are trademarks of Rogers Communications Inc., used under license. All other brands, product names, company names, trademarks and service marks are the properties of their respective owners.
Printed in Canada. MKT-13272-001