



motorola W315

Getting to Know Your Phone



MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners.
© Motorola, Inc. 2006


Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this tutorial, are based on the latest available information and believed to be accurate at the time of publication. Motorola reserves the right to change or modify any information or specifications without notice or obligation.



Note: Your phone may not appear exactly as the phone image above, however, all key locations, sequences, and functions remain the same.





motorola W315


Make, End, and Answer Calls


1 From the home screen, enter a number and press .

Tip: Press  to delete the last number.
Press and hold  to erase all numbers.
Press **STORE** to add the number to your Contacts.



2 To end a call, press .

3 To answer a call, press .


Tip: To answer a call by pressing any key, press  then scroll to **Settings > In Call Setup > Answer Options** and set **Any Key** to **On**.




motorola W315

Add Contacts


1 From the home screen, press **OK**.
Scroll to **Contacts**, then press **SELECT**.



2 Scroll to **Create New Contact**, then press **OK**.




3 Scroll to **Phone Number**, then press **SELECT**.



4 For each field, press **CHANGE**, enter the information, then press **OK**.

Tip: To record a contact's name for voice dialing, scroll to **Voice Name**, press **RECORD**, press the **Voice key** and say the **contact's name**.



5 When you are finished, press **DONE**.





motorola W315

Send a Text Message


1 From the home screen, press **OK**.
Scroll to **Messaging**, then press **SELECT**.




2 Scroll to **New TXT Msg**, then press **OK**.



3 Scroll to the recipient(s) for your message and press **OK**, then press **NEXT**.



4 Enter your message and press **NEXT**, then press **SEND**.





motorola W315

Add a Datebook Event


1 From the home screen, press **OK**.
Scroll to **Calendar** and press **SELECT**.



2 Scroll to the day you want to schedule an event and press **OK**, then scroll to **New Event** and press **OK**.




3 Enter a title for the event and press **OK**.



4 Scroll to other fields to enter information such as: start time, event duration, event date, repeat the event, and set an alarm for the event. Press **OK** to enter the information.



5 Press **DONE** to store the new event.





motorola W315

Set Ring Styles

1 From the home screen, press **OK**.
Scroll to **Alert Styles** and press **SELECT**.



2 Scroll to **Detail** for the style and press **SELECT**.



3 Scroll to the alert you want (Calls, Text Msgs, Voicemail, etc.), scroll right or left to select the ringtone, and then press **DONE** twice.

