

SCHWINN



BLUTUNES™ BLUETOOTH® BIKE SPEAKER


Bluetooth® Bike Speaker

Size: 155 mm × 64 mm × 35 mm

Voltage: 3.7V

Output Power: 3W

OPERATION



BATTERY INSTALLATION

1. Remove the battery cover and insert the BL-5C li-ion battery using the correct polarity direction indicated on the bottom of the compartment.
2. Replace battery cover.

CAUTION:

- Use specified charger only
- Do not dispose of batteries in fire. Batteries may explode or leak
- Do not short-circuit
- Store and use product at ambient temperature
- Do not expose product to rain or damp surroundings
- Prevent product from falls that could result in serious damage
- Do not dismantle, repair or modify product on your own
- Must be recycled or disposed of properly

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

OPERATING INSTRUCTIONS

To listen to your music over Bluetooth® wireless connection, you need to pair your device with Schwinn® BluTunes™:

1. Make sure your device has Bluetooth® capability.
2. Slide POWER SWITCH to turn on the unit. Indicator will begin to flash.
3. Follow the instructions of your device to pair the unit.
4. Pair your device with the unit by selecting Schwinn® BluTunes™ from your Bluetooth® listings on your device or selecting YES.
5. Press play on your device and use controls on the unit to adjust volume.
6. Use the Play/Pause button to play or pause your music.
7. Use the Next button to advance tracks. Use the Previous button to go to the previous track.
8. Schwinn® BluTunes™ has a built-in high visibility light.
To turn on the light, press the LIGHT button once. Press LIGHT again to dim the light.
Press LIGHT again to change to a high visibility flashing light.
Press LIGHT again to turn off the light completely.

Power Charging

1. Indicator is red when charging and will turn off when fully charged. It will take up to 4 hours to fully recharge the battery. Battery life is approximately 4 hours of playback.
2. Use the included MicroUSB charging cable with a standard USB wall charger.

MOUNTING BRACKET INSTALLATION

1. Clamp the mount onto the rubber sides of the Schwinn® BluTunes™.
2. Attach the mounting bracket onto your bicycle by tightening the fastening screw.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

PACIFICCYCLE 

4902 HAMMERSLEY ROAD / MADISON, WI 53711 USA
1-800-515-0074 / CUSTOMERSERVICE@PACIFIC-CYCLE.COM
© 2013 PACIFIC CYCLE, INC. MADE IN CHINA

WWW.SCHWINNBIKES.COM  