

First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit
0	0	0	0	0	0	0	0
1	1	1	1	1	1	1	1
2	2	2	2	2	2	2	2
3	3	3	3	3	3	3	3
4	4	4	4	4	4	4	4
5	5	5	5	5	5	5	5
6	6	6	6	6	6	6	6
7	7	7	7	7	7	7	7
8	8	8	8	8	8	8	8
9	9	9	9	9	9	9	9
232	【	270	圭揭繼頸桁件嫌	311	蝕心珍身尋	347	審申診玉
233	珪携繫鷄傑俊建	271	啓頰經脛隙月豎	312	每慎真辛甚	348	寢深親塵
234	【	272	兄慧系籌激淚圈	313	仔妍玖私試侍	349	娠浸薪刃鞞
235	卦型戲聖云欠倦憲檢見元駭	273	刑廢稽詣擊血喧	314	仕始支社詩似	350	齋榛忒仁鞞
236	【	274	偵惠睦計劇結刺	315	士指獅詞事	351	信晉紳震訊
237	卮裂契景莖迎決健懸權謙原言	275	研險源	316	四思氏視齒	352	侵森臣人迅
238	【	276	獻道弦	317	疔疾私試侍	353	伸新泰針腎
239	【	277	呼狐履後酬功	318	疔疾私試侍	354	尻振神進戾
240	【	278	固狐履後酬功	319	而竺悉之煮勾弱樞樹	【	豆袁數裾
241	【	279	古枯跨吾誤光	320	示矚至柴斜借救珠授	【	吹逐叔
242	【	280	個故誇異語碎	321	瘳式矢篠捨蛇鏡殊呪	【	厨翠高雀守
243	【	281	呼狐履後酬功	322	磁識嫉億敢邪若若壽	【	帥鍾繼
244	【	282	孝恒校硬肱郊鴻趨漣	323	瘳式矢篠捨蛇鏡殊呪	【	垂醉趨
245	【	283	孔弘抗星背膺高轟獄	324	愁冤執執部討遮積充受	【	韻翠趨
246	【	284	好康更甲首責象果黑	325	示矚至柴斜借救珠授	【	漱成生近戚赤劬占泉線舛閃煙
247	【	285	坤垠	326	洲襲住重熟駿純渚水	【	敢整精青昔蹟說專洗
248	【	286	恨魄	327	秀豐允銑出淮巡庶序	【	瀨政成生近戚赤劬占泉線舛閃煙
249	【	287	【	328	拾榮什縱豎髮周暑畧	【	蕭前
250	【	288	【	329	唱庄昌湘章諷障壤穰	【	世成生近戚赤劬占泉線舛閃煙
251	【	289	【	330	嘗床昭曉笑詔誦燥穰	【	性性情借責設干柁箭隙統膳
252	【	290	【	331	商尚捷消祥衝鐘城場	【	征清舊席沓折先栓穿羨錢繕
253	【	291	【	332	嘗床昭曉笑詔誦燥穰	【	姓正誠委績傾仙撰旋織遷澤
254	【	292	【	333	嘗床昭曉笑詔誦燥穰	【	勢栖西脛籍接婢扇扇
255	【	293	【	334	嘗床昭曉笑詔誦燥穰	【	選全
256	【	294	【	335	嘗床昭曉笑詔誦燥穰	【	曾紹高接滄草霜
257	【	295	【	336	嘗床昭曉笑詔誦燥穰	【	楚蘇表掃操壯驛驅束袖
258	【	296	【	337	嘗床昭曉笑詔誦燥穰	【	萃萃
259	【	297	【	338	嘗床昭曉笑詔誦燥穰	【	他花仗腿
260	【	298	【	339	嘗床昭曉笑詔誦燥穰	【	【
261	【	299	【	340	嘗床昭曉笑詔誦燥穰	【	【
262	【	300	【	341	嘗床昭曉笑詔誦燥穰	【	【
263	【	301	【	342	嘗床昭曉笑詔誦燥穰	【	【
264	【	302	【	343	嘗床昭曉笑詔誦燥穰	【	【
265	【	303	【	344	嘗床昭曉笑詔誦燥穰	【	【
266	【	304	【	345	嘗床昭曉笑詔誦燥穰	【	【
267	【	305	【	346	嘗床昭曉笑詔誦燥穰	【	【
268	【	306	【	【	【	【	【
269	【	307	【	【	【	【	【
270	【	308	【	【	【	【	【
271	【	309	【	【	【	【	【
272	【	310	【	【	【	【	【
273	【	【	【	【	【	【	【
274	【	【	【	【	【	【	【
275	【	【	【	【	【	【	【
276	【	【	【	【	【	【	【
277	【	【	【	【	【	【	【
278	【	【	【	【	【	【	【
279	【	【	【	【	【	【	【
280	【	【	【	【	【	【	【
281	【	【	【	【	【	【	【
282	【	【	【	【	【	【	【
283	【	【	【	【	【	【	【
284	【	【	【	【	【	【	【
285	【	【	【	【	【	【	【
286	【	【	【	【	【	【	【
287	【	【	【	【	【	【	【
288	【	【	【	【	【	【	【
289	【	【	【	【	【	【	【
290	【	【	【	【	【	【	【
291	【	【	【	【	【	【	【
292	【	【	【	【	【	【	【
293	【	【	【	【	【	【	【
294	【	【	【	【	【	【	【
295	【	【	【	【	【	【	【
296	【	【	【	【	【	【	【
297	【	【	【	【	【	【	【
298	【	【	【	【	【	【	【
299	【	【	【	【	【	【	【
300	【	【	【	【	【	【	【
301	【	【	【	【	【	【	【
302	【	【	【	【	【	【	【
303	【	【	【	【	【	【	【
304	【	【	【	【	【	【	【
305	【	【	【	【	【	【	【
306	【	【	【	【	【	【	【
307	【	【	【	【	【	【	【
308	【	【	【	【	【	【	【
309	【	【	【	【	【	【	【
310	【	【	【	【	【	【	【










First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit
382	0	412	0	442	0	468	0
383	1	411	1	441	1	469	1
384	2	413	2	443	2	470	2
385	3	414	3	444	3	471	3
386	4	415	4	445	4	472	4
387	5	416	5	446	5	473	5
388	6	417	6	447	6	474	6
389	7	418	7	448	7	475	7
390	8	419	8	449	8	476	8
391	9	420	9	444	9	477	9
392	0	421	0	445	0	478	0
393	1	422	1	446	1	479	1
394	2	423	2	447	2	480	2
395	3	424	3	448	3	481	3
396	4	425	4	449	4	482	4
397	5	426	5	450	5	483	5
398	6	427	6	451	6	484	6
399	7	428	7	452	7	485	7
400	8	429	8	453	8	486	8
401	9	430	9	454	9	487	9
402	0	431	0	455	0	488	0
403	1	432	1	456	1	489	1
404	2	433	2	457	2	490	2
405	3	434	3	458	3	491	3
406	4	435	4	459	4	492	4
407	5	436	5	460	5	493	5
408	6	437	6	461	6	494	6
409	7	438	7	462	7	495	7
410	8	439	8	463	8	496	8
	9	440	9	464	9	497	9
		441		465		498	
		442		466		499	
		443		467		500	
		444				501	
		445				502	
		446				503	
		447				504	
		448				505	
		449				506	





First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit
507	0	550	0	593	0	636	0
508	1	551	1	594	1	637	1
509	2	552	2	595	2	638	2
510	3	553	3	596	3	639	3
511	4	554	4	597	4	640	4
512	5	555	5	598	5	641	5
513	6	556	6	599	6	642	6
514	7	557	7	600	7	643	7
515	8	558	8	601	8	644	8
516	9	559	9	602	9	645	9
517	0	560	0	603	0	646	0
518	1	561	1	604	1	647	1
519	2	562	2	605	2	648	2
520	3	563	3	606	3	649	3
521	4	564	4	607	4	650	4
522	5	565	5	608	5	651	5
523	6	566	6	609	6	652	6
524	7	567	7	610	7	653	7
525	8	568	8	611	8	654	8
526	9	569	9	612	9	655	9
527	0	570	0	613	0	656	0
528	1	571	1	614	1	657	1
529	2	572	2	615	2	658	2
530	3	573	3	616	3	659	3
531	4	574	4	617	4	660	4
532	5	575	5	618	5	661	5
533	6	576	6	619	6	662	6
534	7	577	7	620	7	663	7
535	8	578	8	621	8	664	8
536	9	579	9	622	9	665	9
537	0	580	0	623	0	666	0
538	1	581	1	624	1	667	1
539	2	582	2	625	2	668	2
540	3	583	3	626	3	669	3
541	4	584	4	627	4	670	4
542	5	585	5	628	5	671	5
543	6	586	6	629	6	672	6
544	7	587	7	630	7	673	7
545	8	588	8	631	8	674	8
546	9	589	9	632	9	675	9
547	0	590	0	633	0	676	0
548	1	591	1	634	1	677	1
549	2	592	2	635	2	678	2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9
	0		0		0		0
	1		1		1		1
	2		2		2		2
	3		3		3		3
	4		4		4		4
	5		5		5		5
	6		6		6		6
	7		7		7		7
	8		8		8		8
	9		9		9		9





First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit	First Three Digits	Last Digit
0	1	0	1	0	1	0	1
679	筌	722	莢	765	膊	808	韶
680	筌	723	筌	766	臍	809	頰
681	筌	724	筌	767	臍	810	頰
682	筌	725	筌	768	臍	811	頰
683	筌	726	筌	769	臍	812	頰
684	筌	727	筌	770	臍	813	頰
685	筌	728	筌	771	臍	814	頰
686	筌	729	筌	772	臍	815	頰
687	筌	730	筌	773	臍	816	頰
688	筌	731	筌	774	臍	817	頰
689	筌	732	筌	775	臍	818	頰
690	筌	733	筌	776	臍	819	頰
691	筌	734	筌	777	臍	820	頰
692	筌	735	筌	778	臍	821	頰
693	筌	736	筌	779	臍	822	頰
694	筌	737	筌	780	臍	823	頰
695	筌	738	筌	781	臍	824	頰
696	筌	739	筌	782	臍	825	頰
697	筌	740	筌	783	臍	826	頰
698	筌	741	筌	784	臍	827	頰
699	筌	742	筌	785	臍	828	頰
700	筌	743	筌	786	臍	829	頰
701	筌	744	筌	787	臍	830	頰
702	筌	745	筌	788	臍	831	頰
703	筌	746	筌	789	臍	832	頰
704	筌	747	筌	790	臍	833	頰
705	筌	748	筌	791	臍	834	頰
706	筌	749	筌	792	臍	835	頰
707	筌	750	筌	793	臍	836	頰
708	筌	751	筌	794	臍	837	頰
709	筌	752	筌	795	臍	838	頰
710	筌	753	筌	796	臍	839	頰
711	筌	754	筌	797	臍	840	頰
712	筌	755	筌	798	臍		
713	筌	756	筌	799	臍		
714	筌	757	筌	800	臍		
715	筌	758	筌	801	臍		
716	筌	759	筌	802	臍		
717	筌	760	筌	803	臍		
718	筌	761	筌	804	臍		
719	筌	762	筌	805	臍		
720	筌	763	筌	806	臍		
721	筌	764	筌				
722	筌						





Weather Indicator List





- Indicators and categories are subject to change without prior notice.




Weather	
	Clear (day)
	Clear (night)
	Cloudy
	Rain
	Snow
	Thunderstorm
	Precipitation 0%-100%
	Later
	Occasionally




Pollen Level	
	Low
	Moderate
	High
	Very High

Cherry Blossom	
	Blossoms Opening
	Near Full Bloom
	Peak Bloom
	Past Peak

Fall Foliage	
	No Color
	Moderate Color
	Peak Color
	Past Peak

UV Level	
	Low
	Moderate
	High
	Very High

Typhoon	
	Formed
	Approaching
	Severe

Other Information	
	Heavy Rain
	Strong Winds
	Notifications

Memory List

Data Folder	Up to 3500 items (Up to 100 MB) (One S! Appli corresponds up to 6 MB.)
--------------------	---

- Shared with S! Appli List

Calendar Events	Up to 1000 items
------------------------	------------------

Phone Book	Up to 1000 items
-------------------	------------------

Messaging (SMS and S! Mail combined)	Incoming Mail	Up to 1000 items
	Sent/Unsent	Up to 500 items
	Drafts	Up to 10 items

Yahoo! Keitai	Saved Pages	[Yahoo! Keitai] Up to 20 items/750KB [PC Site Browser] Up to 20 items/1150KB
	Bookmarks	[Yahoo! Keitai] Up to 100 items [PC Site Browser] Up to 100 items
	URL History	[Yahoo! Keitai] URL Entry: Up to 20 items URL Access: Up to 100 items* [PC Site Browser] URL Entry: Up to 20 items URL Access: Up to 100 items*
	Cache	[Yahoo! Keitai] 750KB [PC Site Browser] 1150KB

* The number of savable items varies depending on URL length.

Specifications

842P

Weight (including battery)		108 g*
Dimensions (closed)		50 x 110 x 10 mm (thinnest part)*
Standby Time (closed)	3G	460 hours*
	GSM	240 hours*
Talk Time	3G	180 minutes*
	Video Call	120 minutes*
	GSM	180 minutes*
TV Reception Time	Normal Mode	5.5 hours*
	ECO Mode	7.1 hours*
Charging Time	AC Charger	100 minutes*
	In-Car Charger	100 minutes*
Maximum Output	3G	0.25 W
	GSM	2.0 W

* Approximate value

- Values above were calculated with battery installed.
- Talk Time is an average measured with a new, fully charged battery, with stable signals.
- Standby Time is an average measured with a new, fully charged battery, with handset closed without calls or operations, in Standby with stable signals.
- TV-Reception Time is an average measured using earphone/microphone, with stable signals.
- Talk Time and Standby Time may vary by environment (battery status, temperature, etc.).
- Talk Time and Standby Time may decrease when a S! Appli is active.

Battery

Voltage	3.7 V
Battery Type	Lithium-ion
Capacity	600 mAh
Dimensions	45 x 3.8 x 37 mm*

* Approximate value

- Specifications subject to change without notice.

Index

Numerics

3G 2-10

A	
AC Charger	1-13
Access History	
PC Site Browser	14-5
Yahoo! Keitai	14-4
Account Details	1-26, 4-13
Address (Adding/editing/deleting)	13-8
After-Sales Service	18-32
Alarms	12-7
All Reset	11-12
Alternative Image	2-6
Answer Phone	2-15
Answering Calls	
Video Calls	2-8
Voice Calls	2-5
Attachments	
Adding	13-8
Deleting	13-8
Opening/saving	13-13
Auto Answer	17-6
Auto Focus Lock	6-10
Auto Save (Camera)	6-8
Auto timer	6-6
Auto-sort	13-16

B	
Back Light	
Display	17-5
S! Appli	17-17
Video Calls	2-12
Backup	
microSD Card	9-18
S! Address Back-up	4-10
Bar Code Reader	12-12
Basic Operations	
Handset	x
Internet	14-6
Battery	1-10
Battery Level	1-9, 1-11
Bookmarks	14-8
Books folder	9-3
BookSurfing®	7-6
Brightness	
Camera	6-3
Display	17-5
Video Calls	17-11
Video Camera	6-4
Browser (Initializing)	17-16

C

Cache Memory.....	14-2
Calculator	12-8
Calendar	12-2
Calendar Events.....	12-2
Call Barring.....	2-20
Call Cost	17-8
Call Forwarding	2-17
Call Log.....	2-13
Call Operations.....	2-11
Call Rejection	
Calls without Caller ID	11-11
Unknown Callers	11-11
Call Settings	17-8
Call Time	17-8
Call Waiting	2-19
Caller ID.....	2-3, 2-21
Camera [Section Contents].....	6-1
Center Access Code	1-23
Channel Setting	5-4
Character Code (Kuten Code)	
Character Code List.....	18-18
Input Options	3-5
Charge Limit	17-8
Charging Time	1-10
Check microSD.....	9-20
Clock Display.....	17-4
Closing Clamshell	17-8
Color Scheme.....	17-3
Content Key	9-5
Context Forecast	3-6

Continuous Shooting.....	6-5
Conversion Candidates.....	3-6
Conversion Methods.....	3-6
Cookies	
Deleting.....	17-15
Settings	17-16
Copy Protected Files.....	9-4
Country/Region Code	2-10
Customer Service.....	18-33
Customized Screen	1-20

D

Data Folder.....	9-2
Date & Time Settings.....	17-7
Deleting	
Calendar events	12-5
Messages.....	13-21
Phone Book	4-9
S! Appli.....	15-4
Delivery Report	13-9
Dictionary	12-10
Digital TV [Section Contents]	5-1
Digital TV Settings.....	17-11
Display.....	1-8
Display Indicators.....	1-8
Display Settings.....	17-3

Download

Customized Screen.....	1-20
Familiar Usability.....	1-20
From web pages.....	14-11
Lifestyle-Appli	16-3
Music.....	8-2
S! Appli.....	15-2
Templates	13-10
Drafts.....	13-15
Driving Mode.....	1-16, 17-6

E

e-Book Viewer	7-6
Earpiece Volume	
Video Calls	2-7
Voice Calls	2-5
Emergency Calls (110, 119, 118)	2-4
Emergency Positioning Request	2-4
Emission OFF Mode	1-16
Event Indicators.....	1-16

F

Familiar Usability.....	1-20
Flash® files.....	9-19
Flash(R) folder.....	9-19
Focus Setting.....	6-9
Folder/files.....	9-14
Font Size	
Call Log.....	2-14
Internet.....	17-15
Messages.....	17-14
Phone Book.....	4-7
Font Size (Collective Setting).....	17-5
Function List.....	18-2

G

Global Roaming Service.....	2-9
Graphic Mail.....	13-5
Group Settings.....	4-6
GSM.....	2-10

H

Handset	
Menus.....	1-18
Parts & Functions.....	1-4
Power On/Off.....	1-14
Handset Security [Section Contents]....	11-1
Help (Text Entry).....	3-2
Hold	
Video Calls.....	2-12
Voice Calls.....	2-11
HTML messages.....	13-5

I

IC Card Lock.....	16-5
IC Transmission.....	10-4
IDD Prefix.....	2-9
Image quality	
Still images.....	6-3
Videos.....	6-4
Image size	
Still Images.....	6-3
Videos.....	6-4
Incoming Call Logs.....	2-13
Incoming Options (S! Mail).....	17-14
Information (S! Appli).....	15-2
Infrared.....	10-2
Input Character Settings (SMS).....	17-14
Internal Display.....	17-3
International Call	
From abroad.....	2-9
From Japan.....	2-9

International Setting.....	2-10
Internet [Section Contents].....	14-1

K

Key Assignments	
Mode 1 (5-touch).....	18-14
Mode 2 (2-touch).....	18-15
Mode 3 (NIKO-touch).....	18-16
Key Pad Dial Lock.....	11-7
Key Tone.....	17-2
Keyguard.....	11-3
Kuten Code (Character Code).....	18-18

L

Language.....	17-3
License Information (S! Appli).....	15-2
Location Settings.....	12-14
Lock Message.....	11-7
Lock OFF at Open.....	11-6

M

Mail Group.....	13-18
Mail Security.....	11-10
Main Menu	1-18
Making Calls	
International Calls.....	2-9
Video Calls	2-7
Voice Calls	2-2
Manner Mode	1-15, 2-11, 2-12, 17-6
Manufacture Number	17-16
Memory List.....	18-24
Memory Manager (Internet).....	17-15
Menu Icons	17-4
Menu Numbers	1-19
Messaging [Section Contents].....	13-1
microSD Card.....	9-15
Backup.....	9-18
Formatting.....	9-17
Synchronizing	17-17
Missed Call Notification	2-19
Mobile W-Speed	5-2
MULTI Key	1-5, 1-25, 12-10
Multi Selector	ix
Music folder.....	9-2
Music Player [Section Contents].....	8-1
My Pictograms.....	9-2, 13-6

N

Network Information	1-14
Network S! Appli	15-2

New Messages

Receiving.....	13-15
Viewing	13-10
Night mode	
Camera	6-3
Video Calls	17-11
Video Camera	6-4
Normal Mode (Simple Menu)	1-22
Notepad.....	12-9
Notification Light Settings	17-9

O

One-push Open Button.....	1-6
Open For New.....	17-3
Open-to-Ans. Call.....	17-6
Operator Names	2-11
Optional Services	2-16
Original Animation	9-13
Osaifu-Keitai® [Section Contents].....	16-1
Other Documents folder.....	9-3
Outgoing Call Logs	2-13

P

Passwords	1-23
Passwords (Changing)	
Center Access Code	1-23
Phone Password	11-2
Security Code	2-20

PC Site Browser	14-2
Access.....	14-5
Display Settings	17-15
Memory Manager & Settings	17-15
Security Settings	17-16
Personal Data Lock	11-4
Phone Book [Section Contents].....	4-1
Phone Password	1-23
Changing	11-2
Photo mode	
Still images.....	6-3
Videos.....	6-4
Pictographs.....	3-4
Pictures (Still Images)	
Capturing	6-5
Editing	9-12
Pictures folder	9-2
PIN/PIN2	1-3
Changing	11-2
PIN Authentication	11-2
PIN Lock & Cancellation (PUK)	11-3
Play Background.....	8-7
Play List	8-10
Play mode setting.....	8-6
Predictive Candidates.....	3-6
Preview Window	
Camera	6-3
Video Camera	6-4
Privacy Key Lock	11-4
Private Menu	1-21
PUK/PUK2	1-3, 11-3

Q

QR Code.....	12-12
Quality	
Still images.....	6-3
Videos.....	6-4
Quick Open Menu.....	18-13

R

Recipients (Adding/editing/deleting) ...	13-8
Referer Information.....	17-16
Remote Lock.....	16-5
Reset.....	11-12
All Reset.....	11-12
Browser Settings.....	17-16
Settings.....	11-12
Total Cost.....	17-8
Total Duration.....	17-8
TV Settings.....	17-12
Ring Songs&Tones folder.....	9-2
Ring Time (Answer Phone).....	2-16
Ring Time Settings.....	11-11
Ringer Volume.....	17-2
Ringtone.....	9-8, 17-2
Ringtone Duration.....	17-2
Root Certificates.....	17-16

S

S! Addressbook Back-up.....	4-10
S! Appli [Section Contents].....	15-1
S! Information Channel.....	7-4
S! Mail.....	13-2
Creating/sending.....	13-4
Mail Notice.....	13-11
Settings.....	17-14
Universal Settings.....	17-14
S! Quick News.....	1-17, 7-2
Save	
Alarms.....	12-7
Calendar.....	12-2
Notepad.....	12-9
Phone Book.....	4-3, 17-10
S! Information Channel.....	7-4
S! Quick News.....	7-2
Shortcuts.....	1-17
Still Images.....	6-8
User's Dictionary.....	3-10
Videos.....	6-8
Saved Pages.....	14-8
Script.....	17-16
Scroll Unit.....	17-15
SD Audio.....	8-2
Secret Data Only.....	11-9
Secret Mail Setting.....	11-9
Secret Mode.....	11-9
Secure Remote Lock.....	11-6
Security Code.....	1-24
Security Functions.....	11-2

Security level.....	15-4
Security Settings (Internet).....	17-16
Security Settings (Mail).....	11-10
Server Mail.....	13-14
Settings [Section Contents].....	17-1
Shikkari Talk.....	2-5
Shortcuts.....	1-17
Shutter sound.....	6-8
Side-keys Guard.....	11-8
Signal Strength.....	1-8
Simple Menu.....	1-22
SMS.....	13-2
Creating/sending.....	13-7
Settings.....	17-14
Universal Settings.....	17-14
Snooze.....	12-7
SoftBank Utility Software.....	10-6
Softkeys.....	ix
Software Update.....	18-11
Sort (Messages).....	13-21
Spam Filter.....	13-17
Speaker ON/OFF.....	2-11
SSL.....	14-3
Still Images (Picture)	
Capturing.....	6-5
Editing.....	9-12
Streaming.....	14-12
Symbols.....	3-4
Symbol List.....	18-17

T

Tasks 12-6
 Templates (Graphic Mail)..... 13-5
 Text Entry [Section Contents] 3-1
 Time Correction 17-7
 Timer Lock at Close 11-6
 TLS 14-3
 Trimming (Editing Still Images) 9-12

U

URL History
 PC Site Browser 14-5
 Yahoo! Keitai 14-4
 USB 10-6
 User Mode 17-6
 User's Dictionary 3-10
 USIM Card 1-2
 USIM Card Phone Book 4-3
 USIM PINs 1-3

V

Vibrator
 Incoming alert 17-2
 S! Appli 17-17
 Videos (Recording) 6-6
 Videos folder 9-3
 View Blind 1-25
 Voice Announce 12-11
 Voice Dial 4-14
 Voice Mail 2-18
 Voice Recorder 12-11
 Volume
 Ringtone 17-2
 S! Appli 17-17
 Video Calls 2-7
 Voice Calls 2-5

W

Wallpaper 9-7, 17-3
 Warning Messages (PC Site Browser) ... 17-15
 Warranty 18-32
 Weather Indicator 7-5
 White balance
 Still Images 6-3, 6-8
 Videos 6-4, 6-8
 WMA Files 8-4
 World Clock 17-7

Y

Yahoo! Keitai 14-2
 Access 14-3
 Display Settings 17-15
 Memory Manager & Settings 17-15
 Security Settings 17-16

Z

Zoom 6-7

Warranty & Service

Warranty

Warranty is provided when you purchase a 842P.

- Check name of distributor and date of purchase.
- Read through contents and keep in a safe place.
- The warranty term is described in the warranty.

SoftBank is not liable for any damage resulting from use of this product.

After-Sales Service

See "Troubleshooting" (☞P.18-9) before contacting SoftBank for service or repairs. If you cannot find solutions or solve problems, contact SoftBank Mobile Customer Center, Customer Assistance (☞P.18-33) in your subscription area and provide a detailed description of the problem.

- Repairs within warranty are performed under terms and conditions described.
- Out of warranty, any repairs are performed upon request at subscriber's expense.

Customer Service

If you have questions about SoftBank handsets or services, please call General Information.

For repairs, please call Customer Assistance.

Check phone number before you dial.

SoftBank Mobile Customer Center

From a SoftBank handset, dial toll free at
**157 for General Information or
 113 for Customer Assistance**

SoftBank Mobile Global Call Center

From outside Japan, dial **+81-3-5351-3491**
 (Please take care to dial the correct number. International
 charges will apply to this call.)

Call these numbers toll free from landlines.

Subscription Area	Service Center	Toll Free Number
Hokkaido, Aomori, Akita, Iwate, Yamagata, Miyagi, Fukushima, Niigata, Tokyo, Kanagawa, Chiba, Saitama, Ibaraki, Tochigi, Gunma, Yamanashi, Nagano, Toyama, Ishikawa, Fukui	General Information	0088-240-157
	Customer Assistance	0088-240-113
Aichi, Gifu, Mie, Shizuoka	General Information	0088-241-157
	Customer Assistance	0088-241-113
Osaka, Hyogo, Kyoto, Nara, Shiga, Wakayama	General Information	0088-242-157
	Customer Assistance	0088-242-113
Hiroshima, Okayama, Yamaguchi, Tottori, Shimane, Tokushima, Kagawa, Ehime, Kochi, Fukuoka, Saga, Nagasaki, Oita, Kumamoto, Miyazaki, Kagoshima, Okinawa	General Information	0088-250-157
	Customer Assistance	0088-250-113

SoftBank 842P User Guide

May 2009, First Edition

SOFTBANK MOBILE Corp.

For additional information, please visit a SoftBank shop.

Model: SoftBank 842P

Manufacturer: Panasonic Mobile Communications Co., Ltd.



モバイル・リサイクル・ネットワーク
携帯電話・PHSのリサイクルにご協力を。

Please help the mobile industry maintain high environmental standards. Recycle your old handsets, batteries and charger units (all manufacturers and brands). Before you recycle, please remember these important points:

- Handsets, batteries and chargers submitted for recycling cannot be returned.
- Always erase all data recorded on old handsets (Phone Book entries, call records, mail, etc.) before recycling.

S0509-0