

BLUETOOTH

Bluetooth technology connectivity enables wireless connections between electronic devices. If connected with a Bluetooth Handsfree device, you can use your phone more freely. Since devices with Bluetooth connectivity communicate using radio waves, your phone and the other device do not need to be in direct line-of-sight. The two devices only need to be within 10 meters (30 feet) of each other. The connection can be subject to interference from obstructions such as walls or other electronic devices. This device is compliant with Bluetooth specification 2.0, supporting the following profiles: Headset, Handsfree, Stereo, Phonebook Access, and Object Push for vCard. To ensure interoperability between other devices supporting Bluetooth technology, use approved enhancements for this model. Check with the manufacturers of other devices to determine their compatibility with this phone. There may be restrictions on using Bluetooth technology in some locations. Check with your local authorities or service provider. If you want more information on this function, visit the Bluetooth Technology organization Web site: <https://www.bluetooth.org/>.

Important: Features using Bluetooth technology, or allowing such features to run in the background



while using other features, increase the demand on battery power and reduce the battery life.

BLUETOOTH ON/OFF

To toggle Bluetooth® power On/Off:

1. From idle mode, press the OK Key to unlock the keypad, press the Left Soft Key [] [MENU], swivel to the QWERTY keypad and press **9. Settings & Tools, 3. Bluetooth**.
2. Press the Left Soft Key [] [Turn On/Turn Off]. A confirmation window appears.

ADD NEW DEVICE

Pairing is the process that allows the handset to locate, establish and register a 1-to-1 connection with the target device.

1. From idle mode, press the OK Key to unlock the keypad, press the Left Soft Key [] [MENU], swivel to the QWERTY keypad and press **9. Settings & Tools, 3. Bluetooth, 1. Add New Device**.
2. If the Bluetooth® power is switched off, the following message will appear on the LCD screen: **“TURN BLUETOOTH POWER ON?”** Select **Yes** and press the OK Key.

3. The handset will prompt you with the following message on the LCD screen: “**PLACE DEVICE YOU ARE CONNECTING TO IN DISCOVERABLE MODE.**” Press the OK Key.
4. The device will appear in the **ADD NEW DEVICE** menu. Select the device you wish to pair to, then press the OK Key [**PAIR**].
5. The handset may prompt you for the passkey. Consult the Bluetooth® accessory (sold separately) instructions for the appropriate passkey (typically “0000”—4 zeroes). Enter the passkey, then press the OK Key.



You do not need to input the passkey for pairing when the passkey of the Bluetooth® Headset or hands-free kit is 0000.

6. The handset will prompt you with the following message on the LCD screen: **BEFORE CONNECTING** [Device Name]. If you would like to always confirm before connecting to the Bluetooth® device, select Always Ask, then press the OK Key. Then the handset will prompt you with the message **Connect to [Device Name]?** Select **Yes** and press the OK Key. If you do not wish to confirm every time before connecting to the Bluetooth® device, select Always Connect, then press the OK Key.
7. Once connected, you will see the device listed in

the Bluetooth menu and the Bluetooth® device connected icon will appear at the top of the screen when connected to the Bluetooth® device.



- In the **Bluetooth** menu, you can disconnect the connected device with an icon by pressing the OK Key [**Drop**]. Conversely, you can reconnect by pressing the OK Key again.
- When an audio device is connected, you can select another device and the connection is automatically transferred from that audio device to the other one.
- If multiple devices are displayed, select the device you want to connect to.

OPTIONS

1. From idle mode, press the OK Key to unlock the keypad, press the Left Soft Key [] [**MENU**], swivel to the QWERTY keypad and press **9. Settings & Tools, 3. Bluetooth.**
2. Select the paired device.
3. Press the Right Soft Key [] [**Options**].
4. Select one of the following options, then press the OK Key.
 - **Remove Device:** Removes a device from the pairing list.
 - **Rename Device:** Renames a paired device.
 - **Incoming Security:** Sets permissions for connecting an incoming device.
 - **Service Discovery:** To search for the services that the selected device supports.

- **Device Info:** Displays device information.
5. Or, press the OK Key to access **1. Send Name Card**, **2. Get Name Card** or **3. Send Picture**. Select the desired option and press the OK Key to access the following:
- **Send Name Card:** Send name cards stored in Contacts to a selected device.
 1. Press the Directional Key [] up or down to highlight a desired contact or contacts, then press the OK Key [MARK]. If you want to change your selections, press the OK Key [UNMARK] to deselect your selections.
 2. Press the Left Soft Key [] [Done]. If you want to send all the name cards, press the Right Soft Key [] [Send All].
 - **Get Name Card:** Get name cards from the selected device.
 - **Send Picture:** Send photos to a selected device.
 1. Press the Directional Key [] up, down, left or right to highlight a desired photo or photos, then press the OK Key [MARK]. If you want to change your selections, press the OK Key [UNMARK] to deselect your selections.
 2. Press the Left Soft Key [] [Done]. If you want to send all the photos, press the Right Soft Key [] [Send All].

SETTINGS

MY PHONE NAME

To edit the Bluetooth® name of your phone:

1. From idle mode, press the OK Key to unlock the keypad, press the Left Soft Key [] [MENU], swivel to the QWERTY keypad and press **9. Settings & Tools**,

3. Bluetooth.

2. Press the Right Soft Key [] [Options].
3. Press **1. My Phone Name**.
4. Use the numeric keypad to enter a new custom name.
5. Press the OK Key [SET] to save and exit.

DISCOVERY MODE

To set whether your device is able to be searched for by other Bluetooth® devices in the area:

1. From idle mode, press the OK Key to unlock the keypad, press the Left Soft Key [] [MENU], swivel to the QWERTY keypad and press **9. Settings & Tools**, **3. Bluetooth**.
2. Press the Right Soft Key [] [Options].
3. Press **2. Discovery Mode**.



If Bluetooth power is not on, it will be turned on automatically.

4. Select **On** or **Off**, then press the OK Key [SET].

SUPPORTED PROFILES

To view brief descriptions of the profiles supported by the phone:

1. From idle mode, press the OK Key to unlock the keypad, press the Left Soft Key [] [MENU], swivel to the QWERTY keypad and press **9. Settings & Tools**, **3. Bluetooth**.
2. Press the Right Soft Key [] [Options].
3. Press **3. Supported Profiles**.
4. Select one of the following profiles, and then press the OK Key [VIEW].
Headset / Handsfree / Stereo / Phonebook Access / Object Push

AUTO PAIR HANDSFREE

To set Auto Pair Handsfree On/Off:

1. From idle mode, press the OK Key to unlock the keypad, press the Left Soft Key [] [MENU], swivel to the QWERTY keypad and press **9. Settings & Tools**, **3. Bluetooth**.
2. Press the Right Soft Key [] [Options].
3. Press **4. Auto Pair Handsfree**.
4. Select **On** or **Off**, then press the OK Key [SET].