

ASSEMBLY INSTRUCTIONS







THE ORIGINAL

Sun Hut - 2x4 (#706800)




2 people recommended for assembly




4 plastic ties for securing floor liner
12 bolts & wing nuts to attach flange
4 straps to secure blower & filter

STEP 1




Separate numbered poles. Assemble top poles first. Insert two #1 poles into #1 3-way corner pole. The ball bearing locks when correctly connected. See diagram for connecting the poles.

STEP 4




Assemble bottom corner poles (#8) with bottom connector poles (#9) as shown (see diagram).

STEP 2




The 2 straight bars (#5) and 2 fan & blower bars (#7) should be spaced evenly on the upper frame to support the ceiling (see diagram).

STEP 5




Attach top half to the bottom half to complete the frame (see diagram).

STEP 3




Attach fan bracket into ceiling framing as shown. Tighten 4 screws (provided) into bracket (do not over-tighten).

STEP 6



Place canvas flat with bottom open on the floor. Unzip canvas completely. Face front of Sun Hut with fan & blower brackets in upper right. Place frame into bottom of canvas and pull canvas up around all four corners so that it fits tightly around bottom of frame (see diagram).

STEP 7



Pull canvas up the back and over the top of the frame. Carefully pull canvas around the 4 corners of the ceiling. Fits snug. Pull sides toward the front. (see diagram).

STEP 8






Figure A


Place inner waterproof floor liner into the floor of the Sun Hut. Insert plastic ties into the holes at the corners of the floor liner and secure to the corner poles (see Figure A). This will make the Sun Hut floor water-tight.



STEP 9




Slide flange into canvas and ring above fan & mounting rods. Push bolt through flange, canvas & ring; and tighten wing nuts on the outside. Attach intake flange on bottom left. Slide blower and filter straps onto brackets. Tighten straps around blower and filter. Use duct work (not included) to connect blower to flange.



STEP 10

Zip up doors to make sure that your Sun Hut fits properly.



OPTIONAL FLANGES

Optional flanges and optional two-way flanges are also available. For any questions or to see optional items for your Sun Hut, talk to your local dealer. Log on to www.n-g-w.com to locate a dealer near you.

FOR MORE INFORMATION VISIT
WWW.SUN-HUTS.COM