

How to change the location profile on an NG SIM

Blu Aria, Jenny, Samba, Zoey – menu>organizer(file folder image)>profiles>select location

Nokia – menu>profiles>select location

Standard Rental (Moto V180 flip phone) – Top most middle button on the phone enters you into the menu > Office tools (pencil and a clock image)>profiles(scroll down last option)>select location

Deluxe Rental – Samsung i5500 – Go into the “window” icon on the bottom middle of the home screen – flip through the icon options to find SIM Toolkit (it is its own icon with a SIM and a little gear) select location is inside

iPhone 4 – settings>phone>SIM applications>select location