



## Speed Stream 5200

### **Configurando como router PPPoE**

Para acessar configuração do modem, abra seu navegador e na barra de endereço digite: **192.168.254.254** e tecle Enter. **Se este IP não funcionar, use o IP 10.0.0.1 que é o padrão de configuração das operadoras.**



A tela seguinte tela será apresentada: User Name: admin e Password: admin



1 - Clique em "Setup", WAN Interface e em seguida clique em "ADD a New VC";

# SpeedStream Router Management Interface - Mozilla Firefox

Arquivo Editar Exibir Ir Bookmarks Ferramentas Ajuda

Back Forward Stop Home Address http://192.168.254.254/

Turbo Vip Clan Mod hardMOB



SpeedStream®

5200

Login

Setup 1º

PPP

User Profiles

WAN Interface 2º

Host

DHCP

Admin User

Time Client

Static Routes

NAT/NAPT

Port Forwarding

Firewall

UPnP

Bridge Mode

RIP

Server Ports

Dynamic DNS

## WAN Interface Configuration Wizard

### Current Configuration

#	VC	Type	Name	Actions
0	0/35	PPPoA	d4nk0	<a href="#">Disable</a> <a href="#">Delete</a> <input type="checkbox"/>
1				
2				
3				
4				
5				
6				
7				

\*Checked interface is the default WAN interface

Add a New VC 3º

Portal ADSL

2 - Preencha os exatamente como mostra a figura abaixo e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### ATM Settings

Enter the VPI and VCI numbers as specified by your service provider:

VPI:  VCI:

Select the Encapsulation Type:  LLC  
 VCMUX

Select the Traffic Class:

Enter the desired Traffic Description information: ( All Fields Optional )

Peak Tx Cell Rate


Sustained Tx Cell Rate

Tx Burst Tolerance

#	VC	Type	Name
0	0/32	PPPoE	PPPoE(00) 0/32

Portal ADSL

3 - Preencha os exatamente como mostra a figura abaixo e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### Protocol Selection

Select the Protocol:

- RFC-2684 Bridged
- RFC-2684 Bridged/IP
- RFC-2684 Routed
- PPPoE
- PPPoA

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Portal ADSL

Cancel

<< Back

Next >>

Finish

4 - Preencha os exatamente como mostra a figura abaixo e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### PPPoE Type

Select the PPPoE Configuration:

- Client only
- Bridge only
- with 2684B Connection
- with PPPoE Bridge

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Portal ADSL

[Cancel](#)

[« Back](#)

[Next >>](#)

[Finish](#)

5 - Preencha os exatamente como mostra a figura abaixo e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### PPPoE Session Count

Select the number of PPPoE sessions to configure:

- 1
- 2
- 3
- 4

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Portal ADSL

[Cancel](#)

[« Back](#)

[Next >>](#)

[Finish](#)

6 - Preencha os campos "Username" com login de seu provedor e "Password" cadastrado no seu provedor e em seguida clique em "Next";

**WAN Interface Configuration Wizard**

---

**User Information**

**Enter Login username and password:**

Username:  (Optional)

Password:  (Optional)

---

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Portal ADSL

**Cancel**   **<< Back**   **Next >>**   **Finish**

7 - Marque a opção "Auto-Connect on Disconnect" e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### PPP Options

Check the **PPP options** for this connection:

Dial-Up Mode (Only connect when user invokes connect)

Auto-Connect on Disconnect

Use Idle Timeout

Minutes

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Portal ADSL

[Cancel](#)

[<< Back](#)

[Next >>](#)

[Finish](#)

8 - Não preencher nada, apenas clique em "Next";

## WAN Interface Configuration Wizard

### PPP Static IP

Enter the optional **Static IP address** if desired:

( Optional )

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Portal ADSL

[Cancel](#)

[<< Back](#)

[Next >>](#)

[Finish](#)

9 - Não preencher nada, apenas clique em "Next";

## WAN Interface Configuration Wizard

### Interface Options

Select the following **Interface Options** for this connection:

- Use Firewall
- Use Attack Detection System
- Use Universal Plug-n-Play

RIP:  disabled  Version 1  Version 2  Versions 1&2

Active Mode

NAT/NAPT:

- disabled
- NAT: IP Address:
- NAPT
- NAT & NAPT: Public (WAN)   
IP Address:   
Private (LAN)   
IP Address:

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Porta ADSL

Cancel

<< Back

Next >>

Finish

10 - Digite o nome da sua Conexão Ex: "Brt" ou "Casa" e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### Connection Name

Enter a name to use for this connection:

Sua Conexão

#	VC	Type	Name
0	0/35	PPPoE	PPPoE(00) 0/35

Portal ADSL

Cancel

<< Back

Next >>

Finish

11 - Clicar em "Finish";

## WAN Interface Configuration Wizard

### VC Wizard

# Finished

#	VC	Type	Name
0	0/35	PPPoE	Sua Conexão

Portal ADSL

Cancel

Finish

12 - Clique em "Enable" para habilitar sua conexão e em seguida clique em "reboot";

## WAN Interface Configuration Wizard

### Current Configuration

#	VC	Type	Name	Actions
0	0/35	PPPoE	Sua Conexão	<button>Enable</button> <button>Delete</button>
1				
2				
3				
4				
5				
6				
7				

\*Checked interface is the default WAN interface

[Add a New VC](#)

Portal ADSL

A **reboot** is required before the new configuration takes effect

13 - Clique em "Reboot";

 **Your settings have been saved.**

The new settings will not take effect until the Gateway is rebooted. If you would like to reboot the Gateway now, press the **Reboot** button below.

[Reboot](#)

Portal ADSL

14 - Aguarde os 45 segundos da reinicialização do modem;

## System Reboot

Portal ADSL

The SpeedStream Gateway is now rebooting.

### NOTE:

*Please wait **43** seconds for your Gateway to refresh*

15 - Parabéns! sua Conexão está Ativa!

## System Summary

**System Type:** SpeedStream 5200-Series

**Config Part #:** 003-3081-G0E

**Firmware Part #:** 004-E270-A0N

**MAC Address:** 00:0B:23:31:76:67

Portal ADSL

## Point to Point Connection Summary:


 Sua Conexão

200.138.32.211


[Disconnect](#)

## **Configurando como router PPPoA**

Para acessar configuração do modem, abra seu navegador e na barra de endereço digite:  
192.168.254.254 e tecle Enter. **Se este IP não funcionar, use o IP 10.0.0.1 que é o padrão de configuração das operadoras.**



A tela seguinte será apresentada: User Name: admin e Password: admin



1 - Clique em "Setup", WAN Interface e em seguida clique em "ADD a New VC";

# SpeedStream Router Management Interface - Mozilla Firefox

Arquivo Editar Exibir Ir Bookmarks Ferramentas Ajuda

http://192.168.254.254/

Turbo Vip Clan Mod hardMOB



5200

SpeedStream®

## Login

## Setup 1º

PPP

User Profiles

## WAN Interface 2º

Host

DHCP

Admin User

Time Client

Static Routes

NAT/NAPT

Port Forwarding

Firewall

UPnP

Bridge Mode

RIP

Server Ports

Dynamic DNS

## WAN Interface Configuration Wizard

### Current Configuration

#	VC	Type	Name	Actions
0	0/35	PPPoA	d4nk0	<input type="button" value="Disable"/> <input type="button" value="Delete"/> <input type="checkbox"/>
1				
2				
3				
4				
5				
6				
7				

\*Checked interface is the default WAN interface

Add a New VC 3º

Portal ADSL

2 - Preencha os exatamente como mostra a figura abaixo e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### ATM Settings

Enter the VPI and VCI numbers as specified by your service provider:

VPI: 0      VCI: 35

Select the Encapsulation Type:  LLC  
 VCMUX

Select the Traffic Class: Unspecified Bit Rate

Enter the desired Traffic Description information: ( All Fields Optional )

Peak Tx Cell Rate  
Sustained Tx Cell Rate  
Tx Burst Tolerance


#	VC	Type	Name
1	0/32	PPPoE	PPPoE(10) 0/32

Portal ADSL

Cancel

Next >>

Finish

3 - Preencha os exatamente como mostra a figura abaixo e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### Protocol Selection

#### Select the Protocol:

- RFC-2684 Bridged
- RFC-2684 Bridged/IP
- RFC-2684 Routed
- PPPoE
- PPPoA

#	VC	Type	Name
1	0/35	PPPoE	PPPoE(10) 0/35

Portas ADSL

[Cancel](#)

[« Back](#)

[Next »](#)

[Finish](#)

4 - Preencha os campos "Username" com login de seu provedor e "Password" cadastrado no seu provedor e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### User Information

Enter Login **username and password**:

Username:  (Optional)

Password:  (Optional)

#	VC	Type	Name
1	0/35	PPPoA	PPPoA(1) 0/35

Portal ADSL

[Cancel](#)

[« Back](#)

[Next »](#)

[Finish](#)

5 - Marque a opção "Auto-Connect on Disconnect" e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### PPP Options

Check the **PPP options** for this connection:

Dial-Up Mode (Only connect when user invokes connect)

Auto-Connect on Disconnect

Use Idle Timeout

Minutes

#	VC	Type	Name
1	0/35	PPPoA	PPPoA(1) 0/35

Portal ADSL

[Cancel](#)

[« Back](#)

[Next »](#)

[Finish](#)

6 - Não preencher nada, apenas clique em "Next";

## WAN Interface Configuration Wizard

### PPP Static IP

Enter the optional **Static IP address** if desired:

( Optional )

#	VC	Type	Name
1	0/35	PPPoA	PPPoA(1) 0/35

Porta ADSL

[Cancel](#)

[« Back](#)

[Next »](#)

[Finish](#)

7 - Não preencher nada, apenas clique em "Next";

## WAN Interface Configuration Wizard

### Interface Options

Select the following **Interface Options** for this connection:

- Use Firewall
- Use Attack Detection System
- Use Universal Plug-n-Play

RIP:  disabled  Version 1  Version 2  Versions 1&2  
 Active Mode

NAT/NAPT:

- disabled
- NAT: IP Address:
- NAPT
- NAT & NAPT: Public (WAN)   
IP Address:   
Private (LAN)   
IP Address:

#	VC	Type	Name
1	0/35	PPPoA	PPPoA(1) 0/35

Portas ADSL

[Cancel](#)

[« Back](#)

[Next »](#)

[Finish](#)

8 - Digite o nome da sua Conexão Ex: "Brt" ou "Casa" e em seguida clique em "Next";

## WAN Interface Configuration Wizard

### Connection Name

Enter a name to use for this connection:

Sua Conexão

#	VC	Type	Name
1	0/35	PPPoA	PPPoA(1) 0/35

Portal ADSL

[Cancel](#)

[« Back](#)

[Next »](#)

[Finish](#)

9 - Clicar em "Finish";

## WAN Interface Configuration Wizard

### VC Wizard

# Finished

#	VC	Type	Name
1	0/35	PPPoA	Sua Conexão

Portal ADSL

[Cancel](#)

[Finish](#)

10 - Clique em "Enable" para habilitar sua conexão e em seguida clique em "reboot";

## WAN Interface Configuration Wizard

### Current Configuration

#	VC	Type	Name	Actions
0				
1	0/35	PPPoA	Sua Conexão	<a href="#">Enable</a> <a href="#">Delete</a>
2				
3				
4				
5				
6				
7				

\*Checked interface is the default WAN interface

[Add a New VC](#)



A **reboot** is required before the new configuration takes effect

11 - Clique em "Reboot";

**Your settings have been saved.**

The new settings will not take effect until the Gateway is rebooted. If you would like to reboot the Gateway now, press the **Reboot** button below.

[Reboot](#)



12 - Aguarde os 45 segundos da reinicialização do modem;

## System Reboot

Portal ADSL

The SpeedStream Gateway is now rebooting.

### NOTE:

*Please wait **43** seconds for your Gateway to refresh*

13 - Parabéns! sua Conexão está Ativa!

## System Summary

**System Type:** SpeedStream 5200-Series

**Config Part #:** 003-3081-G0E

**Firmware Part #:** 004-E270-A0N

**MAC Address:** 00:0B:23:31:76:67

## Point to Point Connection Summary:

 Sua Conexão

200.138.32.211

[Disconnect](#)



