KEYWALKER IDF 68 wireless mechanical keyboard Manual

Using manual and warranty card

Thanks very much for buying KEYWALKER mechanical keyboards.

Please read the manual before using it

Attention

After using keyboards for a long time. You hands, arms, neck, shoulders and waist will be uncomfortable. When you feel uncomfortable, tired, please stop using keyboard immediately and have a rest.

When you are not well, please don't use keyboard for a long time.

Feature

All "KEYWALKER" mechanical keyboards use original MX switch.

They have hard internal structure and good touch.

The common colors for MX switch are black, blue, brown, red.

Each keyboard use switches of only one color, Switches of different color have different function and touch. Please check before purchase.

Device parameters and using

Key quantity:68keys **Switch**: MX Switch **Keycaps**: Cherry keycaps

Keyboard specifications: wired control: Aint-ghosting NKRO/wireless control: Aint-ghosting 6KRO)

Keyboard dimension: 316mm*109mm*28mm

Keyboard weight: 722g **Cord length**: 1.5mm

Wireless device system and hardware requirement :

Hardware: Bluetooth V4.0 or above (built-in bluetooth v4.0 or bluetooth adapter v 4.0 or above), Support Device driver/Custom Operation

System requirement : Wired control:

Microsoft: windows XP above.

IOS: MAC OS. Linux system. Wireless control:

Microsoft: windows 8/windows 10.

IOS: IOS7.0 or above/MAC OS10 system above.

Android: Android 4.4 or above.

This device is with lithium polymer battery 1200mAh. Has USB interface for recharging 5.0V recharge Voltage, plug in and charge.

The wireless transmission distance is 15m if no obstacles ,when first connection with wireless device,it need input dynamic pairing code $_{\circ}$

Wireless Control

- 1. After switch in the keyboard.FN+Q/W/E(flash once every 3-5 seconds).the keyboard now is on pairing mode.then please turn on the Bluetooth function on you mobile phones/computer,or other Bluetooth devices.searching new bluetooth device.you will find KEYWALKER,clink KEYWALKER,your device will pop up one window to input.identifying code,please input the identifying code on KEYWALKER keyboard,and press "Enter"key, then the light of "Q/W/E" key keeps on on, which is means your bluetooth device and the keyboard are connected.
- 2. Press and hold 'FN"+Q/W/E key is to disconnect the present bluetooth device, it will enter into new pairing mode.
- 3. change between multiple devices:

At the same time open the phone and tablet PC Bluetooth, by pressing the FN+Q/W/E key.

4.Other function instruction

FN key function Fn+ESC		ALL for light
4.	FN+(1)	F1
5.	FN+(2)	F2
6.	FN+(3)	F3

FN+(4)	F4
FN+(5)	F5
FN+(6)	F6
FN+(7)	F7
FN+(8)	F8
FN+(9)	F9
FN+(10)	F10
FN+(-)	F11
FN+(+)	F12
FN+Q/W/E	Wireless connect
FN+(P)	Print
FN+([)	Home
FN+(])	End
FN+(~)	7 lighting effects change
FN+delete	Change recording light for Custom Operation
FN+pgup	Long press two seconds, into the recording state, the recording is completed and then press the FN+pgup once again to save the state of light.
FN+pgdn	Long press two seconds, into the recording state, the recording is completed and then press the FN+pgdn once again to save the state of light.
	FN+(5) FN+(6) FN+(7) FN+(8) FN+(9) FN+(10) FN+(-) FN+(+) FN+Q/W/E FN+(P) FN+([) FN+([) FN+(-) FN+delete FN+pgup

Note: This version provides timely updates of software programs can be directly updated online, refresh the new program, and will continue to update latter, please focus on Keywalker official website: www.keywalker.com