

Bluetooth® Device  
"For ages 12+"

# AFTERGLOW® COMMUNICATOR

For PlayStation® 3



AFTERGLOW®


For:  
PL-6360



Thank you for purchasing the Afterglow® Communicator for the PlayStation® 3 console. This illuminated wireless Bluetooth® headset lets you chat with and send voice messages to other gamers on your PlayStation® Network. To chat and send voice messages you need to be signed in to PlayStation® Network. This product can also be used with most mobile handsets.



**! WARNING:** Before using this product, read this manual as well as the PlayStation® 3 console manual for important safety and health information. Keep the manual for future reference.

1. Power/sync button
2. Mute button
3. Volume buttons
4. Microphone
5. Operation LEDs (ones on the front)
6. Charging port
7. Speaker
8. Ear clip



#### Charging Your Communicator:

Your Afterglow Communicator should have some charge already when you bought it but it's not 100% charged yet. You can charge your product via PS3 USB ports with the USB cable (provided) or with a USB AC adapter if you have one. It will take approximately 2 hours to fully charge your headset battery.



#### Low Battery Indicator:

Once you have about 10% battery power left, your Communicator will warn you visually and audibly. You will see the red LED blinking every 5 seconds. You will also hear a short beep tone every 8 seconds indicating that you're running low on battery.

#### Charging Indicator:

While charging you will see the red LED lighting up constantly. It will turn off once the headset battery is fully charged.

#### NOTE:

It is recommended, although not required, to fully charge your headset battery at least every 6 months to ensure the longevity of your battery life.

#### Operating Instructions:

Pairing is a form of handshake between Bluetooth® devices. You will need to pair your Afterglow Communicator with a Bluetooth® communication capable device prior to using it. Pairing process is simple. Just follow the below steps.

#### Pairing your headset with a PS3:

1. Power on your PS3 console
2. Under the "Settings" menu, select "Accessory Settings"
3. Find and select "Register Bluetooth Device" under Accessory settings
4. At the next screen, hold the power button of your Afterglow Communicator for 7 seconds until the red & blue Operation LEDs light up and flash alternately. This means your headset is looking for a device to pair
5. Back at the PS3 screen select "Start Scanning"
6. PS3 should automatically find and display your product name on screen as "Afterglow Communicator". Select it.

7. You'll be asked to enter the security code to authenticate the pairing headset. This code is "0000"
8. This completes the pairing process. You should see "Register complete" on your screen.
9. In some instances (such as if you already have an active device running) you might have to point to your PS3 which headset it should recognize as "active". You can do this at "Audio Device Settings" under the "Settings" menu.
10. A successfully paired Afterglow Communicator will have its Blue LED light flash every 4 seconds.

**NOTE:** There are only a limited number of Bluetooth® headsets your PS3 can keep in its memory. If you previously paired many headsets you may not be able to register this new headset prior to deleting one of the old ones. You can do this by going over to the inactive headset, pressing the triangle button and by selecting "delete".

#### Pairing your headset with a mobile phone:

1. Put your Afterglow Communicator in pairing mode as described above in #4
2. From your mobile phone settings menu, seek a Bluetooth® device in pairing mode. Once you see "Afterglow Communicator" name displayed, select it.
3. Enter the password which is "0000". Some mobile phones don't ask for this password but ask a question instead such as "Afterglow Communicator wants to pair; do you accept?" Just accept it.

**NOTE:** Your headset can remain in the pairing mode for 2 minutes. If within these 2 minutes you haven't successfully paired it with a PS3 or a mobile headset you need to put it back in the pairing mode again by pressing the power button for 7 seconds.

**Muting:** Your Afterglow Communicator has a dedicated mute button right next to the power button on its top surface. Press it once to mute the microphone. Press it once more to un-mute. While muted you can still hear the incoming audio.

#### TROUBLESHOOTING:

**I can't see the headset in device menu while pairing:** Your headset stays in pairing mode for 2 minutes. Make sure you set your PS3 or mobile phone to look for the pairing device within this 2 minutes.

Make sure you are in pairing mode by confirming you can see alternately flashing red & blue LED lights

**I can't see the red charging light:** Your battery might be completely drained. Allow it to charge for few minutes, then you should be seeing the red charging indication.

**I can't hear people:** Check your volume level, you might be very low. Increase the volume level by pressing "+" button.

Make sure you properly paired the headset and your blue LED is flashing every 4 seconds.

Make sure your headset is paired with the device you intend to use it with.

**People can't hear me:** Make sure you have not muted the headset. You can tell if it's muted by seeing the mute light constantly.

Make sure you're speaking clearly while the mic is pointing towards your mouth.

**Lost connection:** Your Afterglow Communicator has a range of 10 meters or approximately 30 feet. This distance may vary depending on the walls or other obstructions between the headset and the paired device. If you move out of range you will not hear incoming chat and nobody will hear you either. Stay within the communication range while you're operating this product.

If you walk out of range and re-enter, Afterglow Communicator should reconnect to the device it was last synced to but in case it doesn't go through the pairing process again.

Still having issues? Call the PDP support center at ... 1-800-331-3844 (USA ONLY)

**NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. MODIFICATIONS WILL VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.**

**CAUTION:** Changes or modifications to this equipment not expressly approved by the manufacturer could void the users authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: X5B-PL6360

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**\*please keep this information for future reference**



1840 East 27th Street  
Vernon, CA 90058 USA

59-60 Thames Street  
Windsor SL4 1TX, UK


For technical questions please visit  
[www.pdp.com](http://www.pdp.com) or call: 1-800-331-3844 (USA ONLY)

©2011 - Performance Designed Products LLC. PDP and PDP Gaming are trademarks, and AFTERGLOW is a registered trademark, of Performance Designed Products LLC. All Rights Reserved. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and are used by PDP under license. Playstation 3 and PS3 are registered trademarks of Sony Computer Entertainment, Inc. This product is not designed, manufactured, sponsored or endorsed by Sony.

Merci d'avoir acheté le communicateur Afterglow<sup>MD</sup> pour la console PlayStation<sup>MD</sup> 3. Cette oreillette lumineuse sans fil Bluetooth<sup>MD</sup> vous permet de bavarder et d'envoyer des messages vocaux à d'autres joueurs sur votre réseau PlayStation<sup>MD</sup>. Pour bavarder et envoyer des messages vocaux, vous devrez ouvrir une session sur le réseau PlayStation<sup>MD</sup>. Ce produit peut aussi être utilisé avec des téléphones mobiles.



**AVERTISSEMENT :** Avant d'utiliser ce produit, lisez ce manuel ainsi celui de la console PlayStation<sup>MD</sup> 3 pour des informations importantes sur la sécurité et la santé. Conservez le manuel pour référence ultérieure.

1. Bouton marche-arrêt/synchronisation
2. Bouton de mise en sourdine
3. Boutons du volume
4. Microphone
5. Témoins DEL de fonctionnement (sur le devant)
6. Port de charge
7. Haut-parleur
8. Crochet auriculaire



#### Charge du communicateur:

Votre communicateur Afterglow est déjà préchargé en partie quand vous l'achetez, toutefois il n'est pas chargé à 100 %. Vous pouvez le charger en utilisant les ports USB de la PS3 à l'aide du câble USB (fourni) ou d'un adaptateur USB c.a. si vous en avez un. Il faut environ 2 heures pour charger complètement la batterie de l'oreillette.



#### Témoin de batterie faible:

Lorsqu'il reste environ 10 % de charge de la batterie disponible, le communicateur vous avertit visuellement et par un bip. Le témoin DEL clignote toutes les 5 secondes. Vous entendrez également un bip court toutes les 8 secondes indiquant que la batterie est déchargée.

#### Témoin de charge:

Pendant la charge le témoin DEL rouge reste allumé en continu. Il s'éteint dès que la batterie de l'oreillette est complètement chargée.

#### REMARQUE :

Il est recommandé, sans que ce soit une obligation, de charger complètement la batterie de l'oreillette au moins tous les 6 mois, pour assurer la longévité de la durée de vie de la batterie.

#### Instructions de fonctionnement :

Le couplage est une sorte de liaison entre périphériques Bluetooth<sup>MD</sup>. Vous devrez coupler

vos périphériques Afterglow avec un périphérique de communication à technologie Bluetooth<sup>MD</sup> avant de pouvoir l'utiliser. Le couplage se fait de façon simple. Il suffit de suivre les étapes ci-après.

#### Couplage de l'oreillette avec une PS3 :

1. Mettez la console PS3 en marche.
2. Dans le menu « Settings » (Configuration), sélectionnez « Accessory Settings » (Configuration des accessoires).
3. Localisez et sélectionnez « Register Bluetooth Device » (Coupler un dispositif Bluetooth) dans le menu Accessory settings.
4. Dans l'écran suivant, appuyez et maintenez enfoncé le bouton marche-arrêt du communicateur Afterglow pendant 7 secondes jusqu'à ce que la DEL rouge et bleu de fonctionnement s'allume et clignote. Cela signifie que votre oreillette recherche un dispositif pour le couplage.
5. Sur l'écran de la PS3 sélectionner « Start Scanning » (Commencer la détection).
6. La PS3 doit automatiquement détecter et afficher le nom de votre produit : « Afterglow Communicator ». Le sélectionner.
7. Il vous sera demandé de saisir un code de sécurité pour authentifier l'oreillette en cours de couplage. Ce code est « 0000 ».
8. Le processus de couplage est terminé. Le message « Register complete » (Couplage terminé) s'affiche sur l'écran.
9. Dans certains cas (si vous avez déjà un périphérique actif en marche par exemple) il peut être nécessaire de pointer la PS3 vers l'oreillette qui doit être reconnue comme « active ». Cela peut être effectué dans le sous-menu « Audio Device Settings » (Configuration du périphérique audio) du menu « Configuration ».
10. Si le communicateur Afterglow a été couplé avec succès, le témoin DEL bleu clignote toutes les 4 secondes.

**REMARQUE :** Le nombre d'oreillettes Bluetooth<sup>MD</sup> que la PS3 peut enregistrer en mémoire est limité. Si plusieurs oreillettes ont déjà été couplées, il se peut que vous ne puissiez pas coupler cette nouvelle oreillette sans supprimer celles couplées antérieurement. Pour cela, il suffit d'aller sur l'oreillette inactive et d'appuyer sur le bouton du triangle et de sélectionner « delete » (Supprimer).

#### Couplage de l'oreillette avec un téléphone mobile :

1. Mettre le communicateur Afterglow en mode de couplage tel que décrit ci-dessus à l'étape 4.
2. Dans le menu de configuration du téléphone mobile, recherchez un dispositif Bluetooth<sup>MD</sup> en mode de couplage. Quand le nom de « Afterglow Communicator » s'affiche, le sélectionner.
3. Saisir le mot de passe « 0000 ». Certains téléphones mobiles ne requièrent pas de mot de passe, mais affichent un message du genre « Afterglow Communicator wants to pair; do you accept? » (Le communicateur Afterglow cherche à se coupler, acceptez-vous?) Il suffit d'accepter.

**REMARQUE :** L'oreillette peut rester en mode de couplage pendant 2 minutes. Si au cours de ces 2 minutes le couplage ne s'est pas effectué avec une PS3 ou un téléphone mobile, pour devrez recommencer le couplage en appuyant sur le bouton marche-arrêt pendant 7 secondes.

**Mise en sourdine:** ce communicateur Afterglow dispose d'un bouton de mise en sourdine spécifique juste à côté du bouton marche-arrêt sur le dessus. Il suffit de l'appuyer une fois pour mettre le microphone en sourdine. Appuyer une fois de plus sur ce bouton pour rétablir le son. Pendant la mise en sourdine du microphone, il est toujours possible d'écouter le son du haut-parleur.

#### PROBLÈMES ET SOLUTIONS :

##### Je ne vois pas l'oreillette dans le menu des périphériques pendant le couplage:

L'oreillette reste en mode de couplage pendant 2 minutes. Assurez-vous que la PS3 ou le téléphone mobile a été réglé dans les 2 minutes pour détecter un dispositif de couplage.

Vérifiez que vous êtes en mode de couplage en confirmant que les témoins DEL rouge et bleu clignotent bien en alternance

**Je ne vois pas la DEL de charge rouge:** Votre batterie est sans doute complètement déchargée. Laissez-la charger pendant quelques minutes, elle devrait alors s'allumer pour indiquer que la charge est en cours.

**Je n'entends pas les personnes qui m'appellent:** Vérifiez le niveau du volume, il est peut-être trop bas. Augmentez le niveau du volume en appuyant sur le bouton « + ».

Vérifiez que l'oreillette a été correctement couplée et que le témoin DEL clignote toutes les 4 secondes.

Vérifiez que l'oreillette est couplée avec le périphérique avec lequel vous voulez l'utiliser.

**Les personnes qui m'appellent ne m'entendent pas:** Vérifiez que l'oreillette n'est pas mise en sourdine. Lorsqu'elle est en sourdine, le témoin de mise en sourdine est allumé en continu.

Assurez-vous de parler clairement dans le microphone pointant vers votre bouche.

**Perte de connexion:** Votre communicateur Afterglow a une portée de 10 mètres, soit environ 30 pieds. Cette distance peut varier en fonction des murs ou d'autres obstructions entre l'oreillette et le périphérique couplé. Si vous vous déplacez hors de portée, vous ne pourrez pas entendre les conversations entrantes et personne ne pourra vous entendre. Restez dans la portée de communication pendant l'utilisation de ce produit.

Si vous vous trouvez hors de portée et que vous revenez à portée du périphérique, il est nécessaire