Tree Tunes

Bluetooth WIRELESS SPEAKER

SUPPORT:

If you are having problems with your product, please contact customer support before contacting your retailer.

support@lifemade.com

life made Limited Warranty Statement

life made warrants this product against defects in workmanship and material for a period of 12 months from the original date of purchase. If the product fails during normal and proper use within the warranty period, life made will requir or replace any products or parts determined to be defective in workmanship or material at its option. All components repaired or replaced by life made's service site will be under warranty for the remainine period of warranty.

This Limited Warranty covers only the accessory components packaged with this product. This Limited Warranty does not include failure caused by improper installation, one practine, cleaning or maintenance, accident, damage caused by extreme temperature, humidity, or extreme electrical stress, missue, abuse, numathorized modifications to this product, software failure, normal wear and tear or any other event, a.c., default, or omission outside of life made's control or if the serial number has been offended, altered or removed and the easier has been oneed.

IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

- THIS IS NOT A TOY. Not for use by children.
 - Do not keep in or near liquids.
- Please do not attempt to change or remove the lithium battery yourself.
 - Do not dispose of battery in fire.
- Do not leave battery in hot places such as an automobile under direct sunlight.
- Do not mix used and new batteries, or install used batteries in other equipment.
- Do not mix Alkaline, standard (Carbon-Zinc) or rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries.
 - Do not reverse the polarity (positive and negative terminals) of the battery.
 - Batteries should be recycled or disposed of as per state and local guidelines.

Bluetooth® is a registered trademark of Bluetooth® SIG Inc. The Bluetooth® word mark and logos are owned by the Bluetooth® SIG, Inc. and any use of such marks by life made LLC is under license. All other trademarks and trade names are those of their respective owners.

www.lifemade.com • 21 Englehard Dr, Monroe, NJ 08831

FCC Certification Requirements:

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may include undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed in accordance with the instructions, may cause harmful interference to radio communications. However, there is not guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- $\hbox{-} Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.\\$
- Consult the dealer or an experienced radio/ TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

How to charge the Tree Tunes:

- Insert the USB end of the microUSB cable into a computer or USB wall charger (not included).
- Insert the micro end of the microUSB cable into the port located on the back of the Tree Tunes.
- Fully charged in 2 hours.

- Turn on the Tree Tunes speaker by pressing and holding the Power Button for more than 3 seconds. Once turned on, a voice will sound, and say, "Bluetooth powered on," indicating the Tree Tunes is ready to pair.
- Then, go to the Bluetooth menu on your Bluetooth device.
- In the Bluetooth menu, select, "Ornament Speaker." Wait a moment, and the speaker will say, "Bluetooth Connected."
- You can now enjoy your music!
- To adjust the volume, select a track, play/ pause your music, you must use the controls located on your Bluetooth device.

Specifications:

- Power Supply: DC5V
- Rated Output Power: 3W
- Built-in lithium battery: 3.7V 450 mAh
- Battery charging time: about 2 hours
- Battery working time: > 3 hours
- Bluetooth version: JL2.1
- Working distance: about 10 feet
- Material: ABS housing

- Quick Start Guide (x1)
- MicroUSB Cable (x1)
- Hanging Hook (x1)
- Ribbon (x1)

Accessories:

Troubleshooting:

- If the device has no power, try recharging it.
- If the device has no sound, try adjusting the volume on your phone, tablet, etc. (and make sure they are in effective range).
- If the speaker is still not responding, try restarting the device.

Product functions & features:

- A voice will notify you when the speaker successfully pairs to your Bluetooth ${\bf @}$ device.
- The Tree Tunes supports hands free calling.
- Power Supply: built in 450 mAh lithium battery that can be charged in just 2 hours!
- Includes: microUSB charging cable