


# **Quick Start Guide**

**C630**

**Please Read Before Proceeding**

## I. PHONE COMPONENTS



- |                           |                           |
|---------------------------|---------------------------|
| 1. Data Line Interface    | 9. Menu                   |
| 2. Headset Socket         | 10. Home                  |
| 3. Receiver               | 11. Back                  |
| 4. Light Sensor           | 12. Microphone            |
| 5. Camera Lens (on front) | 13. Speaker               |
| 6. Volume Control key (+) | 14. Camera Lens (on back) |
| 7. Volume Control key (-) | 15. Flash                 |
| 8. Power Key              |                           |

## II. BOX CONTENT

The phone packaging box should contain following items and accessories:

Phone, Battery, Power Adapter, USB sync cable, Quick Start Guide, Headset.

## III. INSTALLING SIM CARD AND STORAGE CARD

Make sure to always turn off the power before installing or replacing the SIM card, storage card and battery. Also, remove the back cover before you can install the SIM card, storage card and battery.

### REMOVE THE BACK COVE

1. Make sure your device is turned off.
2. Carefully hold the device with the front panel facing down.

3. Hold the lower left quarter of the back cover up with your thumbs or fingers. Remove it from the opening.



#### **SIM CARD**

The SIM card includes your phone number, the service information, the phone book and the message storage.

##### **Install SIM Card**

1. Make sure your device is turned off.
2. Remove the back cover and battery.
3. With the SIM card's gold contacts facing down and its cut-off corner facing left, insert the SIM card into the SIM card slot.




##### **Remove SIM card**

1. Make sure your device is turned off.
2. Remove the back cover and battery.
3. Take out the SIM card.

##### **Insert Battery**

1. Align the battery's exposed copper contacts with the battery connectors inside the battery compartment.
2. Insert the contact's side of the battery first and then gently push the battery into place.
3. Replace the back cover.



#### Remove Battery

1. Make sure the phone is off.
2. Remove the back cover.
3. Remove the battery from the small opening on top side of the battery compartment.



#### Install MicroSD Card

1. Make sure your device is turned off.
2. Remove the back cover and battery.
3. With the MicroSD card's gold contacts facing down insert the card into the card slot.



#### IV. CHARGING THE BATTERY

The battery is partially charged when shipped. Before you turn on and start using your phone, it is recommended that you fully charge the battery. Some batteries perform best after several full charge/discharge cycles.

1. Connect the power adapter and the USB connector of your phone with the USB cable
2. Plug in the power adapter to an electrical outlet to start charging the battery.

**NOTICE:** When charging the battery with the phone on, the charging battery icon is displayed in phone's status bar. After the battery is fully charged, the charging battery icon turns a full battery icon.

#### **Optimization of battery power**

Use the following tips to improve your battery performance:

- ◆ Before first use charge your device 100%.
- ◆ Charge the device frequently.
- ◆ Disable all data connections over mobile network, if there is no internet access.
- ◆ Deactivate Bluetooth™ or WLAN if unnecessary.
- ◆ Extend the interval of the synchronization frequency (e.g. synchronization of e-mail, calendar and contacts).

#### **V. INTERNET CONNECTION**

Your device's networking capabilities allow you to access the Internet through WLAN, GPRS/3G/4G or EDGE.

##### **TO TURN WLAN ON AND CONNECT TO A WLAN NETWORK**

1. Tap home screen > settings > wireless & networks.
2. Tap the check box for WLAN to turn it on. Then your phone will detect available wireless networks.
3. Tap WLAN settings, and then detected WLAN networks will be listed.
4. Tap the WLAN network you want to connect to. If you selected an open (unsecured) network, you are automatically connected to the network. If you selected a secured network, enter the security key to connect to network.

**NOTICE:** Next time you use your device to detect WLAN networks, you will not be prompted to enter the network key of the previously accessed WLAN network (unless you perform a hard reset which will erase custom settings on your device).

WLAN networks are self-discoverable, which means no additional steps are required for your device to connect to a WLAN network. It may be necessary to provide a username and password for certain closed wireless networks.

##### **TO CHECK WIRELESS NETWORK STATUS**

You can check the current wireless connection status as follows:

###### **Status bar**

When your phone is connected to a wireless network, the WLAN icon will be displayed in the status bar along with the signal strength icon.

If the network notification is enabled within WLAN settings, the icon will be displayed in the status bar when your phone has automatically detected an available wireless network.

**WLAN**

1. Tap home screen > settings > wireless & networks.
2. Then tap the network to which you are currently connected.

**USING WEB BROWSER**

Start browser to surf the internet. The browser has been optimized for making your internet usage easy and enjoyable.

**NOTICE:** You can only access the internet with either 3G/4G, GPRS or WLAN connection.

**Opening the web browser**

Tap on home screen > Applications > Browser.

**Opening a webpage**

1. Enter an URL in the browser window.
2. As you type, automatically possible addresses will be displayed. You can tap an address to go directly to that webpage or continue typing in the address line.

**PLEASE READ BEFORE USE!**

**All misprints, mistakes and changes reserved.**

The battery is not charged when you take it out of the box. Do not remove the battery pack when the device is charging.

Your warranty is invalidated if you disassemble or change the device shell. (The warranty for this product is void by opening or disassembling the device's case).

**LEGAL INFORMATION ABOUT INTELLECTUAL PROPERTY**

All company, product and service names mentioned herein are trademarks, registered trademarks or service marks of their respective owners.

Shanghai Feixun Communication Co., Ltd. reserves the right to revise the content of this document at any time without prior notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or storing in a retrieval system, or translated into any language in any form without prior written permission of Shanghai Feixun Communication Co., Ltd.

**DISCLAIMER**

Any pre-installed software or data provided as a bundle to this device is subject to the applicable law under the responsibility of the issuing software/service provider. The hardware manufacturer cannot be held liable for any breach, malfunction or other occurrence raised by using this third-party software. Only the issuing providers can lawfully be held responsible. Shanghai Feixun Communication Co., Ltd. does not own the intellectual property of the third-party software and applications that are delivered with this product. Therefore, Shanghai Feixun Communication Co., Ltd. will not provide any warranty of any kind for these third-party software and applications. Neither will Shanghai Feixun Communication Co., Ltd. provide support to customers who use these third-party software and applications nor be responsible or liable for the functions of these third-party software and applications. Third-party software and applications services may be interrupted or terminated at any time. Shanghai Feixun Communication Co., Ltd. does not guarantee that any content or service would be maintained for any period during its availability. Third-party service providers provide content and services through network or transmission tools outside of the control of Shanghai Feixun Communication Co., Ltd. To the greatest extent permitted by applicable law, it is explicitly stated that

Shanghai Feixun Communication Co., Ltd. shall not compensate or be liable for services provided by third-party service providers or the interruption or termination of third-party contents or services.

Shanghai Feixun Communication Co., Ltd. shall not be responsible for the legality, quality or any other aspects of any software installed on this product, or for any uploaded or downloaded third-party works, such as texts, images, videos or software. Customers shall bear the risk for any and all effects including incompatibility between the software and this product, which result from installing software or uploading or downloading the third-party works.

This product uses the open-source Android platform. Shanghai Feixun Communication Co., Ltd. has made necessary changes to the platform. Therefore, this product may not support all the functions that are supported by the standard Android platform or may be incompatible with third-party software. Shanghai Feixun Communication Co., Ltd. shall not be liable for any of such situation.

#### **LIMITATION OF DAMAGES**

To the maximum extent permitted by applicable law, in no event shall Shanghai Feixun Communication Co., Ltd. be liable for any special incidental, indirect, or consequential damages or lost profits, business, revenue, data, goodwill or anticipated savings.

The maximum liability (this limitation shall not apply to liability for personal injury to the extent applicable law prohibits such a limitation) of Shanghai Feixun Communication Co., Ltd.

Arising from the use of the product described in this document shall be limited to the amount paid by customers for the purchase of this product.

#### **IMPORTANT HEALTH INFORMATION AND SAFETY PRECAUTIONS**

When using this product, the safety precautions below must be taken to avoid possible legal liabilities and damages.

Retain and follow all product safety and operating instructions.

Observe all warnings in the operating instructions on the product.

To reduce the risk of bodily injury, electric shock, fire, and damage to the equipment, observes the following precautions.

#### **SAFETY PRECAUTIONS FOR PROPER GROUNDING INSTALLATION**

**CAUTION:** Connecting to a weaker inappropriate charger can result in an electric shock to your device.



This product is equipped with a USB Cable for connecting with desktop or notebook computers. Be sure your computer is properly grounded (earthed) before connecting this product to the computer. The power supply cord of a desktop or notebook computer has an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet which is properly installed and grounded in accordance with all local codes and ordinances.

#### SAFETY PRECAUTIONS FOR POWER SUPPLY UNIT


##### Use the correct power source

This product can only be charged with matching battery, standard external power source or battery, external power source appointed by Shanghai Feixun Communication Co., Ltd.

Shanghai Feixun Communication Co., Ltd. is not liable for any device breakdown or safety accident arising from the use of unauthorized battery or external power source.

##### Handle Power Packs Carefully

The product contains a Li-ion battery. There is a risk of fire and burns if the battery pack is handled improperly. Do not attempt to open or service the battery pack. To reduce risk of fire or burns, do not disassemble, crush, puncture, short external contacts or circuits, or expose a battery pack to temperatures higher than 60°C (140°F), or pose of in fire.

 **WARNING:** There is danger of explosion if battery is incorrectly replaced. Replace only with specified batteries. Recycle or dispose of used batteries according to the local regulations or reference guide supplied with your product.



##### Instructions for battery disposal

1. If the battery of your product is marked with this symbol they are subject to the European Directive 2006/66/EC.
2. Batteries must always be separated from household waste and disposed according to applicable regulations.
3. By ensuring correct disposal of your old batteries harmful effects on humans, animals and the environment can be avoided.
4. For detailed information about disposal of used batteries, please contact your local office, waste disposal service or the shop where you purchased the product.

**Take extra precautions**

- ◆ Keep the battery or device dry and away from water or any liquid as it may cause a short circuit.
- ◆ Keep metal objects away so they don't come in contact with the battery or its connectors as it may lead to short circuit during operation.
- ◆ Do not use a battery that appears damaged, deformed, or discolored, or the one that has any rust on its casing, overheats, or emits a foul odor.
- ◆ Consult the doctor immediately if the battery is swallowed.
- ◆ If the battery leaks:
  - ◆ Do not allow the leaking fluid to come in contact with skin or clothing. If already in contact, flush the affected area immediately with clean water and seek medical advice.
  - ◆ Do not allow the leaking fluid to come in contact with eyes. If already in contact, DO NOT rub; rinse with clean water immediately and seek medical advice.
- ◆ Take extra precautions to keep a leaking battery away from fire as there is a danger of ignition or explosion.

**SAFETY PRECAUTIONS FOR DIRECT SUNLIGHT**

Keep this product away from excessive moisture and extreme temperatures. The device is designed to be operated in temperatures between 0°C and 33°C (32°F to 91.4°F). Low- or high- temperature conditions might temporarily shorten battery life or cause the device to temporarily stop working properly. Do not leave the product or its battery inside a vehicle or in places where the temperature may exceed 60°C (140°F), such as on a car dashboard, window sill, or behind a glass that is exposed to direct sunlight or strong ultraviolet light for extended periods of time. Avoid dramatic changes in temperature or humidity when using the device as condensation may form on or within the device.

When you are using the device or charging the battery, it is normal for device to get warm. The exterior of the device functions as a cooling surface that transfers heat from inside the unit to the cooler air outside.

**PREVENTION OF HEARING LOSS**

**To prevent possible hearing damage, do not listen at high volume levels for long periods.**



Permanent hearing loss may occur if the receiver, headphones, speakerphone, or earpieces are used at high volume. Use only

compatible receivers, headphones, speakerphones or earpieces with your device. Turn on the audio and check the volume before inserting anything in your ear. You can adapt over time to a higher volume of sound that may sound normal but can be damaging to your hearing. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. Hearing experts suggest that to protect your hearing:

- ◆ Limit the amount of time you use the receiver, headphones, speakerphone, or earpieces at high volume.
- ◆ Avoid turning up the volume to block out noisy surroundings.
- ◆ Turn the volume down if you can't hear people speaking near you.

#### **SAFETY IN AIRCRAFT**

Due to the possible interference caused by this product to an aircraft's navigation system and its communications network, using this device on board an airplane is against the law in most countries. Please comply with all regulations specified by airlines and turn off your phone or switch to Airplane Mode.

#### **ENVIRONMENT RESTRICTIONS**

Do not use this product in gas stations, fuel depots, chemical plants or where blasting operations are in progress, or in potentially explosive atmospheres such as below deck on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Please be aware that sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

#### **EXPLOSIVE ATMOSPHERES**

In any area with a potentially explosive atmosphere or where flammable materials exist, the product should be turned off and the user should obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised not to use the equipment at refueling areas such as service or gas stations, and are reminded of the need to observe restrictions on the use of radio equipment in fuel depots, chemical plants, or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. These include fueling areas, below deck on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as dust, or metal powders.

**ROAD SAFETY**

Vehicle drivers in motion are not permitted to use phone services with handheld devices, except in the case of emergency. In some countries, using hands-free devices as an alternative is allowed. Please inform yourself before driving about the legal requirements.

**SAFETY PRECAUTIONS FOR RF EXPOSURE**

- ◆ Avoid using your phone near metal structures (for example, the steel frame of a building).
- ◆ Avoid using your phone near strong electromagnetic sources, such as microwave ovens, sound speakers, TV and radio.
- ◆ Use only original manufacturer-approved accessories.
- ◆ Use of non-original manufacturer-approved accessories may violate your local RF exposure guidelines and should be avoided.

**INTERFERENCE WITH MEDICAL EQUIPMENT FUNCTIONS**

This product may cause medical equipment to malfunction. The use of this device is forbidden in most hospitals and medical clinics. If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so.

**HEARING AID DEVICES**

Some digital wireless phones may interfere with some hearing aid devices. In the event of such interference, you may want to consult your service provider, or call the customer service line to discuss alternatives.

**NON-IONIZING RADIATION**


It is recommended to keep it away from your body and head at least 15mm during operation.

Your device has an internal antenna. This product should be operated in its normal-use position to ensure the radiative performance and safety of the interference. As with other mobile radio transmitting equipment, users are advised that for satisfactory operation of the equipment and for the safety of personnel, it is recommended that no part of the human body be allowed to come too close to the antenna during operation of the equipment.

Use only the supplied integral antenna. Use of unauthorized or modified antennas may impair call quality and damage the phone, causing loss of performance and SAR levels exceeding the recommended limits as well as result in noncompliance with local

regulatory requirements in your country.

To assure optimal phone performance and ensure human exposure to RF energy is within the guidelines set forth in the relevant standards, always use your device only in its normal-use position. Contact with the antenna area may impair call quality and cause your device to operate at a higher power level than needed. Avoiding contact with the antenna area when the phone is IN USE optimizes the antenna performance and the battery life.



Position of Antenna

**GENERAL PRECAUTIONS**

**AVOID APPLYING EXCESSIVE PRESSURE TO THE DEVICE**

Do not apply excessive pressure on the screen and the device to prevent damaging them and causing cracked display of the touch screens. Do not put the device in your pants' pocket for a prolonged period of time.

**DEVICE GETTING WARM AFTER PROLONGED USE**

When using your device for prolonged periods of time, such as when you're talking on the phone, charging the battery or browsing the web, the device may become warm. In most cases, this condition is normal and therefore should not be interpreted as a problem with the device.

**HEED SERVICE MARKINGS**

Except as explained elsewhere in the Operating or Service documentation, do not repair any product yourself. Service needed on components inside the device should be done by an authorized service outlet or provider.

**DAMAGE REQUIRING SERVICE**

Unplug the product from the electrical outlet and refer servicing to an

authorized service center or provider under the following conditions:

- ◆ Liquid has been spilled or an object has fallen onto the product.
- ◆ The product has been exposed to rain or water.
- ◆ There are noticeable signs of overheating.
- ◆ The product does not operate normally when you follow the operating instructions.

**AVOID HOT AREAS**

The product should be placed away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

**AVOID WET AREAS**

Never use the product in a wet location.

**AVOID USING YOUR DEVICE AFTER A DRAMATIC CHANGE IN TEMPERATURE**

When you move your device between environments with very different temperature and/or humidity ranges, condensation may form on or within the device. To avoid damaging the device, allow sufficient time for the moisture to evaporate before using the device.

**NOTICE:** When taking the device from low-temperature conditions into a warmer environment or from high-temperature conditions into a cooler environment, allow the device to acclimate to room temperature before turning on power.

**AVOID PUSHING OBJECTS INTO PRODUCT**

Never push objects of any kind into cabinet slots or other openings in the product. Slots and openings are provided for ventilation. These openings must not be blocked or covered.

**MOUNTING ACCESSORIES**

Do not use the product on an unstable table, cart, stand, tripod, or bracket. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

**AVOID UNSTABLE MOUNTING**

Do not place the product with an unstable base.

**USE PRODUCT WITH APPROVED EQUIPMENT**

This product should be used only with personal computers and options identified as suitable for use with your equipment.

#### ADJUST THE VOLUME

Turn down the volume before using head-phones or other audio devices.

#### CLEANING

Unplug the product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning, but NEVER use water to clean the LCD screen.

The device has been provided with special treatments featuring that it could dispose dirt and sweat on its surface. The device itself does not have a stain-resistant function. In case of smudginess and dyeing, please wipe it with clean damp sponge immediately. Please keep the device dry when necessary.

#### PACEMAKERS



The device may cause disturbance to pacemakers. Please keep the device a proper distance of at least 5 centimeters away from pacemakers. In no case should the device be put in the front pocket of your shirt or coat.



If you need detailed information about other active implantable medical devices, please consult your doctor to ensure the magnetic interference of such active implantable medical devices.

#### ATTENTION

##### UPDATE YOUR OPERATING SYSTEM WITH CAUTION

- ◆ Improper operation or unpredictable external factors may cause operating system update is not successful; the device will not work properly. When such situation occurs, the device need to be returned for repair.
- ◆ Unofficial operating Software may cause security risks. Please only use official released Software Updates by Phicomm, otherwise the warranty and the right to claim under guarantee is invalid.

##### CAUTION:

- ◆ Users data will be erased during the update process, please backup data before it.
- ◆ Please make sure that battery charge above 30%.
- ◆ Do not unplug the battery or the MicroSD card during the update process.

**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement**

This device complies with FCC SAR exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution!**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.