

33052/**/16



Gebruiksaanwijzing

Notice d'emploi

Benutzerhandbuch


User manual

Manual de usuario




PHILIPS


Incl.






Excl.





Type 1 ➔ P4




Type 2 ➔ P8








Type 1





②
















Type 2






①











Philips Lighting Contact Centre
Int. Business Reply Service
I.B.R.S. / C.C.R.I. Numéro 10461
5600 VB Eindhoven
Pays-Bas / The Netherlands

www.philips.com/homelighting
☎ +800 7445 4775

4404.016.96391
Last update: 20/03/14