

Audio Systems, cont.

PIONEER.....	0689 0388 0288	0388 0489 0299	RADIO SHACK.....	0272 0077 0980	0282 0188 0288 0388	0488 0189 0489 0589	RCA.....	0373 0274 0878 0779 0181	0384 0186 0288 0388 0688 0788	0888 0189 0489 0589 0546 0683	REALISTIC.....	0883	RIO.....	0142 0380	SABA.....	0593	SAMSUNG.....	0047	SANYO.....	0072	SCOTT.....	0478	SHARP.....	0768 0070 0582	SHERWOOD.....	0272 0282 0487 0587	SIBURS.....	0276 0070	SKYFI.....	0187	SONY.....	0976 0933 0479 0579	0980 0381 0481 0581 0984	0985 0185 0285 0985 0200	TAD.....	0174	TEAC.....	0672 0382 0187 0287 0387	TECHNICS.....	0780 0682 0183	0983 0987 0088	TEVION.....	0446	VENTURER.....	0176	WMRADIO.....	0877	XMRADIO.....	0472 0174	YAMAHA.....	0781 0881 0488 0685	0785 0286 0386 0486 0588 0785	ZENITH.....	0269 0674 0576 0577 0178	0278 0880 0883 0380 0686 0142																																																																																																				
GE.....	0556	GEMINI.....	0255 0549	GENERAL INSTRUMENT (G).....	0552	VISIONETICS.....	0951 0548 0748	PANASONIC.....	0264 0260 0261	PANSAT.....	1105 0060 1406	PHILIPS.....	0755 0259 0862 0763	PHILIPS-MAGNAVOX.....	0259	PROSAT.....	0957	PROSCAN.....	1804 0265 0365	REALISTIC.....	0961 0358	SAMSUNG.....	0061 0939 0062	SHARP.....	0757	SIBURAH III.....	0757	SKY NETWORK.....	0855 0755 0063	SONY.....	0613 0266 0355 0485 0555	SONY.....	0963 0367 0567 0160 0661	STARLIGHT.....	0964	STARTRAK.....	0587 0362 0585 0355 0455 0555	STARTRAC.....	0665 0166 0364	SIS.....	0458 0658 0758	SEG GUIDE.....	0562	SYLVANIA.....	0759	TELSAT.....	0756	THOMSON.....	0355	TOSHIBA.....	0765 0864 0465 0564	TOSHIBA.....	0664 0362 0858 0064 0164 0764	TV.....	0756	ULTIMATE TV.....	0966 0567	UNIDEN.....	0964 0938 0762	UNITED.....	0361	DIGITREX.....	0146	DIGIX.....	0095	DISNEY.....	0447	DRIVE.....	1011	DUAL.....	0346 0080 0297	ESACENT.....	1842	FARHENHEIT.....	0697	FISHER.....	0443 0041 0041	GENIUM.....	0161	GEMINI.....	0511	GLOBECAST.....	0956 1306	GO VIDEO.....	0362	HITACHI.....	0465 0564 0664	HUGHES NETWORK.....	0049	IBM.....	0864 (A) 0465 (B) 0564 (C) 0644 (D)	KENWOOD.....	0461	LG.....	0362 0964 0765	LUCOR.....	0561	MACOM.....	0350	MAGNAVOX.....	0259 0962 0565	MICROVAL.....	1977	MITSUBISHI.....	0765 0864 0465	MOTOROLA.....	0266 0466 0463	NEOSAT.....	1777	NET.....	0456 0262																																												
AXION.....	0793	HARMAN KARDON.....	0344	HD-DVD.....	1941 1541 1441 1341	BLAUPUNKT.....	0499	BLUESKY.....	0143 0146 1114	BLU-RAY.....	1742 1941 1541 1441	HUMAX.....	0892	BODYSONIC.....	0343	BOSE.....	0868	INFINITY.....	0597 1608 1912	INITIAL.....	0644 1608 1110 1512	INSIGNIA.....	1741 1608 1208	PROSCAN.....	0542 0690	JVC.....	0441 0242 0442 0908	REGENT.....	0794 1210	REOC.....	0444	KJH.....	0644 0292 0240	RO.....	0142	KAWASAKI.....	0196 0546	KEENWOOD.....	0641 0544	KISS.....	1908	KLH.....	0644 0292 0240	KONKA.....	0642 0742 0842 0942 0192	RO TECHNOLOGY.....	1209 1311	KOSS.....	0146 0494 0091 1710	KOSK.....	0143 0440	KND.....	0091	LASONIC.....	1642 0746 0496	LENNOX.....	0794 0145 1310 1140	LG.....	1042 1641 0142 0898 0392	LINN.....	0945	LIQUIDVIDEO.....	0793	LITEON.....	0899 0891 0491 0597 1508	LITEON.....	0899 0891 0491 0597 1508	MARANTZ.....	0441 0142	SEARS.....	0041 0247	SEG.....	0444	SENSORY SCIENCE.....	0891	SEMP.....	1609 1709 1809 1909	SHARP.....	1941 0341 0391 0952	SHERWOOD.....	0144	SHINCO.....	0644	SHINSONIC.....	0644	SONIC BLUE.....	0395	SONY.....	0542 1612	SONY.....	0500 0541 0200 0540	PINNACLE.....	1605 1705 1805	PIONEER.....	0428 0309 0252	SANYO.....	0428 0309 0252	ROYAL.....	1973	SMARTPARTS.....	1075 1773	ZENITH.....	0934	MEMOREX.....	1606 1413 1913	MERIDIAN.....	0441	MICROSOFT.....	0542 1612	MUSTEK.....	0744	MYRON & DAVIS.....	0897	NAD.....	1142 0142 0944	NAKAMICHI.....	0844	NEC.....	0142	NEC.....	0142	NEC.....	0142	NESA.....	0644 0897	NEXXTech.....	1741 1208 0896 0897	SYMPHONIC.....	0247 0447 0591	TASCAM.....	0192	TECHNICS.....	0942 0546 0142	TECHNICS.....	0942 0546 0142	TECHWOOD.....	0944 1708 0442	TIME WARNER.....	0252	TIVO.....	0738 0838 0036 0136	TOSHIBA.....	0597 0999 0802 0592	HUMAX.....	0892	TRITEX.....	1906 0798 1713	UNITED.....	0546	GREENHILL.....	0644	HAZZ.....	0746 0848	WESTINGHOUSE.....	0360
PHILIPS-MAGNAVOX.....	0441 0442	WHARFEDALE.....	0845 0343	B & K.....	0499	BLAUPUNKT.....	0499	BLUESKY.....	0143 0146 1114	BLU-RAY.....	1742 1941 1541 1441	HUMAX.....	0892	BODYSONIC.....	0343	BOSE.....	0868	INFINITY.....	0597 1608 1912	INITIAL.....	0644 1608 1110 1512	INSIGNIA.....	1741 1608 1208	PROSCAN.....	0542 0690	JVC.....	0441 0242 0442 0908	REGENT.....	0794 1210	REOC.....	0444	KJH.....	0644 0292 0240	RO.....	0142	KAWASAKI.....	0196 0546	KEENWOOD.....	0641 0544	KISS.....	1908	KLH.....	0644 0292 0240	KONKA.....	0642 0742 0842 0942 0192	RO TECHNOLOGY.....	1209 1311	KOSS.....	0146 0494 0091 1710	KOSK.....	0143 0440	KND.....	0091	LASONIC.....	1642 0746 0496	LENNOX.....	0794 0145 1310 1140	LG.....	1042 1641 0142 0898 0392	LINN.....	0945	LIQUIDVIDEO.....	0793	LITEON.....	0899 0891 0491 0597 1508	LITEON.....	0899 0891 0491 0597 1508	MARANTZ.....	0441 0142	SEARS.....	0041 0247	SEG.....	0444	SENSORY SCIENCE.....	0891	SEMP.....	1609 1709 1809 1909	SHARP.....	1941 0341 0391 0952	SHERWOOD.....	0144	SHINCO.....	0644	SHINSONIC.....	0644	SONIC BLUE.....	0395	SONY.....	0542 1612	SONY.....	0500 0541 0200 0540	PINNACLE.....	1605 1705 1805	PIONEER.....	0428 0309 0252	SANYO.....	0428 0309 0252	ROYAL.....	1973	SMARTPARTS.....	1075 1773	ZENITH.....	0934	MEMOREX.....	1606 1413 1913	MERIDIAN.....	0441	MICROSOFT.....	0542 1612	MUSTEK.....	0744	MYRON & DAVIS.....	0897	NAD.....	1142 0142 0944	NAKAMICHI.....	0844	NEC.....	0142	NEC.....	0142	NESA.....	0644 0897	NEXXTech.....	1741 1208 0896 0897	SYMPHONIC.....	0247 0447 0591	TASCAM.....	0192	TECHNICS.....	0942 0546 0142	TECHNICS.....	0942 0546 0142	TECHWOOD.....	0944 1708 0442	TIME WARNER.....	0252	TIVO.....	0738 0838 0036 0136	TOSHIBA.....	0597 0999 0802 0592	HUMAX.....	0892	TRITEX.....	1906 0798 1713	UNITED.....	0546	GREENHILL.....	0644	HAZZ.....	0746 0848	WESTINGHOUSE.....	0360		

Cable

ABC.....	0747 0947 0048 0148 0248	ADELPHIA.....	0852 0752	ALLEGRO.....	0054 0154	AMERICAST.....	0354	ANTRONIX.....	0448 0548	ARCHER.....	0448 0548 0648 0748	AT&T.....	1976 0752	BELL.....	1177	BELL SOUTH.....	0354	CABLETENNA.....	0448	CABLEVIEW.....	0448	CABLEVISION.....	0252	CENTURY.....	0748	CHARTER.....	0852 0554	CITIZEN.....	0748	CLEARMAX.....	0847	COGECO.....	0752	COLOR VOICE.....	0848 0948	COMCAST.....	0954	CONTRONICS.....	0049 0149	CONTEC.....	0249	COX.....	0554	DIGITAL MUSIC EXPRESS.....	0053	DIRECTOR.....	0752	EASTERN.....	0349	EVERQUEST.....	0049	GAERARD.....	0748	VERIZON.....	0252 0554	VIDEO TECH.....	0656	VIDEOTRON.....	0252																																																																																														
GE.....	0556	VIEWEWAY.....	0052	VIEWSTAR.....	0149 0150 0350 0651	VISIONETICS.....	0951 0548 0748	PANASONIC.....	0264 0260 0261	PANSAT.....	1105 0060 1406	PHILIPS.....	0755 0259 0862 0763	PHILIPS-MAGNAVOX.....	0259	PROSAT.....	0957	PROSCAN.....	1804 0265 0365	REALISTIC.....	0961 0358	SAMSUNG.....	0061 0939 0062	SHARP.....	0757	SIBURAH III.....	0757	SKY NETWORK.....	0855 0755 0063	SONY.....	0613 0266 0355 0485 0555	SONY.....	0963 0367 0567 0160 0661	STARLIGHT.....	0964	STARTRAK.....	0587 0362 0585 0355 0455 0555	STARTRAC.....	0665 0166 0364	SIS.....	0458 0658 0758	SEG GUIDE.....	0562	SYLVANIA.....	0759	TELSAT.....	0756	THOMSON.....	0355	TOSHIBA.....	0765 0864 0465 0564	TOSHIBA.....	0664 0362 0858 0064 0164 0764	TV.....	0756	ULTIMATE TV.....	0966 0567	UNIDEN.....	0964 0938 0762	UNITED.....	0361	DIGITREX.....	0146	DIGIX.....	0095	DISNEY.....	0447	DRIVE.....	1011	DUAL.....	0346 0080 0297	ESACENT.....	1842	FARHENHEIT.....	0697	FISHER.....	0443 0041 0041	GENIUM.....	0161	GEMINI.....	0511	GLOBECAST.....	0956 1306	GO VIDEO.....	0362	HITACHI.....	0465 0564 0664	HUGHES NETWORK.....	0049	IBM.....	0864 (A) 0465 (B) 0564 (C) 0644 (D)	KENWOOD.....	0461	LG.....	0362 0964 0765	LUCOR.....	0561	MACOM.....	0350	MAGNAVOX.....	0259 0962 0565	MICROVAL.....	1977	MITSUBISHI.....	0765 0864 0465	MOTOROLA.....	0266 0466 0463	NEOSAT.....	1777	NET.....	0456 0262																																										
AXION.....	0793	HARMAN KARDON.....	0344	HD-DVD.....	1941 1541 1441 1341	BLAUPUNKT.....	0499	BLUESKY.....	0143 0146 1114	BLU-RAY.....	1742 1941 1541 1441	HUMAX.....	0892	BODYSONIC.....	0343	BOSE.....	0868	INFINITY.....	0597 1608 1912	INITIAL.....	0644 1608 1110 1512	INSIGNIA.....	1741 1608 1208	PROSCAN.....	0542 0690	JVC.....	0441 0242 0442 0908	REGENT.....	0794 1210	REOC.....	0444	KJH.....	0644 0292 0240	RO.....	0142	KAWASAKI.....	0196 0546	KEENWOOD.....	0641 0544	KISS.....	1908	KLH.....	0644 0292 0240	KONKA.....	0642 0742 0842 0942 0192	RO TECHNOLOGY.....	1209 1311	KOSS.....	0146 0494 0091 1710	KOSK.....	0143 0440	KND.....	0091	LASONIC.....	1642 0746 0496	LENNOX.....	0794 0145 1310 1140	LG.....	1042 1641 0142 0898 0392	LINN.....	0945	LIQUIDVIDEO.....	0793	LITEON.....	0899 0891 0491 0597 1508	LITEON.....	0899 0891 0491 0597 1508	MARANTZ.....	0441 0142	SEARS.....	0041 0247	SEG.....	0444	SENSORY SCIENCE.....	0891	SEMP.....	1609 1709 1809 1909	SHARP.....	1941 0341 0391 0952	SHERWOOD.....	0144	SHINCO.....	0644	SHINSONIC.....	0644	SONIC BLUE.....	0395	SONY.....	0542 1612	SONY.....	0500 0541 0200 0540	PINNACLE.....	1605 1705 1805	PIONEER.....	0428 0309 0252	SANYO.....	0428 0309 0252	ROYAL.....	1973	SMARTPARTS.....	1075 1773	ZENITH.....	0934	MEMOREX.....	1606 1413 1913	MERIDIAN.....	0441	MICROSOFT.....	0542 1612	MUSTEK.....	0744	MYRON & DAVIS.....	0897	NAD.....	1142 0142 0944	NAKAMICHI.....	0844	NEC.....	0142	NEC.....	0142	NESA.....	0644 0897	NEXXTech.....	1741 1208 0896 0897	SYMPHONIC.....	0247 0447 0591	TASCAM.....	0192	TECHNICS.....	0942 0546 0142	TECHNICS.....	0942 0546 0142	TECHWOOD.....	0944 1708 0442	TIME WARNER.....	0252	TIVO.....	0738 0838 0036 0136	TOSHIBA.....	0597 0999 0802 0592	HUMAX.....	0892	TRITEX.....	1906 0798 1713	UNITED.....	0546	GREENHILL.....	0644	HAZZ.....	0746 0848	WESTINGHOUSE.....	0360
PHILIPS-MAGNAVOX.....	0441 0442	WHARFEDALE.....	0845 0343	B & K.....	0499	BLAUPUNKT.....	0499	BLUESKY.....	0143 0146 1114	BLU-RAY.....	1742 1941 1541 1441	HUMAX.....	0892	BODYSONIC.....	0343	BOSE.....	0868	INFINITY.....	0597 1608 1912	INITIAL.....	0644 1608 1110 1512	INSIGNIA.....	1741 1608 1208	PROSCAN.....	0542 0690	JVC.....	0441 0242 0442 0908	REGENT.....	0794 1210	REOC.....	0444	KJH.....	0644 0292 0240	RO.....	0142	KAWASAKI.....	0196 0546	KEENWOOD.....	0641 0544	KISS.....	1908	KLH.....	0644 0292 0240	KONKA.....	0642 0742 0842 0942 0192	RO TECHNOLOGY.....	1209 1311	KOSS.....	0146 0494 0091 1710	KOSK.....	0143 0440	KND.....	0091	LASONIC.....	1642 0746 0496	LENNOX.....	0794 0145 1310 1140	LG.....	1042 1641 0142 0898 0392	LINN.....	0945	LIQUIDVIDEO.....	0793	LITEON.....	0899 0891 0491 0597 1508	LITEON.....	0899 0891 0491 0597 1508	MARANTZ.....	0441 0142	SEARS.....	0041 0247	SEG.....	0444	SENSORY SCIENCE.....	0891	SEMP.....	1609 1709 1809 1909	SHARP.....	1941 0341 0391 0952	SHERWOOD.....	0144	SHINCO.....	0644	SHINSONIC.....	0644	SONIC BLUE.....	0395	SONY.....	0542 1612	SONY.....	0500 0541 0200 0540	PINNACLE.....	1605 1705 1805	PIONEER.....	0428 0309 0252	SANYO.....	0428 0309 0252	ROYAL.....	1973	SMARTPARTS.....	1075 1773	ZENITH.....	0934	MEMOREX.....	1606 1413 1913	MERIDIAN.....	0441	MICROSOFT.....	0542 1612	MUSTEK.....	0744	MYRON & DAVIS.....	0897	NAD.....	1142 0142 0944	NAKAMICHI.....	0844	NEC.....	0142	NEC.....	0142	NESA.....	0644 0897	NEXXTech.....	1741 1208 0896 0897	SYMPHONIC.....	0247 0447 0591	TASCAM.....	0192	TECHNICS.....	0942 0546 0142	TECHNICS.....	0942 0546 0142	TECHWOOD.....	0944 1708 0442	TIME WARNER.....	0252	TIVO.....	0738 0838 0036 0136	TOSHIBA.....	0597 0999 0802 0592	HUMAX.....	0892	TRITEX.....	1906 0798 1713	UNITED.....	0546	GREENHILL.....	0644	HAZZ.....	0746 0848	WESTINGHOUSE.....	0360

Use codes (A) (B) etc. if you have 2 or more of the same device.

AXION.....	0793	HARMAN KARDON.....	0344	HD-DVD.....	1941 1541 1441 1341	BLAUPUNKT.....	0499	BLUESKY.....	0143 0146 1114	BLU-RAY.....	1742 1941 1541 1441	HUMAX.....	0892	BODYSONIC.....	0343	BOSE.....	0868	INFINITY.....	0597 1608 1912	INITIAL.....	0644 1608 1110 1512	INSIGNIA.....	1741 1608 1208	PROSCAN.....	0542 0690	JVC.....	0441 0242 0442 0908	REGENT.....	0794 1210	REOC.....	0444	KJH.....	0644 0292 0240	RO.....	0142	KAWASAKI.....	0196 0546	KEENWOOD.....	0641 0544	KISS.....	1908	KLH.....	0644 0292 0240	KONKA.....	0642 0742 0842 0942 0192	RO TECHNOLOGY.....	1209 1311	KOSS.....	0146 0494 0091 1710	KOSK.....	0143 0440	KND.....	0091	LASONIC.....	1642
------------	------	--------------------	------	-------------	---------------------	----------------	------	--------------	----------------	--------------	---------------------	------------	------	----------------	------	-----------	------	---------------	----------------	--------------	---------------------	---------------	----------------	--------------	-----------	----------	---------------------	-------------	-----------	-----------	------	----------	----------------	---------	------	---------------	-----------	---------------	-----------	-----------	------	----------	----------------	------------	--------------------------	--------------------	-----------	-----------	---------------------	-----------	-----------	----------	------	--------------	------