

MINI RADIO CONTROL – CARS & MOTOR CYCLES

START UP

1. Press the release button and **REMOVE** the clear **DOME** cover.
2. **CAREFULLY LIFT OFF** the **PLASTIC** blister **SECURING THE CHARGING UNIT** and **ANTENNA**, AND **REMOVE BOTH**. **CAREFULLY** unscrew AND **REMOVE** the vehicle from the **PLASTIC** blister.
3. Secure / **THREAD** the antenna **IN THE ANTENNA HOLE LOCATED ON THE CONTROLLER**
4. Unscrew and **REMOVE** the battery **COVERS** on both the controller and **THE** charging unit. **INSERT** 3 “AAA” batteries (not included) into charger unit and 3 “AA” batteries (not included) into controller of the battery compartments. Then **REPLACE** the battery **COVERS** and tighten the screws.

CHARGING THE VEHICLE

1. Place the vehicle on **TOP OF** the charging unit **HOLDER**, **GENTLY BUT FIRMLY PUSH THE VEHICLE INTO POSITION ON THE HOLDER**.
2. Press the charging button and the charging LED indicator will turn on **INDICATING THE VEHICLE IS CHARGING**. The LED indicator will turn off when the vehicle is fully charged (approx. 45 seconds).

PLEASE NOTE: a). If the batteries inside the controller are low, the LED light will become dim or **NOT LIGHT UP AT ALL, AND YOU WILL NOT BE ABLE TO CHARGE THE VEHICLE. PLEASE REPLACE THE BATTERIES.**
b). Make sure the **BATTERIES HAVE BEEN INSERTED CORRECTLY (+ OR -)** then preparing **TO CHARGE THE VEHICLE**.
c). Rechargeable batteries may get hot and dangerous if being continuously recharged.

OPERATING THE VEHICLE:

- 1). Fully extend the **CONTROLLER ANTENNA**.
- 2). Press the forward and reverse buttons to make the vehicle move **FORWARDS AND BACKWARDS. FOR LEFT AND RIGHT TURNING**, press the left and right buttons respectively. **PLEASE NOTE**, the vehicle will turn only when it is moving forwards or backwards. **ALSO NOTE**, the operation light will turn on when the vehicle is in use.
- 3). Adjust the fine tune **STEERING LEVER** located under the vehicle to keep it moving straight.

PLEASE NOTE: a) When operating the controller, please do not touch the antenna. As control distance and the speed will both be **AFFECTED**.

b). If **YOU NOTICE A REDUCTION IN SPEED AND CONTROL, PLEASE BEGIN RE-CHARGING PER THE INSTRUCTIONS ABOVE.**

{Rosie, this is also recommended to add the following Warning on the manual.}

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- **Reorient or relocate the receiving antenna**
- **Increase the separation between the equipment and receiver**
- **Connect the equipment into an outlet on a circuit different from that to which the receiver is needed**
- **Consult the dealer or an experienced radio/TV technician for help**

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and**
- (2) this device must accept any interference, including interference that may cause undesired operation of the device**