Customize your headset so it tits comfortably. mobile phone user guide for more details. call. Refer to Section 5, FIG. 5.2 and your Test the headset to phone pairing by making a

CHECK THE CONNECTION

repeat the pairing process. Refer to your mobile phone user guide and

headset will return to standay without sounding will stop flashing after 60 seconds and your NOTE - If pairing fails, the INDICATOR light pairing succeeded and follow any instructions. Check your mobile phone display to see if a tone and the INDICATOR light will turn off. If pairing is successful, the headset will sound

CONFIRM PAIRING

will not require a passkey powe wopile byones and portable devices qidit passkey.

It prompted by your phone, enter your tour-

FIG. 7.3 - ENTER YOUR PASSKEY

Check your mobile phone display and follow won si bedank. Your headset is now

MUTE/VOLUME key until the INDICATOR On your headset, PUSH IN and HOLD the from the Bluetooth options of your phone. user guide, select discover, or pairing, mode Following instructions in your mobile phone

FIG. 7.2 - SELECT PAIRING MODE

ło dtgnel s'm1a na nidtiw enodą bna tesbaed Once both devices are turned on, place the

See Section 5 for more details. TALK/OM-OFF button until the button lights. to turn on your headset, press and HOLD the

FIG. 7.1 - TURN ON BOTH DEVICES






FIG. 7.2





W1200 backage). ocajeg ou tue basskey card included in your lnige; aug (3) hont tont-gibit peagset basskey cyalded yeadset, (2) your mobile phone user Before PAIRING, you will need: (1) your fully your headset to a Bluetooth mobile phone.

The following instructions show how to pair compatible Bluetooth mobile device.

tue batting process. will light red for 2 seconds and then turn off. Repeat will not sound a tone. Also, the adapter INDICATOR ing after 60 seconds and return to standby mode. It If pairing fails, the headset INDICATOR will stop blink-

will furn off. and both the headset and adapter INDICATOR lights If pairing is successful, the headset will sound a tone The pairing process should take about 15–30 seconds. UME dial until the INDICATOR light begins to flash. Now, PUSH IN and HOLD the headset MUTE/VOL-

unit for about 10 seconds, or until the INDICATOR light Press and HOLD the POWER button on the adapter

Make sure both devices are turned on. See Section 5FIG. 6.3 - PAIRING THE HEADSET AND ADAPTER

set to a Bluetooth enabled mobile phone. See Section $\boldsymbol{\Sigma}$ for instructions on pairing just the head-

yeaqset aug agabtet are already parred when you headset or adapter in your system. Your M J 500 Use these instructions only if you replace either the

BLUETOOTH PAIRING

two screws. Be careful not to over tighten the screws. Replace the bottom cover and insert and tighten the correctly to the labels inside the battery compartment. a uew pattery so the (+) and (-) symbols correspond FIG. 6.2 – Lift the cover and remove the battery. Insert bottom of the adapter using a small Philips screwdriver FIG. 6.1 - Loosen and remove the two screws on the REPLACING THE ADAPTER BATTERY









Visit www.plantronics.com or call 1.800.544.4660 for assistance.

I NEED WORE HELP.

nstructions. see the tootnote in Section 4 for detailed easily aligned for your left ear. Please one very simple adjustment, the headset is be used on your right ear. However, with The headset, as packaged, is ready to

HOW DO I USE THE HEADSET ON MY LEFT

loop to conform to the shape of your ear. Cently bend the angle of the flexible ear-

your ear, causing you discomfort. pressure is not being exerted on any part of loop, both up and down, front and back, so Adjust the height and direction of the ear-

is properly positioned and resting gently on Check to make sure that the adjustable earloop

THE HEADSET IS UNCOMFORTABLE.

Make sure that the headset's microphone is

securely and is compatible with your model Make sure the adapter unit is connected are turned on and the batteries are charged.

Make sure both your headset and adapter trom a headset, then review Section 3. if your phone supports answer/end control Check your mobile phone user guide to see

STERDSET? I CAN'T ANSWER CALLS FROM MY

tioned snugly over your ear.

I DON'T HEAR CALLERS.

CALLERS DO NOT HEAR ME.

Make sure the headset's speaker is posi-

on your headset and on your mobile phone.

jaciud your mouth and positioned properly.

Turn up the volume using the volume control

.ebom etum ni ton si tinu eht that \lambda in mute mode.

you purchased is compatible with your on your M1500 box and make sure the unit plug styles. Check the compatibility sticker Different models of phones require different

WX PHONE? THE ADAPTER UNIT DOESN'T PLUG INTO

What do I do if...

TROUBLESHOOTING

efficiency of the headset.

IN CANADA

Saint-Laurent.

455 Piffield Boulevard

Clean the outside of the headset with a moist cloth once a month. Dirt can decrease the

Replace both the headset and adapter batteries every 12 months.

MAINTENANCE HINTS FOR OPTIMAL PERFORMANCE

MAINTENANCE/TROUBLESHOOTING

WARRANTY AND SERVICES

IMPORTANT SAFETY INSTRUCTIONS

OTHER IMPORTANT INSTRUCTIONS

PARTS AND ACCESSORIES

PAIRING TO ANOTHER DEVICE

M1500 BATTERY

Replacement battery for headset or adapter. 2.4V Nickel Metal Hydride (NiMH).



AC ADAPTER

- 110-Volt AC Adapter. Replacement AC adapter/charger for North America.
- 220-Volt AC Adapter. Replacement AC adapter/charger for Europe.
- 220-Volt UK AC adapter. Replacement AC adapter/charger for United Kingdom



M1500 HEADSET

Replacement headset for your M1500 system. Battery included



M1500 FLEXIBLE EARLOOP

Replacement headset earloop



CAR LIGHTER ADAPTER

Optional car lighter Y-adapter allows you to charge your M1500 headset, adapter and one other device from any 12-Volt car lighter socket.



A500 ADAPTER

Replacement adapter for your M1500 system. Battery included.



- Check local laws regarding use of a mobile phone and headset while driving.
- If you use the product while driving ensure you attention and focus remains on your responsibility of driving safely.
- CHILDREN. Never allow children to play with the headset — small parts may be a choking
- Batteries can be swallowed by children and are dangerous if swallowed. Álways store and dispose of batteries where children can't
- Observe all signs that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blast ing areas, and potentially explosive atmospheres. Turn off your headset prior to boarding an air-
- craft. Do not use your headset in an aircraft. Never mount or store your headset over any air bag deployment area as serious injury may result

when an air bag deploys.

- CAUTION: To reduce the risk of fire or injury to persons, read and follow these instructions
- 1. Use only the battery supplied with this product; Plantronics Part Number 35923-01. 2. Do not dispose of battery in a fire. The cells may
- explode. Check with local codes for possible disposal instructions. 3. Do not open or mutilate battery. Released elec-
- to eyes or skin and may be toxic if swallowed 4. Exercise care in handling the battery in order not to "short" the battery contacts with conducting materials such as rings, bracelets, or keys. The battery or conductor may overheat and

trolyte is corrosive and may cause damage

- 5. Charge the battery in accordance with instructions supplied with this unit.
- 6. Observe proper orientation between battery and charger contacts

- ▲ CAUTION: Use only the supplied Class 2 AC adapter to charge the headset from an AC
- ing charging, disconnect the AC adapter from the wall and contact qualified service personnel
- ⚠ CAUTION: Do not disassemble the AC adapter of this product as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the product is subsequently used.
- ⚠ CAUTION: Do not use the charger outdoors or in damp areas.
- Only charge the headset battery in accordance with the instructions of this manual.
- Charger Output: 5.5V/500mA maximum, center contact positive

345 Encinal Street, Santa Cruz, CA 95060 (800) 544-4660 www.plantronics.com

PLANTRONICS

- Never submerge your headset in water or other
- Protect your headset from spills, excessive rain,
- they may damage the headset or finish of the
- Do not stick anything inside the product as this

- Do not use liquid cleaners or aerosol cleaners as
- Use a damp cloth to clean the external portions
- may damage internal components.

The following one-year warranty and service information applies only to product purchased and used in the U.S. and Canada. Contact your local retail dealer for warranty informa

tion in your country. During this warranty time, if the product is option, will replace or exchange it for a model of equal value. Damage caused by improper care, accidents, unauthorized NEITHER PLANTRONICS NOR YOUR RETAIL DEALER OR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING WITHOUT LIMITATION DAMAGE TO PROF ERTY, COMMERCIAL LOSS OF PROFIT, OR FOR ANY EXPENSES LOSS OF TIME OR INCONVENIENCE

APPLY TO YOU. To obtain warranty service, please prepay shipment and return the unit to the appropriate facility listed at right:

IN THE UNITED STATES Plantronics Service Center

345 Encinal Street Santa Cruz 800.544.4660

514.956.8363

(tall free)

following information TION OF INCIDENTAL OR CONSEQUENTIAL DAMAGE

- Ship-to address
- 4. Number and description of units shipped
- $5. \ \ \text{Name and telephone number of person to call, should con-}$ tact be necessary.
- 6. Reason for return and description of the problem

NOTE: Modifications not expressly approved by

FCC NOTICE

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference; and 2. This device must accept any interference received, includ-
- This equipment has been tested and found to comply w the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a resican radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,

If this equipment does cause harmful interference to radio or television recention, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit differen from that to which the receiver is connected.

- Tel: 800.540.8363 (toll free)
- Fax: 514.956.1825

Please use the original container, or pack the unit(s) in a car to with sufficient packing material to prevent damage. Include the

- 1. Proof of purchase indicating model number and date of
- 2. Bill-to address

ing interference that may cause undesired operation. there is no guarantee that interference will not occur in a

Consult the dealer or an experienced radio/TV technician

EXPOSURE TO RADIO FREQUENCY RADIATION

Plantronics, Inc. could void the user's authority to operate

The radiated output power of this internal wireless radio is far below the FCC radio frequency exposure limits. Never theless, the wireless radio shall be used as described in

The internal wireless radio operates within guideline

found in radio frequency safety standards and recom-mendations, which reflect the consensus of the scientific community. Plantronics therefore believes the internal wireless radio is safe for use by consumers. The level of energy emitted is

far less than the electromagnetic energy emitted by wire-less devices such as mobile phones. However, the use of wireless radios may be restricted in some situations or env ronments, such as aboard airplanes. If you are unsur of restrictions, you are encouraged to ask for authorization before turning on the wireless radio

www.plantronics.com. Assistance Center (TAC) at (800) 544-4660 or visit For accessibility information call the Plantronics Technical

also supports the Audio Gateway Profile. Specification and supports the Headset Profile. The adapter unit Your headset is compliant with version 1.1 of the Bluetooth


This guide will help you set up and use your cordless headset. cordless headset solution is tailored to suit your mobile litestyle. phone. Designed for maximum comfort and ease of use, this and wire-free communication for your headset-ready mobile 2.4GHz Bluetooth technology to provide lightweight, hands-free



CORDLESS HEADSET SOLUTION WITH BLUETOOTHTM **PLANTRONICS**

TUO8A

CORDLESS HEADSET SOLUTION WITH BLUETOOTH™




PLANTRONICS

Bluetooth™

FIG. 2.1

WELCOME

Welcome to the cutting edge of hands-free and wire-free technology for mobile phones. Here are the components to your Plantronics M1500 headset and adapter solution.



GETTING STARTED



FIG. 2.1 - Open the battery compartment by pulling on the two battery door

latches. Remove the door.

TRANSFER/POWER BUTTON

INDICATOR LIGHT

POWER JACK

Install, activate and charge the batteries

FIG. 2.2 - Insert battery into compartment so the (+) and (-) symbols correspond correctly. Replace battery compartment door by inserting the small tabs nearest the speaker and then snapping the door into place.



FIG. 2.4 - Connect the included wall charger to AC power and then to both the headset and adapter power jacks. In a few seconds, the INDICATOR lights will begin to blink. The INDICATOR lights will stop blinking and turn off when the headset and adapter are fully charged.

FIG. 2.3 - Locate the white vinyl strip

out of the slot to activate the battery.

protruding from the rear of the adapter

The first charge takes 2 hours; subsequent charges take just 1 hour. A fully charged headset and adapter will provide approximately 3 hours of talk time and 3 days of standby. Recharging your batteries each night will ensure your headset is ready for use the next day.

The batteries used in this product must be recycled or disposed of properly. Contact your local recycling center for proper disposal instructions.




FIG. 3.1B

• Select a location on your handset to attach the adapter unit. Make sure the attachment point is flat and large enough to fit the supplied tape/Velcro


Check that the adapter unit cord will connect to the headset-jack on your handset without interfering with normal usage.

adapter unit is fixed to your handset, other accessories you use (belt clips, car kits or charging stations) can connect and work properly.

· Peel the backing off one side of it squarely to the back of the adapter unit.

• Peel off the other (exposed) side of

 Now attach the adapter unit to your user guide for instructions for con-



USING YOUR HEADSET








FIG. 5.1 - TURNING THE HEADSET ON AND OFF

• To turn your headset on, press and HOLD the blue TALK button until the button lights. The INDICATOR will light continuously for a few seconds and then

turn off. • To turn your headset off, press and HOLD the TALK button for about 3 seconds or until you hear a tone. The INDICATOR will flash twice and the headset will turn off.

• To check if your headset is turned on or off, hold the unit to your ear and ROTATE the MUTE/VOLUME dial. If you hear a tone, your headset is turned on.

FIG. 5.2 - TURNING THE ADAPTER ON AND OFF

- To turn your adapter on, press and HOLD the blue POWER button until the INDICATOR lights The INDICATOR will flash green while the unit is on.
- To turn your adapter off, press and HOLD the POWER button for about 3 seconds, or until the indicator turns red. The INDICATOR will flash twice and the adapter will turn off.

FIG. 5.3 - HANDLING CALLS

 Make sure both your headset and adapter are turned on and the adapter is connected to your phone.

HANDSET

CONNECTION

MAKING A CALL

- Press the TALK button on your headset to establish a connection between the headset and adapter. You will hear a tone and the INDICATOR lights on both the adapter and headset will begin to flash red
- Dial using your mobile phone keypad and press the SEND key to place a call. You will hear the call progress in your headset.
- When your call is complete, press the TALK button on your headset to disconnect the adapter. The INDICATOR light on the adapter will return to flashing green.

NOTE—To prevent shortened battery life, make sure the adapter INDICA-TOR light is flashing green between calls. If the adapter INDICATOR light is flashing red and you are not using your headset, press the TALK button on the headset to disconnect the adapter.

ACCEPTING A CALL

• As soon as your handset rings, press the TALK button on your headset to establish a connection between the headset and adapter. You will hear a tone and the INDICATOR lights on both the adapter and headset will begin to flash red.

ADAPTER

- Answer the call using your handset SEND key.
- When your call is complete, press the TALK button on your headset to disconnect the adapter. The INDICATOR light on the adapter will return to flashing green.

FIG. 5.4 - ADJUSTING THE VOLUME

- To increase volume, ROTATE the MUTE/VOLUME dial up and release (for headset usage on right ear).
- To lower volume, ROTATE the MUTE/ VOLUME dial down and release (for headset usage on right ear).
- Also adjust the volume on your

NOTE-If using the headset on your left ear, reverse the instructions, rotating down to raise volume, and up to lower it.

FIG. 5.5 - MUTE FUNCTION


FIG. 2.4

- To mute the microphone while on a call, PUSH IN on the MUTE/VOLUME dial. A tone, followed 2 seconds later by a reminder tone, indicates mute function.
- To disable the mute, PUSH IN on the MUTE/VOLUME dial again. A beep indicates Mute function is off.






PUSH IN







Customize your headset so that it fits comfortably. FIG. 4.1 - Rotate the earloop outward.

GETTING THE PERFECT FIT



FIG. 4.3

FIG. 4.4



so it is aligns with your mouth. FIG 4.4 - For left ear usage, simply

FIG 4.2 - Position the headset over

your right ear so that the earloop slides


behind your ear. Bend the flexible ear-

loop to achieve a snug, comfortable fit.

FIG 4.3 - Adjust the microphone BOOM

remove the earloop from the headset, flip the headset over and reinsert the earloop on the opposite side. After completing this step, follow the fit instructions above except using your left ear.

NOTE - If the speaker sounds soft or feels uncomfortable, slide the headset up or down along the earloop post so that it is centered on your ear when fitted.



You may attach the adapter unit directly to your handset or carry it separately in the supplied belt pouch. Before attaching the unit to your handset, place a few calls (see Section 5) and determine a position that provides the best audio performance.

CONNECTING TO YOUR HANDSET

FIG. 3.1 - ATTACHING DIRECTLY TO HANDSET

- patches.
- NOTE Make sure that when the
- the tape/Velcro patch and attach
- the tape/Velcro patch and secure it to your handset.
- handset and connect the cord to the headset-jack. See your mobile phone necting a headset.

FIG. 3.2 - USING THE BELT POUCH

- Open the pouch and slide in the adapter unit with the power jack facing down.
- With the pouch open, slip the adapter cord through the rectangular slot in the top flap and close the pouch.
- Slide the pouch onto your belt and attach the adapter cord to your handset.
- When using the belt pouch, remember to unplug the adapter before you answer or make a call using your handset.



