


Parts List

部件清 / 零件清單 / Teilleiste / Lista de piezas / Nomenclature des pièces / Elenco dei componenti

部品一覧 / 부품 목록 / Deleliste / Lista de peças

SoundStation2 console

SoundStation2 控制台 / SoundStation2 主控台 / SoundStation2-Konsole
 Consola SoundStation2 / Console SoundStation2 / Console SoundStation2
 SoundStation2 本体 / SoundStation2 콘솔 / SoundStation2-konsoll
 Consola do SoundStation2




External microphones

分接麦克风 / 延伸麥克風 / Externe Mikrofone / Micrófonos de extensión
 Micros supplémentaires / Microfoni supplementari / 拡張マイク
 확장 마이크 / Uvidelsesmikrofoner / Microfones de extensão


(Sold as an accessory)

作为配件另售 / 做為配件銷售 / Als Zubehör erhältlich
 Se venden como accesorio / Vendus comme accessoires
 Venduti come accessorio / アクセサリーとして販売 / 별매품
 Selges som ekstrautstyr / Vendida como acessório




Documentation/CD

文档/CD / 文件/光碟 / Dokumentation/CD
 Documentación/CD / CD de documentation
 Documentazione/CD / マニュアル/CD
 문서/CD / Dokumentasjon/CD
 CD/Documentação



Console cable

控制台电缆 / 主控台纜線 / Konsolenkabel
 Cable de la consola / Câble de console
 Cavo della consola / 本体ケーブル
 콘솔 케이블 / Konsollkabel / Cabo do console




Interface module

接口模块 / 介面模組 / Schnittstellenmodul
 Módulo de la interfaz / Module d'interface
 Módulo di interfaccia
 インターフェースモジュール
 인터페이스 모듈 / Grensnittmodul
 Módulo da interface






Telephone cord

电话线 / 電話線 / Telefonkabel
 Cable del teléfono / Cardon de téléphone
 Cavo del telefono / 電話コード / 전화 코드
 Telefonledning / Cabo do telefone



Required Setup

必备件 / 必要的安裝 / Erforderliche Konfiguration / Instalación necesaria / Configuration nécessaire
 Configurazione richiesta / セットアップ方法 / 설치 방법 / Nødvendig oppsett / Configuração
 necessária



Display

显示屏 / 顯示 / Anzeige / Pantalla / Affichage / Schermo / 表示 / 화면 / Skjerm / Display

Information Area
 消息区 / 資訊區域
 Infobereich
 Área de información
 Zone information
 Area informazioni
 情報表示エリア
 정보 표시 영역
 Informasjonsområde
 Área de informação

3125551212

READY

SP DIAL PH BOOK REDIAL

This Phone's Number
 本机号码 / 此電話的號碼
 Telefonnummer dieses
 Geräts / Número de este teléfono
 Numéro de ce poste
 Numero del telefono
 自局電話番号 / 이 전화기 번호
 Nummeret til denne telefonen
 Número deste telefone

Soft Key Functions

软键功能 / 軟體鍵功能
 Display-Tasten-Funktionen
 Funciones de teclas de función
 Fonctions des touches interactives
 Funzioni dei tasti software
 ソフトキー機能
 소프트 키 기능
 Funksjoner for programmerbare taster
 Funções com teclas programáveis

Console

控制台 / 主控台 / Konsole / Consola / Console / Console / 本体 / 콘솔 / Konsoll / Console

LED Indicators

LED 指示灯 / LED 指示器 / LED-Anzeigen / Indicadores LED / Voyants lumineux LED / LED インジケータ

LED 표시기 / Lampeindikatorer / Indicadores LED



Green - Your call is in progress

绿色 - 正在通话 / 綠燈 - 您的通話正在進行中

Grün - Anruf ist aktiv / Verde: su llamada está en curso.

Vert - Appel en cours. / Verde: chiamata in corso

綠 - 通話為進行中 / 녹색 - 통화 중 / Grønn - Samtalen er aktiv

Verde - Sua chamada está em andamento

Red - Your call is muted

红色 - 电话静音 / 紅燈 - 您的通話已靜音

Rot - Anruf ist stummgeschaltet

Rouge - Secret activé

Rosso - silenzatore attivato per la chiamata

赤 - 通話はミュート中 / 빨간색 - 음소거됨

Red - Samtalen er dempet

Vermelho - Sua chamada está sem som

Blinking Green - A call is incoming

绿色闪烁 - 来电显示 / 閃爍綠燈 - 來電進行中

Grün blinkend - Ein Anruf geht ein

Verde intermitente: recepción de llamada entrante.

Vert clignotant - Appel entrant / Verde lampeggiante: chiamata in arrivo

綠の点滅 - 通話が着信中 / 녹색 깜박임 - 수신 중

Blinker grønt - Det kommer inn en samtale

Verde piscante - Uma chamada está sendo recebida

Blinking Red - Your call is on hold

红色闪烁 - 保留通话 / 閃爍紅燈 - 您的通話保留中

Rot blinkend - Anruf wird gehalten

Rouge intermitente: su llamada está en espera.

Rouge clignotant - Appel en garde.

Rosso lampeggiante: chiamata in attesa

赤の点滅 - 通話は保留中

빨간색 깜박임 - 대기 중

Blinker rødt - Samtalen er på venting

Vermelho piscante - Sua chamada está em espera

Buttons

按钮 / 按鈕 / Tasten / Botones / Boutons / Pulsanti / ボタン / 단추 / Knapper / Botões

Exit Button

“退出”按钮 / 結束按鈕

Taste "Beenden"

Botón Salir / Bouton Quitter

Pulsante Esci / 終了ボタン

종료 단추 / Avslutt-knapp

Botão de saída

Menu Button

“菜单”按钮 / 功能表按钮

Menütaсте / Botón Menú

Bouton Menu / Pulsante Menu

メニューボタン / 메뉴 단추

Menüknapp / Botão de menu

Scroll Buttons

滚动按钮 / 移動按鈕 / Navigationstasten

Botones de desplazamiento

Boutons de défilement / Pulsanti di scorrimento

スクロールボタン / 스크롤 단추

Rulleknapper / Botões de rolagem

Soft Keys

软键 / 软键 / Display-Tasten

Teclas de función / Touches interactives

Tasti software / ソフトキー / 소프트웨어 키

Programmierbare tasten

Teclas programáveis

Select Button

“选择”按钮 / 選択按钮 / Taste "Auswahl"

Botón Seleccionar / Bouton de sélection

Pulsante Seleziona / 決定ボタン

선택 단추 / Valg-knapp

Botão de seleção

Phone Button

“电话”按钮 / 電話按鈕

Taste "Telefon"

Botón Teléfono

Bouton Téléphone

Pulsante Telefono

電話ボタン / 전화 단추

Telefon-knapp / Botão de telefone

Volume Buttons

音量按钮 / 音量按钮 / Lautstärkeregulierungstasten

Botones de volumen / Boutons de volume

Pulsanti del volume / 音量ボタン / 音量 단추

Volumknapper / Botões de volume

Conference Button

“会议”按钮 / 會議按鈕

Konferenztaсте / Botón Conferencia

Bouton Conférence

Pulsante Conferenza

CONF ボタン / 회의 단추

Konferanse-knapp

Botão de conferência

Dialing Keypad

拨号键盘 / 撥號鍵台

Wähltastenblock

Teclado de marcación

Cloavier téléphonique

Tastierino

ダイヤルキーパッド

전화 번호 키패드

Oppringings tastatur

Teclado de discagem

Mute


静音 / 靜音

Stummgeschalttaсте

Silenciar / Activer le secret


Mute / ミュート / 음소거

Demp / Sem som




Additional Setup Options

其它安装选项 / 额外的安装选项 / Weitere Konfigurationsmöglichkeiten / Otras opciones de instalación
Autres options de configuration / Opzioni di configurazione aggiuntive / その他のセットアップオプション
추가 설치 옵션 / Ekstra oppsettalternativer / Opções de configuração adicional




External Microphones

分接麦克风 / 延伸麦克风
Externe Mikrofone
Micrófonos de extensión
Micros supplémentaires
Microfoni supplementari
拡張マイク / 확장 마이크
Utvildelsesmikrofoner
Microfones de extensão



Recording Device

录音设备 / 錄音裝置
Aufnahmegerät
Dispositivo de grabación
Appareil enregistreur
Dispositivo di registrazione
録画装置 / 기록 장치
Innspillingsenhet
Dispositivo de gravação



For information, contact your reseller or go to:
www.polycom.com

Polycom WW Headquarters:

Polycom, Inc. Corporate Headquarters
6001 America Center Dr
P.O. Box 641390
San Jose, CA 95164
USA

© 2013 Polycom, Inc. All rights reserved. Polycom®, the Polycom logo and the names and marks associated with Polycom's products are trademarks and/or service marks of Polycom, Inc. and are registered and/or common law marks in the United States and various other countries. All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Polycom.

1725-16756-001 Rev D