

User instructions

Precise BioAccess™ 200



Sweden Precise Biometrics AB, Scheelevägen 19 C, SE-223 70 Lund
Phone +46 46 31 11 00 Fax +46 46 31 11 01 info@precisebiometrics.com

Precise Biometrics AB, Finlandsgatan 66 2nd floor, SE-164 74 Kista
Phone +46 8 632 33 50 Fax +46 8 632 33 55 info@precisebiometrics.com

USA Precise Biometrics Inc, 8300 Boone Boulevard, Suite 500, Vienna VA 22182
Phone +1 (703) 848 9266 Fax +1 (703) 832 0577 infous@precisebiometrics.com

UK Precise Biometrics Ltd, 288 Bishopsgate, London EC2M 4QP
Phone +44 (0) 207 959 3060 Fax +44 (0) 207 959 3030 info@precisebiometrics.com



If you don't get in then

- **Position the finger straight**
- **Try several height positions with the finger**
- **Press harder or softer**
- **Wipe the finger or the sensor**
- **Moist the finger if it's too dry**
- **Reenroll. Try another finger**

1.



Place the card in front of the lower part of BioAccess™ 200. Wait for the green light to the left above the display. The red light indicates a faulty card or a poor reading; try again. Instructions will follow on the display.

2.



Position the finger straight onto the finger guide. Follow the instructions given on the display. If pin code is asked for press in your personal pin code.

3.



The green light to the right above the display indicates a correct match. If a red light displays, then try again.

