



1 YEAR LIMITED WARRANTY PROGRAM

This limited warranty program is the only one that applies to this product, and it sets forth all the responsibilities of Vector Manufacturing, Ltd., regarding this product. There is no other warranty, other than described herein.

This Vector Manufacturing, Ltd. product is warranted, to the original purchaser only, to be free of defects in materials and workmanship for one year from the date of purchase without additional charge. The warranty does not extend to subsequent purchasers or users. Vector Manufacturing, Ltd. will not be responsible for any amount of damage in excess of the retail purchase price of the product under any circumstances. Incidental and consequential damages are specifically excluded from coverage under this warranty. This product is not intended for commercial use. This warranty does not apply to accessories or damage to units from misuse or incorrect installation. Misuse includes wiring or connecting to improper polarity power sources.

RETURN/REPAIR POLICY: Defective products, other than accessories, may be returned postage prepaid to Vector Manufacturing. Any defective product, other than accessories, that is returned to Vector Manufacturing within 30 days of the date of purchase will be replaced free of charge. If such a product is returned more than 30 days but less than one year from the purchase date, Vector Manufacturing will repair the unit or, at its option, replace it free of charge. If the unit is repaired, new or reconditioned replacement parts may be used, at Vector Manufacturing's option. A unit may be replaced with a new or reconditioned unit of the same or comparable design. The repaired or replaced unit will then be warranted under the terms of the remainder of the warranty period. The customer is responsible for the shipping charges on all returned items after 30 days. During the warranty period, Vector Manufacturing, Ltd. will be responsible for the return shipping charges.

LIMITATIONS: This warranty does not cover accessories, bulbs, fuses and batteries, defects resulting from normal wear and tear (including chips, scratches, abrasions, discoloration or fading due to usage or exposure to sunlight, accidents, damage during shipping to our service facility, alterations, unauthorized use or repair, neglect, misuse, a abuse, failure to follow instructions for care and maintenance, fire, flood and Acts of God. If your problem is not covered by this warranty, call our Technical Support Department (954) 584-4446 or toll free (866) 584-5504 for general repair information and charges if applicable. You may also contact us through our website www.vectormfg.com.

STATE LAW RIGHTS: This warranty gives you specific legal rights. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the exclusions or limitations stated herein may not apply. This warranty gives the purchaser specific legal rights; other rights, which vary from state to state, may apply.

TO REQUEST WARRANTY SERVICE FOR THIS PRODUCT: Contact Vector Manufacturing Technical Support by telephone, fax or mail. We suggest that you keep the original packaging in case you need to ship the unit. When returning a product, include your name, address, phone number, dated sales receipt (or copy) and a description of the reason for return and product serial number. After repairing or replacing the unit, we will make every effort to return it to you within four weeks.

WARRANTY ACTIVATION: Please complete Warranty Activation Card and mail to Vector Manufacturing. Enter "VEC168" as Model and "FM Transmitter" as Product Type. All Vector Manufacturing, Ltd. products must be registered within 10 days of purchase to activate this warranty. Mail the completed registration card, along with a copy of the original sales receipt to:

ATTN: CUSTOMER SERVICE / VECTOR MANUFACTURING, Ltd.
4140 SW 28th Way, Ft. Lauderdale, FL 33312
PH: 954-584-4446 • TOLL FREE: 866-584-5504 • Fax: 954-584-5556.
You may also contact us at our web site www.vectormfg.com.

WARRANTY IS NON-TRANSFERABLE AND NON-REFUNDABLE.
RD092004

VEC068



MOBILE FM STEREO AUDIO TRANSMITTER

4 SELECTABLE FREQUENCIES

IDEAL FOR
AUTO/TRUCK, MARINE
AND RV/CAMPING USE




FM FREQUENCIES
1: 88.1
2: 88.3
3: 88.5
4: 88.7

READ ALL INSTRUCTIONS AND PRECAUTIONS
CAREFULLY BEFORE USING THIS PRODUCT.

OWNER'S MANUAL

4140 S.W. 28th Way • Ft. Lauderdale, Florida 33312
Tel: (954) 584-4446 • Fax: (954) 584-5556
Toll Free: (866) 584-5504



CONGRATULATIONS ON PURCHASING THE VECTOR MOBILE FM STEREO AUDIO TRANSMITTER (MODEL VEC068). YOU NOW CAN PLAY YOUR MP3 OR CD AUDIO PLAYER THROUGH YOUR CAR/VEHICLE'S FM STEREO RECEIVER. THE DEVICE IS SIMPLE TO USE; REQUIRES NO WIRES OR A CASSETTE ADAPTER. JUST PLUG IT DIRECTLY INTO A CAR OR VEHICLE'S 12-VOLT DC POWER OUTLET AND PLAY. PLEASE READ CAREFULLY AND FOLLOW INSTRUCTIONS TO ENSURE LONG-TERM TROUBLE-FREE USE.

OPERATION:

NOTE: BEFORE PLUGGING IN THE DEVICE MAKE SURE THE CAR/VEHICLE'S IGNITION IS OFF.

1. INSERT THE VECTOR FM STEREO AUDIO TRANSMITTER INTO THE VEHICLE'S 12-VOLT DC OUTLET OR ACCESSORY SOCKET. A RED INDICATOR (LOCATED ON BOTTOM OF DEVICE) LIGHTS TO SHOW THAT THE DEVICE IS POWERED ON AND WORKING.
2. TUNE THE CAR/VEHICLE'S FM RADIO RECEIVER TO EACH OF THE FOLLOWING CHANNELS: 88.1, 88.3, 88.5, 88.7. TO DETERMINE WHICH STATION HAS NO RADIO SIGNAL. (THE BEST STATION TO USE HAS EITHER NO SIGNAL OR HAS A WEAK AND/OR NOISY ONE. (NOTE: A STRONG SIGNAL INTERFERES WITH AND REDUCES THE DEVICE PERFORMANCE.)
3. SET THE CHANNEL SELECTION SWITCH LOCATED ON THE BACK OF THE VECTOR TRANSMITTER TO THE CHANNEL DECIDED UPON IN STEP 2.
4. CONNECT THE HEADPHONE PLUG ON THE CABLE PROVIDED WITH YOUR VECTOR TRANSMITTER TO THE HEADPHONE OR LINE-OUT JACK ON YOUR MP3 PLAYER OR OTHER AUDIO SOURCE.
5. ADJUST THE VOLUME ADJUSTMENT ON YOUR MP3 PLAYER OR OTHER AUDIO SOURCE TO A MEDIUM OR LOW LEVEL. MAKE SURE THERE IS NO AUDIO DISTORTION. (NOTE: SETTING THE AUDIO VOLUME TOO HIGH RESULTS IN UNDESIRABLE SEVERE AUDIO DISTORTION.)
6. WHEN NOT IN USE, DISCONNECT THE DEVICE FROM THE CAR/VEHICLE'S 12-VOLT DC OUTLET AND STORE THE DEVICE IN A CONVENIENT LOCATION. FAILURE TO DISCONNECT THE DEVICE COULD DRAIN THE CAR/VEHICLE'S BATTERY.

FOR BEST RESULTS:

- Try to keep the Vector transmitter close to the antenna of your FM radio. Although the transmitter often works at distances of 30 feet or more, a distance of 10 feet or less minimizes interference and provides the strongest signal.

FUSE REPLACEMENT

TO REPLACE FUSE, UNSCREW AND REMOVE THE DEVICE TIP AND THE ENCLOSED FUSE. INSERT THE REPLACEMENT FUSE AND SCREW BACK THE DEVICE TIP.

SPECIFICATIONS:

INPUT VOLTAGE	12 VDC
CURRENT	45 mA
FM FREQUENCIES	88.1, 88.3, 88.5, 88.7 MHz
FREQUENCY RESPONSE	100 Hz-15 kHz \pm 3dB
FUSE	500 mA

FCC DECLARATION OF CONFORMITY STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference;
2. This device must accept any interference received, including interference that may cause undesired operation

CAUTION: CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT. THIS UNIT CONTAINS NO USER SERVICEABLE PARTS INSIDE.

FM FREQUENCIES: 1 -	88.1
2 -	88.3
3 -	88.5
4 -	88.7

WARNING: KEEP AWAY FROM WATER, BEVERAGES AND ALL LIQUIDS.

WARNING: THIS UNIT CONTAINS NO USER SERVICEABLE PARTS. DO NOT ATTEMPT TO REPAIR THIS UNIT.

UNAUTHORIZED REPAIRS WILL VOID YOUR WARRANTY. CONTACT VECTOR TECHNICAL SUPPORT FOR REPAIRS (954 584-4446). TOLL FREE (866) 584-5504.

