

Table Of Contents

Safety Summary	iii
Chapter 1: Introduction	
1.1 About This Manual.....	7
1.2 Text Conventions	7
1.3 About The Scan-See.....	8
1.3.1 Features	8
1.3.2 The Scan-See Scanner.....	8
1.3.3 The Scan-See Transceiver.....	8
Chapter 2: Getting Started	
2.1 Getting Started Check List	11
2.2 Important Safety Precautions	11
2.3 Scanning.....	11
2.3.1 Infra-Red (IR) Sensor.....	11
2.3.2 Scan-See Infra-Red Sensor Range.....	11
2.3.3 Detecting A Bar Code	12
2.3.4 Scanning A Bar Code.....	12
2.4 The Display	12
2.5 The Transceiver - Model No. 2015	13
2.5.1 Batteries Used With Transceivers.....	13
2.5.2 Interpreting The Bi-Coloured LED	14
2.6 Communicating With A Teklogix Terminal.....	15
2.6.1 Using Transceivers.....	15
2.6.2 Using Cables	16
2.7 Mounting The Scan-See To The Glove.....	17
2.8 Maintenance	17
Chapter 3: Terminal Settings For Scan-See	
3.1 Setting The Terminal Console Port For Scan-See.....	19
3.2 Scan-See Menu Settings.....	20
3.2.1 Model 7000 Settings – Defaults & Allowable Range	20
3.2.2 Model 7000M Settings – Defaults & Allowable Range.....	20
3.2.3 Mapping The Scan-See Viewport	21
3.3 Scan-See Keyboard Mapping.....	25
3.4 Software Self-Identification	25
Chapter 4: Specifications	