

LWA-SERIES

	Pump Model	LWA1500	LWA2200	LWA15	LWA22	LWA37	LWA55	LWA55H	LWA75	LWA75H
Pos. No.	Part Description	Item #	Item #	Item #	Item #	Item #	Item #	Item #	Item #	Item #
1	CABLE, POWER, SJOW, 12/4 - 15M, LWA 2200	-	200099	-	-	-	-	-	-	-
1	CABLE, POWER, SJOW, 14/4 - 15M, LWA 1500	200100	-	-	-	-	-	-	-	-
1B	CABLE, POWER, ASSY., SOOW 14-5, 230, 460, 575V	-	-	200047	200047	-	-	-	-	-
1B	CABLE, POWER, ASSY., SOOW 12-5, 230, 460, 575V	-	-	-	-	200055	-	-	-	-
1B	CABLE, POWER, ASSY., SOOW 12-5, 460, 575V	-	-	-	-	-	-	-	200055	200055
1B	CABLE, POWER, ASSY., SOOW 10-5, 230, 460, 575V	-	-	-	-	-	200062	200062	-	-
2	BASE, CABLE	200087	200087	-	-	-	-	-	-	-
3	COVER, MOTOR HOUSING, CI	200105	200105	200106	200106	200106	200107	200107	200107	200107
6	BRACKET, LWA1500-2200	200095	200095	-	-	-	-	-	-	-
7	STATOR, 10HP, 460/3/60, 3600 RPM, CLASS F	-	-	-	-	-	-	-	200154	200154
7	STATOR, 10HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	-	-	-	-	200155	200155
7	STATOR, 2HP, 230/1/60, 3600 RPM, CLASS F	200156	-	-	-	-	-	-	-	-
7	STATOR, 2HP, 230/460/ 3/60, 3600 RPM, CLASS F	-	-	200157	-	-	-	-	-	-
7	STATOR, 2HP, 575/3/60, 3600 RPM, CLASS F	-	-	200158	-	-	-	-	-	-
7	STATOR, 3HP, 230/1/60, 3600 RPM, CLASS F	-	200159	-	-	-	-	-	-	-
7	STATOR, 3HP, 230/460/3/60, 3600 RPM, CLASS F	-	-	-	200160	-	-	-	-	-
7	STATOR, 3HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	200161	-	-	-	-	-
7	STATOR, 5HP, 230/460/3/60, 3600 RPM, CLASS F	-	-	-	-	200162	-	-	-	-
7	STATOR, 5HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	-	200163	-	-	-	-
7	STATOR, 7.5HP, 230/460/3/60, 3600 RPM, CLASS F	-	-	-	-	-	200164	200164	-	-
7	STATOR, 7.5HP, 575/3/60, 3600 RPM, CLASS F	-	-	-	-	-	200165	200165	-	-
9	ROTOR, SHAFT ASSY., 2HP, 1 PHASE, 304 SS	200142	-	-	-	-	-	-	-	-
9	ROTOR, SHAFT ASSY., 2HP, 3 PHASE, 304 SS	-	-	200143	-	-	-	-	-	-
9	ROTOR, SHAFT ASSY., 3HP, 1 PHASE, 304 SS	-	200144	-	-	-	-	-	-	-
9	ROTOR, SHAFT ASSY., 3HP, 3 PHASE, 304 SS	-	-	-	200145	-	-	-	-	-
9	ROTOR, SHAFT ASSY., 5HP, 3 PHASE, 304 SS	-	-	-	-	200146	-	-	-	-
9	ROTOR, SHAFT ASSY., 7.5-10HP, 3 PHASE, 304 SS	-	-	-	-	-	200147	200147	200182	200182
10	SWITCH, OVERLOAD 3HP, 230V, 1PH, LWA2200	-	200132	-	-	-	-	-	-	-
10	SWITCH, OVERLOAD 2HP, 230V, 1PH	200175	-	-	-	-	-	-	-	-
10A	SWITCH, OVERLOAD 5HP/230V, 10HP/460V, 3PH	-	-	-	-	200173	-	-	200173	200173
10A	SWITCH, OVERLOAD 10HP, 575V, 3PH	-	-	-	-	-	-	-	200174	200174
10A	SWITCH, OVERLOAD 2HP, 230V, 3PH	-	-	200176	-	-	-	-	-	-
10A	SWITCH, OVERLOAD 3HP/230V, 5HP/460V, 3PH	-	-	-	200177	200177	-	-	-	-
10A	SWITCH, OVERLOAD 2HP, 460V, 3PH	-	-	200178	-	-	-	-	-	-
10A	SWITCH, OVERLOAD 3HP, 460V, 3PH	-	-	-	200179	-	-	-	-	-
10A	SWITCH, OVERLOAD 2HP, 575V, 3PH	-	-	200180	-	-	-	-	-	-

**All 1 HP and up BJM mechanical seal
elastomer material is FKM

LWA-SERIES

		Pump Model	LWA1500	LWA2200	LWA15	LWA22	LWA37	LWA55	LWA55H	LWA75	LWA75H
Pos. No.	Part Description	Item #	Item #	Item #	Item #	Item #	Item #	Item #	Item #	Item #	Item #
10A	SWITCH, OVERLOAD 3HP, 575V, 3PH	-	-	-	200181	-	-	-	-	-	-
10A	SWITCH, OVERLOAD 5HP, 575V, 3PH	-	-	-	-	200184	-	-	-	-	-
10A	SWITCH, OVERLOAD 7.5HP, 230V, 3PH	-	-	-	-	-	200185	200185	-	-	-
10A	SWITCH, OVERLOAD 7.5HP, 460V, 3PH	-	-	-	-	-	200186	200186	-	-	-
10A	SWITCH, OVERLOAD 7.5HP, 575V, 3PH	-	-	-	-	-	200187	200187	-	-	-
10B	PLATE, OVERLOAD SWITCH	-	-	200133	200133	200133	200134	200134	200134	200134	200134
11	RETAINER, BEARING	200139	200139	200139	200139	202818	200141	200141	200141	200141	200141
12	SWITCH, CENTRIFUGAL	200171	200171	-	-	-	-	-	-	-	-
13	COVER, CENTRIFUGAL SWITCH, LWA 1500-2200	200104	200104	-	-	-	-	-	-	-	-
14A	CAPACITOR, RUN, LWA 1500-2200	200101	200101	-	-	-	-	-	-	-	-
14B	CAPACITOR, START	200102	200103	-	-	-	-	-	-	-	-
16	FRAME, MOTOR	200113	200113	200114	200114	200115	200116	200116	200116	200116	200116
18	HOUSING, OUTER W/ 3" NPT DISCH, 304SS	200120	200120	200121	200121	200119	-	-	-	-	-
18	HOUSING, OUTER, 304SS	-	-	-	-	-	200122	200122	200122	200122	200122
19	BRACKET, BEARING	200183	200183	200183	200183	200093	200094	200094	200094	200094	200094
20A	BEARING, UPPER, LWA	200088	200088	200088	200088	200088	200089	200089	200089	200089	200089
20B	BEARING, LOWER, LWA	200089	200089	200089	200089	200968	200091	200091	200091	200091	200091
21	SEAL, MECH., SI/SI X CARB/CER	200151	200151	200151	200151	200152	200153	200153	200153	200153	200153
24	BUSHING, LIP SEAL, 304SS	200096	200096	200096	200096	200097	200098	200098	200098	200098	200098
25	SEAL, LIP	200148	200148	200148	200148	200149	200150	200150	200150	200150	200150
26	VOLUTE, HARDENED DI	200188	200188	200188	200188	200189	200190	200190	200190	200190	200190
27	IMPELLER, HI CHROME CI	200123	200124	200123	200124	200125	200128	200127	200129	200126	200126
28	COVER, SUCTION, HARDENED DI	200108	200108	200108	200108	200109	200111	200112	200110	200111	200111
29	PLATE, WEAR HI CHROME CI	-	-	-	-	-	200167	200136	200137	200167	200167
31	STRAINER, BOTTOM COVER	200166	200166	200166	200166	200166	200168	200168	200168	200168	200168
37	ADAPTER, DISCHARG, 4", MALE NPT	-	-	-	-	-	200082	-	-	200082	200082
37	ADAPTER, DISCHARGE, 3" MALE NPT	-	-	-	-	-	-	200083	-	-	-
37	ADAPTER, DISCHARGE, 6" MALE NPT	-	-	-	-	-	-	-	200084	-	-
39	AGITATOR, HARDENED DI	200085	200085	200085	200085	200085	200086	200086	200086	200086	200086
41	HANDLE, LIFT	200117	200117	200117	200117	200117	200118	200118	200118	200118	200118
46	KEY, IMPELLER	200130	200130	200130	200130	200131	200131	200131	200131	200131	200131
47	KIT, O-RING	200211	200211	200212	200212	200212	200213	200213	200213	200213	200213
53E	SPACER WASHER (LOWER BEARING)	-	-	-	-	-	200997	200997	200997	200997	200997
53F	SPACER WASHER (LOWER BEARING)	200995	200995	200995	200995	200996	-	-	-	-	-
55	PLUG, OIL, LWA	200138	200138	200138	200138	200138	200138	200138	200138	200138	200138
55H	STUB, AGITATOR JOINT	-	-	200169	200169	200169	-	-	200170	200170	200170
55L	STUB, AGITATOR JOINT	200169	200169	-	-	-	200170	200170	-	-	-
64	BRACKET, OVERLOAD (460V & 575V MOTOR ONLY)	-	-	-	-	-	203376	203376	203376	203376	203376

**All 1 HP and up BJM mechanical seal
elastomer material is FKM

Last updated on 4/10/2013