



物料名称：用户手册

物料编号:

材质：70g书写纸，双面单黑印刷

展开尺寸: 531×146mm 成品尺寸: 59×73mm

Running Status	LED Indicator Description
Parking	Red and Blue LED turn alternately
Turn On	LED light in solid red (the LED flash light is off in initial state)
Standby Mode/ TF Card Mode	LED light in solid blue/green
TF Card Music Play	Green LED fast flash
Charging	LED light in red while charging, LED light goes off when fully charged

- Bluetooth Connection (1)**
Headphone is disconnected. It will automatically enter in pairing mode and can be paired with another Bluetooth device.
- Volume Adjustment**
Short press or to adjust volume.
- Music Selection**
Next Track: Short press
Previous Track: Short press
- Play/Pause/Answer the Phone**
Mute/Play/Pause: Short press touchkey
Answer the Phone: Short press touchkey

TF Card Music Play	Language Switch
1 When inserting TF card during shutdown, the driver will enter TF card music play mode.	Double click "Vol+" in pairing status.
Mode Switch: Long press the touch button for 6 seconds to switch between TF card mode and Bluetooth mode.	
Auto off and Long-distance Reconnect	Line-in Mode
When TF card is not working, it will auto off after 5 mins for avoiding energy cost.	Turn on Status Bar, plug the audio connection, can only listen to the music.
The headphone will disconnect when out of the effective range. If you want to reconnect your headphones, please follow these steps:	Turn off Status Bar, plug the audio connection, can only listen to the music.
(1)long press the touch button for 5 seconds; (2)long press the touch button for 5 seconds.	NOTE: If you want to listen to the music from the headphones, you need to plug the headphones to use.

Parameters	
Profiles Supported	A2DP
Accept Range	8-15
Speaker Resistance	32Ω
Speaker Sensitivity	108dB
Frequency Range	20-20KHz

Packing	
1. Bluetooth Headphone	
2. User Manual	

on	Attentions
P / SVP / HFP	1. Please keep or use the headphones in normal temperature, direct sunlight. 2. Please keep the headphones away from fire or other heat sources. 3. Please keep the headphones away from water or submerged in liquid. Keep dry. 4. Please don't try another method for charging except USB charging cable we provide. 5. Please don't disassemble, repair or modify. 6. Please keep the headphones away from magnetic field, if any, such as computer, monitor, television, etc. 7. If the headphones produce an abnormal sound, such as normal temperature, color or shape changes, stop using it immediately and contact the customer service for further information on your warranty card.
TK-HZ	
HZ	
B Charging Cable	
Certification	

WARRANTY CARD	
Product Model:	Product ID#:
Purchase Date:	Purchase Store:
Purchase Account:	Resale To Merchant:
User Name:	Phone Number:
User Address:	
Warranty Description <small>Please keep the original sales receipt and/or purchase凭证 as evidence of purchase date. This warranty does not apply to damage resulting from accident, misuse, abuse or normal wear and tear. The manufacturer's standard warranty period for the product applies. The length of the warranty period will be based on the product manufacturer's date.</small>	
Warranty Regulations <small>For more information about warranties, contact the manufacturer or distributor.</small>	

FCC Statement:
This device complies with FCC rules and is exempt from Part 15 of the FCC Rules.
The equipment does not cause harmful interference in a residential installation.
However, the user could experience interference from radio communications, television reception, or other devices.
If this equipment does cause harmful interference to radio or television reception, or to other devices,
the user is encouraged to try to correct the interference by one or more of the following methods:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into a circuit different than that
used by the radio or television.
• Consult the dealer or an experienced radio/TV technician for
help.