




PSDNL12

3-in-1 Multifunction Rechargeable FM/AM  
Radio with LED Flashlight and Compass  
Instruction Manual



[www.pyleaudio.com](http://www.pyleaudio.com)



### Functions:

#### 1. Torch:

Press "LED Switch" to turn on/off one Red LED or four White LEDs.

#### 2. Radio

- 1) When "Alarm Switch" is turned off "OFF", turn the "Radio Power & Volume Control" counter-clockwise to proper position to turn on the radio.
- 2) When "AM/FM Switch" is switched to "FM", unit will receive FM frequencies, adjust rotating Antenna to get better FM radio reception.
- 3) When "AM/FM Switch" at the state of "AM", unit will receive AM frequencies, adjust position of unit to get better AM radio reception.

Frequency: AM 530-1600KHZ

FM 88-108MHZ

#### 3. Alarm

When "Alarm Switch" is positioned "ON", Alarm function sounds.

#### 4. Charge

##### 1) Rotating the Hand Crank Charger

- a) When power is drained or LED is dim or volume reduced
- b) Keep "LED Switch" "RADIO POWER & VOLUME CONTROL" "ALARM SWITCH" OFF. Rotating Handle clockwise 90 seconds (80-120 times per minute) to charge.
- c) Charge 90 seconds can operate radio 10 minutes, if LED cannot light 10 minutes, replace rechargeable battery.

Note: When battery is depleted, charge at once. To protect battery, suggest to charge 90 seconds every 3 months.

##### 2) Using USB DC Charging Cable

When plugged into USB cable, unit will charge.

DC Power: 6V 80Ma

Note: To protect unit, suggest to charge not over 5 hours; attention to "+" "-"

3) How to Charge Other 6V DC Device

- a) Use fitted at both ends power cord.(Not Included)
- b) Connect one side with DC Input/output Socket, the other side with input DC 6V device.

Note: Attention to "+" and "-" of multi-function charging power cord. Otherwise may cause damage to device.

5. Compass

When in use, keep in level position and keep away from magnetic material. This will assure correct reading.

Specifications:

DC charge:6V 80mA

AM 530-1600KHZ

FM 88-108MHZ