Model QT5516	
Туре	Analog
Video Format	NTSC/PAL
Live Display Resolution(s)	720x480, 720P, 1080P
Video Compression	H264
Live Display FPS	30
Languages	English, Chinese (Simplified & Traditional), Czech, French, Portuguese, Spanish, Turkish, Bulgarian, Greek, Italian, German, Russian, Polish, Japanese, Indonesian, Thai, Hungarian, Lithuanian, Vietnamese, Dutch, Swedish, Norwegian, Persian, Arabic, Romanian
CIF	
CIF Recording Display Resolutions	352x240
CIF Recording FPS	30
2CIF	
2CIF Recording Display Resolutions	Not Applicable
2CIF Recording FPS	Not Applicable
D1	
D1 Recording Display Resolutions	702x480
D1 Recording FPS	30
960H	
960H Recording Display Resolutions	960x480
960H Recording FPS	15
720p	
720p Recording Display Resolutions	Not Applicable
720p Recording FPS	Not Applicable
1080p	
1080p Recording Display Resolutions	Not Applicable
1080p Recording FPS	Not Applicable

Hard Drives	
Maximum Size	ЗТВ
Number Supported	1
Recording	
Recording Modes	Manual, Time Schedule, Motion Detection
Display Modes	1, 4, 8, 16, Auto Sequence
Backup Methods	USB Flash Drive, USB Hard Drive, Network
Playback	
Playback Speed	30FPS
Number Channels Simultaneous Local Playback	16
Video, Audio & Alarm Ports	
Video In	16 BNC
Video Out	HDMI, VGA, BNC
Alarm In	16
Alarm Out	1
Audio In	4 (2 way available on 1 st port)
Audio Out	1
PTZ	
PTZ Support	RS485
Supported Protocols	Null, Pelco D, Pelco D, Lilin, Minking, Neon, Star, VIDO, DSCP, VISCA, Samsung, RM110, HY
Communication Ports	
Network	RJ45 10/100 mbps
USB	2 USB 2.0
eSATA	None
Compatibility	
Software Support	QT View
Mobile Support	iPhone, iPad, Android
Computer Support	WinXP, Vista, Win7/8, Mac OS 10.7/10.8/10.9
Remote Monitoring	
Dual Stream	CIF
Simultaneous Users	10

Power	
Power Supply	12V 2A
Power Consumption	15W w/o hard drive
Physical	
Weight	3.3 lbs
Dimensions (WxDxH)	11.75 x 10.75 x 2 in
Operating Temperature Range	50°F to 104° F
Accessories	
Control	Remote, Mouse
Connectors/Cables	HDMI, RCA to BNC Adapter
Power	12V 2A
Mounting Hardware	Hard Drive Screws
Other	CD with manuals & software, quick start guide