

# CARE AND WARNING

## WARNING:

Changers or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/panel PC technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

"FCC & CE RF Radiation Exposure Statement Caution: To maintain compliance with the FCC & CE's RF exposure guidelines, place the product at least 20cm from near by persons."

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This product complies with ISED radiation exposure limits set forth for an uncontrolled environment.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

This product should be installed and operated with minimum distance 20 cm between the radiator and your body.

For products available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

For LE-LAN devices

- i. the device for operation in the band 5150~5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;
- ii. the maximum antenna gain permitted for devices in the bands 5250-5350 MHz and 5470-5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit;

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Ce produit sont conformes aux limites ISED d'exposition aux rayonnements définies pour un environnement non contrôlé.

Cet appareil et son antenne (s) ne doit pas être co-localisés ou fonctionnement en association avec une autre antenne ou transmetteur.

Ce produit doivent être installés et utilisés avec distance minimum de 20 cm entre le radiateur et votre corps.

Pour les produits disponibles aux États-Unis / Canada du marché, seul le canal 1 à 11 peuvent être exploités. Sélection d'autres canaux n'est pas possible.

Pour les appareils LE-LAN

- i. les dispositifs fonctionnant dans la bande de 5 150 à 5 250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;
- ii. le gain maximal d'antenne permis pour les dispositifs utilisant les bandes de 5 250 à 5 350 MHz et de 5 470 à 5 725 MHz doit être conforme à la limite de la p.i.r.e.;

## Declaration of Conformity

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC), RoHS directive (2011/65/EU) and Radio Equipment Directive (2014/53/EU).

This product has been tested and found to comply with the harmonized standards for Information Technology Equipment, these harmonized standards published under Directives of Official Journal of the European Union.

Adaptor with ferrite must be used with this equipment to ensure compliance with the Class B FCC limits.

Specifications of the DC power adapter

Model: SOY-0500200-090/PSAF10R-050Q

Input: 100-240V~50/60Hz 0.5A Max

Output: 5V 2A

**NOTE:** Operating Temperature: 0~40°C

**Qbic Technology Co., Ltd.**

26F.-12, No 99, Sec. 1, Xintai 5th Rd., Xizhi Dist., New Taipei City 22175, Taiwan (R.O.C)

Tel: 886-2-2697-2000 / FAX: 886-2-2697-2868




QTD06001ENQ01

# Quick Start Guide

This quick guide will help you go through installation quickly

## Panel PC TD-0360



Support site




QSG download link

The color depends on the actual product.


The specifications are subject to change without prior notification to improve the performance.




## Contents




Panel PC



Bracket




Bracket Screw \*2  
Specification: M2\*3 (T5)  
Rubber caps \*2




Adhesive tape



USB cable




DC Power Adaptor



Power Plug  
(Provided by region)


## Indication




- |                       |                              |
|-----------------------|------------------------------|
| 1 Front LED indicator | 5 Reset Button               |
| 2 Touch Display       | 6 Micro USB for ADB          |
| 3 Rear LED indicator  | 7 USB Type-C (Power USB 2.0) |
| 4 Speaker             | 8 NFC / RFID                 |

## Installation

### 1. Cable Connection




Plug USB cable into USB port.



\*The TD-0360 is designed for installation with a discreet cable management system.


### 2. Surface Bracket Mount Installation

#### Step 1




Install the bracket on surface.  
Screw specifications: KA 4\*14  
Diameter: 8mm  
(Screws are not provided)

#### Step 2




Assemble the panel PC to the bracket.

#### Step 3



Tighten the screws. Locations are shown in above illustration.  
\*Bracket screws\*2 (M2\*3)


#### Step 4



Cover the screws with rubber caps.


### 3. Adhesive Bracket Mount Installation

#### Step 1




Laminate adhesive to the back of bracket.

#### Step 2




Peel off the adhesive and attach the bracket on a smooth and clean surface. (Refer to "Surface Preparation for Tape Application")

#### Step 3




Assemble the panel PC to the bracket.

#### Step 4



Tighten the screws. Locations are shown in above illustration.  
\*Bracket screws\*2 (M2\*3)

#### Step 5



Cover the screws with rubber caps.