



Notice:

1. Please do not drop down or crash.
 2. Please keep the camera away from the magnet.
 3. Please keep it away from the high temperature place.
 4. Please use the branded Micro SD.
 5. Please keep the micro SD card away from magnet.
 6. Please get out of the cable from adaptor during recharging if you found there is the smoking, strange smell etc.
 7. During recharging, please keep it away from Children.
 8. Please store the product in dry and cool place.
- Please read this manual and please be sure you fully understand the manual and its Description before using.
- Features**
 Waterproof, it can work under water, 30m.
 WiFi Function, the user can operation or review via Smart Phone or Ipad.
 1920*1080@30fps
 2" TFT
 Detachable battery that is easy to replace and prolongs your camera's life.
 It can shoot video during charging.
 100° ultra wide angle field of view
 HDMI out
 Web Camera
 Micro SD Card Max 32G
 1080P(30fps)/720P(60fps)/720P(30fps)
 MPEG video format

Picture of Accessories



Diagram waterproof shell



General



Option



