



Premium Wireless Over Ear Headset Instruction

Welcome use

Welcomed select the IJOY LOGO premium wireless headset, the product can provide high quality listening enjoyment for your computer, mobile phone, and multimedia. Before using this product, carefully read this manual to correctly manipulate and play its best performance. If somewhere puzzled, please ask your local dealer or call us.

Notice

Do NOT expose product to extreme temperatures, moisture or electric shock.

Do NOT attempt to open the unit for any reason. Do NOT attempt to manipulate any electrical components in the unit. Doing so will invalidate any implied or written warranty and will release us from any liability related to product.

Do NOT attempt to use if internal components have been exposed to liquid. This notice serves to release us from any liability for damages caused by use of product following exposure to liquid.

Keeping unit on when not in use will shorten the lifespan of the battery. Please use responsibly.

Package Contents

- 1- Bluetooth Headset -----1pcs
- 2- Micro USB Charging Cable -----1pcs
- 3- Aux in cable -----1pcs
- 4- User Instruction -----1pcs

Specifications

Bluetooth: 4.1

Battery: 3.7V/250mAh


Standby/talk: 120 hrs/ 6hrs

Playback time: 6 hrs







Charge time: 2 hrs

Working Distance: 10M

Constructions



Keys Description

1. Switch power button to the right direction to turn on the headset. You will hear a prompt. Switch power button to the left direction to turn off the headset.
2. Press “” button to play or pause music, answer or hang up a call; press “” button twice to redial last number.
3. Press “” button to skip to next track; press and hold down “” button to decrease volume.
4. Press “” button to skip to previous track; press and hold down “” button to increase volume.
5. Press “M” button to switch to Bluetooth or FM mode.
6. Press “EQ” button for different styles of music.
7. Plug in AN aux cable to the Aux plug in port to enjoy the music directly. All button functions will stop working under Aux mode.
8. Put a TF card into the TF card slot to play music directly.

Bluetooth Headset Pairing

Turn on the headset by switching the power button to right direction; you will hear a prompt tone. Turn Bluetooth on using your phone or audio device and search for “JOY LOGO” in the Bluetooth device list, and pair it. There will be prompt tone played as soon as pairing is successful. Please make sure it is under Bluetooth mode when pairing.

Bluetooth Headset Charging

Headset with built in battery, can portable use, when the headset automatically shut down during playing music, means power is to run out, needs to be charged. Connect a micro USB cable to a 5V 1A power source to charge the unit. Red indicator will be on when charging, and changes to blue once completion of charging.

Troubleshooting

Failure to connect to a Bluetooth-enabled device can be caused by any of the following:

Other Bluetooth devices are in pairing or sync mode and are interfering with your connection. Please remove other devices from the vicinity or turn them off.

Static or muffled sound can be caused by any of the following:

There are major Bluetooth obstructions between your device and the headset.

You have extended the headset beyond the recommended distance between devices.

Product Warranty

This product comes with a limited one year warranty from date of purchase. This warranty covers any product failures and offers a replacement guarantee. We will replace this product if it fails within 1 year of purchase date. All warranties are handled by the Authorized Reseller. Please retain your receipt. Please contact your authorized reseller with the receipt to process a replacement.

This replacement guarantee does not imply any liability for any product-related damages. Please use responsibly.

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by QUEST USA CORP may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.