

# **Deluxe Remote Trainer Owner's Manual**

Changes made to the old Remote Trainer Owner's Manual for new manual

## **Front Page**

Change picture to reflect dog with new receiver

## **Components**

Add to the list of "Components" – receiver batteries, long probes

Add picture instead of drawing displaying the components

## **Assemble Collar**

Change instructions to the following:

To assemble the collar, first measure your pet's neck, mark the appropriate length, and cut off any excess collar. Seal the edge of the cut by taking a match or lighter along the frayed edge.

***Note: When cutting off the excess collar, be sure to leave enough slack for your dog's growth.***

When threading your collar through the clasp, loop it through the clasp exactly as illustrated. Pull on the excess collar. If it slides at all, it was not looped correctly.

Add new threading instructions

If your dog has long or thick hair, the longer probes might be more effective in delivering the stimulation to your dog. If the dog still has trouble feeling the stimulation even with the longer probes, the dog's hair will need to be trimmed. This can be done either by a veterinarian, or you can do it yourself.

## **Install Batteries**

The transmitter takes one (1) 9-Volt Alkaline battery. To install, follow the instructions listed below:

- Place your finger on top of the “Pull” area of the battery door, located on the backside of the transmitter.
- Now remove the battery door by pulling your finger towards you.
- Insert the battery and replace the battery door.

Add picture(s) of transmitters displaying each step.

The receiver takes two (2) 3-Volt Lithium batteries (Model 2032). To install, follow the instructions listed below:

- With a Philips screwdriver, remove the two screws located on top of the receiver.
- Remove the battery door and insert the two batteries into the battery door as shown in the drawing below.

Add same drawing that is for the Ultralight receiver in the Owners guide for the fence system.

- Insert battery door with batteries back into the receiver and secure it with the two screws.

## **Turning the Deluxe Remote Trainer On/Off**

**To turn the receiver on**, slowly connect the white dots located on both the receiver and transmitter and separate. Upon separating, the receiver will emit one short beep.

***Note: Once the receiver has been activated, the receiver must be manually turned off by following the instructions shown below.***

**To turn the receiver off**, slowly connect the white dots located on both the receiver and transmitter, hold for three (3) seconds, and separate. Upon separating, the receiver will emit a long beep indicating the unit has been turned off.

Add new pictures showing white dots.

## **Setting the Stimulation Level**

To set the stimulation level, hold down the “Program” button. After a few seconds, the receiver will indicate the present stimulation level by beeping a number of times corresponding to the current level. For instance, for level 1, the receiver will beep one time. For level 8, the receiver will beep eight times.

Continue to hold the “Program” button down until the number of beeps equals the level of stimulation you want. After Level 8, the receiver will go back to Level 1.

Once the receiver has been programmed to the desired stimulation level, the receiver will remember that level whether the unit has been turned off or with the batteries replaced.

Add picture of new transmitter

## **Placing the Collar on Your pet**

Keep everything except last statement.

## **Maintenance**

Check batteries (weekly)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a practical installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modifications to the equipment, not approved by PetSafe, could result in not meeting compliance with FCC regulations and could void the user’s authority to operate the equipment.

Radio Systems Corporation, 10427 Electric Ave, Knoxville, TN 37932  
**1-800-732-2677**                      **www.petsafe.net**