

Quick Start Guide Of 2.4GHz Wireless Ultra Slim Keypad

Keypad Functions



Installation

1. Plug the Micro receiver into a USB port of your computer.
2. Open the battery door and install battery.
3. Click the keypad key to get connected with the receiver.

Caution:

Before your keypad is connected with the receiver. You need to keep the keypad at a distance of less than 2 meter to the receiver to finish the initial connection.

Trouble Shooting

1. Check Micro receiver connection; try to inserting Micro Receiver to another USB port on your computer.
2. Connection between the keypad and the Micro Receiver. Re-insert the Micro Receiver. Take out the battery and reinstall it.

Note:

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference

to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.