


Wireless Audio Box User Manual



Introduction

Thank you for purchasing the Wireless Audio Box. Please read this user manual carefully for the proper use of the Wireless Audio Box and keep it for future reference.

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any mean, electronic or mechanical, for any purpose, without the express written prior permission of the seller.

Trademarks

Windows, Microsoft and Windows Vista are registered trademarks of Microsoft Corporation.

Mac is registered trademark of Apple Inc.

Other trademarks and registered trademarks are used herein for identification purpose only and belong to their respective companies.

Certification



FEDERAL COMMUNICATIONS COMMISSION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

EU DECLARATION OF CONFORMITY

This product is carrying the CE-Mark in accordance with the related European Directives.

Features

- Stream music on your PC to your stereo without running wires.
- CD quality 16-bit/44.1 kHz stereo.
- Up to 150 feet (50 meters) range.
- Get started in 3 steps-- **Connect**, **Power on** and **Play**.
- No software required.
- RCA and 3.5mm jack audio output.


System Requirements



- Windows® 2000/XP/Windows Vista™ or Mac OS® 10.4 or later
- An available USB port on PC or Mac
- Multimedia software installed on PC or Mac


Package Contents


- Wireless Audio Box *1
- USB dongle *1
- USB power adapter *1
- RCA to 3.5mm jack audio cable *1
- User manual *1


Initial set up for the Wireless Audio Box

Step 1  Connect the USB dongle to the USB port on your PC or MAC.

Step 2  **RCA L/R Jack** or  **3.5mm Jack** Connect the audio cable to the RCA or 3.5mm jack to Wireless Audio Box.

Step 3  **Output Device** Connect the other side of the audio cable to the RCA or 3.5mm jack of the stereo device, such as speakers, headsets, etc.

Step 4  Connect the supplied USB power adapter to the Wireless Audio Box and plug the adapter into power outlet.

Step 5  Press the power on button on the Wireless Audio Box, once the Wireless Audio Box is activated, the green LED will be blinking regularly.

Step 6 Choose the USB Speaker as default audio output device for the first time use.

➤ For Windows®:



Open the “*Sounds and Audio Devices Properties*” and choose the **USB speaker** as default Sound playback device.


➤ For Mac OS®:



Open the “*System Preferences → Sound*” and choose the **USB speaker** as default sound output device.

Now, play a song on your computer and enjoy the convenience of wireless!

Parts descriptions




	Icons	Keys	Function description
1	LED	Mode indicator	1. Working mode: green LED blinks regularly. 2. Pairing mode: green LED blinks faster.
2		1. Power On/Off 2. Pairing	1. Press to turn ON and OFF. 2. Press and hold the button 3 seconds to activate the pairing mode. (green LED blinks faster) Note: Implement the pairing in case of serious cross-interferenced.
3		Volume up	Click to adjust volume level.
4		Volume down	Click to adjust volume level.
5		Audio output	RCA jack L/R.
6		Audio output	3.5mm audio jack.
7		Power source	5V DC adapter.

Note: The green LED on Wireless Audio Box will be died out once losing the connection to the USB dongle.


How to pair the Wireless Audio Box

Step 1



Press and hold the button for 3 seconds until the green LED on Wireless audio Box blinks faster.

Step 2



Press the pairing button on USB dongle, the green LED on USB dongle will light up. Once the Wireless Audio Box retrieve the new ID, the green LED on USB dongle will resume blinking regularly.

Specifications

Frequency	2400MHz~2483MHz
Channel number	38
Data rate	4M bps
Wireless range	Up to 150 feet (50 meters)
Audio resolution	16-bit / 44.1KHz
Interface	USB 1.1
Power Type	USB Power 5V
Power Consumption	Working:45mA
Transmitter Dimensions	75 x 19 x 10.3mm (W x H x D)
Receiver Dimensions	90 x 70.65 x 26mm (W x H x D)
Transmitter Weight	Approx. 15g
Receiver Weight	Approx. 90g