changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installati This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Light control: the "Bulb Color" section of the homepage is where you can control all of the light bulb specific features, such as:

Turning the light off & on

Light & Features:

Changing the color of the light (press the center bulb icon to turn the light back to white)

Change the feature of the lights to Normal, Rainbow, Random, Flashing, or Candle

Here you can control the Timer & Sleep Assistant

- Main Menu: in the upper left of the app there is a menu button Timer: set an alarm and customize the music and lighting effects
- Sleep Assistant; program a time that the bulb will turn itself off



Tips & Troubleshooting:

Changing the device that is controlling the Chroma-Melody Light Bulb Switch the mobile device by disconnecting the Chroma-Melody speaker in the settings and of your mobile device. If you are unable to Pair your phone's Bluetooth to the bulb, make sure the bulb is not connected to a different device at that time.

**Once the bulb is connected to a device, it will not be able to connect to a second device unless it is disconnected in the Bluetooth settings app or the first device loses its Bluetooth connection by being

Bluetooth distance: No obstacle 10M Frequency hand: 2 4GH7 Bluetooth protocol: A2DPV1.2 AVCRPV1.0/DIV1.3 Working temp: -10-50⊠

Precautions:

- 1. Do not put Chroma Melody in closed lampshade
- 2. Do not install Chroma Melody on the light with dimmed switch
- 3. Do not place Chroma Melody near water or humid environment
- 4. Keep using it under the power supply of 100V to 240V AC. 50-60HZ 5. Chroma Melody is not a toy and should be kept out of the reach of children
- 6. Do not place Chroma Melody on high-temperature surface
- 7. Do not open any sealing device for safety and in accordance to Warranty Terms
- 8. Cool the bulb before replacing it to avoid electric shock or burning

Specifications of Chroma-Melody Light Bulb

Light effect: 59.61 1m/w

Radiation flux: De=836.9mw

Base specification: E27/B22

Bluetooth version: Bluetooth 4.0 Dual mode

LED colors: red, orange, yellow, green, light blue, blue and purple

Product power: LED 6W, AMP 3V life made warrants this product against defects in workmanship and material for a period of 12 months. Working voltage: AC100-240V from the original date of purchase. If the product fails during normal and proper use within the warranty period. life made will repair or replace any products or parts determined to be defective in workmanship o Working frequency: 50-60HZ material at its option. All components repaired or replaced by life made's service site will be under Viewing angle of LED bulb: 120 degree warranty for the remaining period of warranty Color temperature: TC=6520K Red ratio: R=13.2% This Limited Warranty covers only the accessory components packaged with this product. This Limited Color rendering index: Ra=70.9 Warranty does not include failure caused by improper installation, operation, cleaning or maintenance. Light-flux: Φ=273.01m

accident, damage caused by extreme temperature, humidity or extreme electrical stress, misuse, abuse unauthorized modifications to the product, software faults, normal wear and tear or any other event, act. default or omission outside of life made's control or if the serial number has been defaced, altered or removed and the casing has been opened.

life made Limited Warranty Statement

To obtain warranty service, please contact life made for specific instructions at the email below, Dated. documented proof of the original purchase is required.

life made Customer Service Representatives are available by emailing support@lifemade.com

USER MANUAL

life made....™ simple • better • easier

Chroma-Melody

Connection/Pairing for Lighting Function:

- -To control the light function of bulb, open the "Chroma-Melody" App.
- -Under the CONNECT tab, connect the Bluetooth AGAIN inside the "Chroma-Melody" App.
- After a successful pairing inside the App, you can:
- -Control the bulb color and brightness under the LIGHT tab
- -Control the On/Off function on the LIGHT tab
- -Have the color of the light change to the music's beat by selecting the Automatic function
- -Control the light turning off via the TIMER tab

- . To install the Chroma-Melody lightbulb, screw the bulb into any light socket.
- Next you'll need to download the "Chroma-Melody" App from the iTunes App or Google Play Store Bulb screws into any B22 socket.

Installation of APP software:

Connection/Pairing for Bluetooth Speaker If you're using the Chroma Melody for the first time, follow the steps below:

-Power on the Chroma-Melody lightbulb -Download the "Chroma-Melody" App from the iTunes App Store or Google Play Store.

To play music through the Chroma Melody Bulb, power on your Chroma-Melody Lightbulb and connect the bulb via Bluetooth under your device's system settings.

- Caution: Always turn off your light switch before screwing in your Chroma-Melody Bulb

-Applicable Apple devices: Supports iPhone 4S and later with iOS 7.0 and later versions. -Applicable Android devices: Supports Android 2.3.3 and later.

Note: APP software can be downloaded by searching "LM Chroma-Melody" in your phone's APP Store reopen the Chroma-Melody App

go to 'Bluetooth Conn" and click on the 'Chroma-Melody' icon at the top"



- After a successful Bluetooth connection, you will hear a Bluetooth connection tone. Next, exit the Settings App and open the "Chroma-Melody App"

For Android open the APP and click "Connect"

After successfully connecting to the Chroma-Melody App via Bluetooth.

Click on the Menu icon on the top and



Bluetooth Conn Chroma-Melody

After installing and connecting to the Chroma-Melody lightbulb, you must swipe to the left for 4 screens until you see the "Enter" icon. -Then click "Enter" to gain access to the APP



toggling the top menu bar with the below options.

Normal (solid white light), Rainbow, Pulse, Flashing, Candle



-If you choose the icon in the middle of the wheel, the bulb will become a solid white light

- You can also choose between the 5 lighting options to go with your color choice. This can be done by



top left screen, this will bring you some alternate features



If you hit the icon on the . Timing lights (can set bulb on a time

. Sleep assistant (can set the bulb &



- music to turn off after a predetermined
- choose your timing settings

No fireing Lights



- . Click the "+" icon to
- Sleep Assistant (to



About (shows the

current version of the

Chroma-Melody APP)

choose sleep time)



there will be an Overview section. You can click "My Music" at the top to load all the music on your phone.

click the "Music" icon

on the hottom of

After clicking Music Tab.



the beat, simply click the





Clicking "Settings" allows you to change the feature "shaking" your phone controls







-To disconnect your phone from the Chroma-Melody bulb, disconnect the Bluetooth pairing inside the Settings app of your phone