

# RB-M7


Bluetooth speakers

Instruction manual ▶

---



**REMAX**®



1.Power button 2.USB port 3.Indicator lights 4. Play  
5.Volume up 6.Volume down

# PRODUCT PARAMETERS

**Model:**RB-M7 Bluetooth speakers

**The Bluetooth brand:** ACTIONS

**Bluetooth version:** 3.0

**Transmission distance:** ≥ 10 m

**Speaker:** 4Ω5W\*2

**Output power:** 4W+4W

**Battery:** 3.7V, 2200mAh, 18650 li-ion battery

**Working hours:** with maximum volume for more than 6 hours

**Charging time:** 4 hours

**Charging connection:** micro USB

**Built-in mic:** yes

**Receiving calls:** yes

**Size:** 198\*84.5\*64.5mm

**Net weight:** 485g

**Accessories:** one 60cm USB charging cable

## PRODUCT INTRODUCTION

### 1.Functions' characteristics

Power button □ notification sound, Bluetooth+USB card+free communication.

### 2.Buttons

Button	Action	Bluetooth music	Call	Conversation	USB sound card	Attention
CALL/▶	Short press	Play/Stop	Answer	Hung up	Mute	
	Long press	–	Reject	–	–	
Previous song / volume down	Short press	Volume down	Volume down	Volume down	Volume down	When it is on maximum, you will hear a notification sound
	Long press	Previous song	–	–	–	
Next song/ volume up	Short press	Volume up	Volume up	Volume up	Volume up	When it is on maximum, you will hear a notification sound
	Long press	Next song	–	–	–	
POWER	Short press	Change mode	–	–	Change mode	
	Long press	Turn on/off	Turn on/off	Turn on/off	Turn on/off	

### 3.Mode switch order

After turning on the machine, it will automatically turn on Bluetooth mode, quick-press POWER button to change modes. When you will switch modes, you will hear notification sound.

### 4.Notification light

There is red and blue light.

- 1.Red light is on when device is charging, it is blinking long and slowly. After it is fully charged, the light is out.
- 2.Blue light is on during the Bluetooth mode. While your devices are pairing, the light blinking slowly, after pairing is completed, it is blinking long and slowly. When Bluetooth/TF card playing/stopping music, there is a long light.
- 3.While playing music from USB sound card, red and blue lights will blink long at the same time.
- 4.When the battery is low, red light will blink slowly (and you will hear notification sound as well).

### 5.Notification sound

When you will turn on the device, pairing or un-pairing devices, changing modes, battery is low, sound is on maximum, there will be a notification sound.

### 6.Bluetooth instruction

- 1.After turning on this device, it will automatically turn on Bluetooth, you will hear a notification sound, and blue light will start slowly blinking. Enter pairing mode and you will hear another notification sound. Light will start blinking long and slowly. At first, you will have to pair them manually, after that they will pair automatically.
2. Long press (previous song/VOL-) button to change to the previous song, short press to put volume down.
3. Long press (next song/VOL+) button to change to the next song, short press to put volume up.
- 4.Short press (CALL/play) button to play or stop a song.
- 5.When someone is calling, short press(CALL/play) button to answer, long press for rejecting a call. During your conversation short-press (CALL/play) to hung up.
- 6.While listening to a song, short press (POWER) button to switch to the next mode.Long press for Chinese/English sound notification.

### 7.USB sound card

When the device is on, insert USB cable to automatically enter USB sound card mode.When the device is off, insert USB cable to charge it.

Bluetooth devices such as mobile phones , computers , etc.

I. Connecting computers and mobile phones that have built-in Bluetooth function:

1. Turn on stereo via Bluetooth, place it in pairing mode (Blue light will blink slowly), turn on the computer or the phone's Bluetooth Device Manager and search for Bluetooth devices, click the on the Bluetooth stereo, complete the pairing and connection.

2. Open an audio or video player, you can immediately use it.

II. Connecting computers without built-in Bluetooth:

1. Please, equip Bluetooth adapter 1 with the corresponding adapter driver software.


2. Properly install the adapter driver software on the system disk c, insert the adapter into your computer USB port, open the adapter software, set the default password as 0000.

3. Turn on Bluetooth stereo, put it in a pairing mode (blue and red lights will flash alternately), open the adapter software, open the interface, click [view]-[refresh devices], the interface will be displayed in the discovered Bluetooth. Double click on the discovered Bluetooth stereo, once paired, the interface will show that the lookup service completed.

4. Click on the [Bluetooth high quality audio service], it will show the connection of the interface, then open a player such as Windows Media Player, and use it.

## USB functions (Charging Mode)

One end of the USB cable goes into the stereo, the other one- to your PC.  
**The usb port is only used for charging, no other function.**



### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Attention:

- Please place this product in dry and ventilating place, avoid rain, water, heat or strong magnetic field.
- Do not place near any heat sources, such as radiators, heaters, stoves or other heating devices. Please use a dry cloth to clean the surface, do not use volatile liquids or other organic solvents.
- Do not expose this product to too high or too low temperatures.
- Do not use this product under direct sunlight for a long time.
- Do not use this product near an open flame.
- Avoid a contact with any sharp objects, as this may cause scratches and damage.
- Do not attempt to disassemble the product because it does not contain any serviceable components.

## Package contains:

Bluetooth stereo	1
Cable	1
Instruction	1
Quality certificate	1
Warranty card	1



Refine Industrial (Asia) Limited  
Add:15/F.,Two Grand Tower,625 Nathan  
Road,kowloon,HongKong  
Tel:00852-30766658  
Fax:00852-30626606

Designed & Produced by :Refine Industrial (Asia) Limited  
Manufacturer:Shenzhen Remax Co.,Ltd.  
Add:Mingjun Industrial Park, Huarong Rd., Baoan Area,  
Shenzhen,CN  
Service Hotline:4006755178



[www.iremax.hk](http://www.iremax.hk)