

INSTRUCTIONS FOR OPERATION

SETTING THE OPERATING CONTROLS

1. This unit operates on a 3 volts battery (not included).
To prevent possible damage if the battery should leak, be sure to remove the battery when the unit is not use .
2. Store the controller away from excess heat or humidity .
3. This remote control unit is required with 24bit code combinations. To prevent possible interference from or to other remote units such as garage door openers, car alarm or security system .
4. Operation buttons on the panel of transmitter .

FAN SPEED button – fan speed (HIGH, MED, LOW)

FAN OFF button - FAN OFF

FAN TIMING button- 2 hour/ 4 hour / 8 hour



LED display


REV button – Fan reverse Warm weather/Cool weather

LIGHT button - Light ON/OFF or Dimmer

LED display

FAN SPEED button – fan speed (HIGH, MED, LOW,OFF)

FAN TIMING button- 2 hour/ 4 hour / 8 hour



REV button – Fan reverse Warm weather/Cool weather

LIGHT button - Light ON/OFF or Dimmer



Light set Switch –

For set light dimmer type

or light ON/OFF type control .

5. **Start the fan**
Press the FAN speed button .
6. **Turn off the fan :**
Press the OFF button .
7. **Light control :**
Turn the light on or off by only touching the LIGHT CONTROL button .
Keep pressing the button in excess of 0.7 second it becomes a dimmer ,
the light varies cyclically in 0.8 second .
8. **Timing set :**
2H : 2 hours later, the fan is off
4H : 4 hours later, the fan is off
8H : 8 hours later, the fan is off

GENERAL INFORMATION :

This REMOTE controller is designed to separately control your ceiling fan speed and light brightness . The Light ON/OFF button will control the light brightness ON/OFF . The LED indicator on the transmitter will light when the Function button is pressed .

INSTRUCTIONS FOR INSTALLATION AND OPERATION OF FAN SPEED CONTROLLER

1. Setting the code on your new transmitter .

Within 60 seconds of turning the AC power on, press and hold the FAN ON/OFF button for 5 seconds. The receiver will then lock in the chosen frequency. If your fan has a light it will blink twice, for fans without lights check operation using the transmitter

NOTICE :

The changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment .

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

FCC INFORMATION

The Federal Communication Commission Radio Frequency Interference Statement includes the following paragraph:

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication.

However, there is no grantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.