
Features & Functions





This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE:


The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment

MP3, CD, DVD Player Operation

- **1.** Plug the 12 Volt adaptor end of the VRFM6 Modulator into the vehicle's 12 Volt cigarette lighter socket or 12 Volt Power Outlet.
- 2. The Red LED Digital Display will light up indicating the unit has power, and on what frequency it is transmitting. 88.1 is the default.
- **3.** Insert the 3.5mm plug of the supplied audio cable into the stereo headphone jack of an MP3, CD, or DVD player. Insert the 3.5mm plug of the cable into the 3.5mm stereo jack on the underside side of the VRFM6.
- **4.** Tune your car stereo to one of the pre-set FM frequencies of the VRFM6 that is not being broadcast on by any local radio stations.

(88.1, 88.3, 88.5, 88.7, 88.9, 89.1, Supplied Audio Cable 106.7, 106.9, 107.1, 107.3, 107.5, 107.7, 107.9 MHz)

- **5.** Press the + or Pre-Set Channel Rocker Button to select the FM frequency that you have set the car stereo's tuner to.
- **6.** Press the Play Button on the player that you connected to the VRFM6.







Portable DVD Player

7. The Music/Audio will transmit from the VRFM6 to the vehicle's stereo system.

Changing the Fuse

