

Main Features

- An audio amp in the design of the JAZZ CHORUS guitar amp loved by countless guitarists.
- **Bluetooth** connectivity and a built-in lithium-ion rechargeable battery let you enjoy music anywhere.
- Use the three-band equalizer to obtain the tone you prefer.
- Input to the AUDIO IN jack can be mixed with the playback from a **Bluetooth** device (*).
- Hands-free conversation is supported.



(*) A device that can output audio via **Bluetooth**, such as a smartphone or audio player.

Panel Descriptions

[VOLUME] knob

Adjusts the overall volume.

Three-band equalizer

[TREBLE] knob

Adjusts the character of the high range.

[MIDDLE] knob

Adjusts the character of the mid-range.

[BASS] knob


Adjusts the character of the low range.

MEMO

If you want the sound to be uncolored, set each knob to the "5" position.

[Talk] button

Lets you conduct a hands-free conversation via your smartphone.
➔ See "Hands-Free Conversation."



[PAIRING] button

➔ See "Registering a Bluetooth Device (Pairing)."

Bluetooth indicator

Indicates the **Bluetooth** connection status.

Indicator	Explanation
Lit	Connected
Blinking	Connecting in progress
Rapid blinking	Pairing in progress
Unlit	Not connected

[POWER] button

Turns the power on/off.

Power indicator

Indicates the power supply status.
➔ See "Charging."

AUDIO IN jack

Sound from an audio player connected here can be played through this unit.


To adjust the volume, use the [VOLUME] knob or make adjustments on the audio player.

About the auto-off function

The power of this unit automatically turns off if nothing is connected to the AUDIO IN jack and approximately 15 minutes have elapsed without a **Bluetooth** device being connected (Auto Off function).

Charging

- * Use a standard USB AC adaptor (5 V $\overline{\text{---}}$ /over 1.8 A) for charging. Before using this unit for the first time, connect the included micro USB charging cable to the rear panel 5 V $\overline{\text{---}}$ port and charge it.



The power indicator shows the status of the power supply.


Indicator	Explanation
Lit red	Remaining battery capacity is more than half, or charging is complete
Blinking red	Remaining battery capacity is less than half
Lit orange	Charging (power is on)
Blinking orange	Charging (power is off)

Registering a Bluetooth Device (Pairing)

What is pairing?

"Pairing" is the procedure by which the **Bluetooth** device that you want to use is registered on this unit (the two devices recognize each other).

Make settings so that music data saved on the **Bluetooth** device can be played wirelessly via this unit.



MEMO

- Once a **Bluetooth** device has been paired with this unit, there is no need to perform pairing again. If you want to connect this unit with a **Bluetooth** device that has already been paired, refer to "Connecting an Already-Paired Bluetooth Device."
- The following steps are one possible example. For details, refer to the owner's manual of your **Bluetooth** device.

1. Place the **Bluetooth** device that you want to connect nearby this unit.

MEMO

If you have more than one unit of this model, power-on only the unit that you want to pair (power-off the other units).

2. Press the [POWER] button to power-on this unit.


* This unit is equipped with a protection circuit. A brief interval (a few seconds) after turning the unit on is required before it will operate normally.

3. Continue holding down the [PAIRING] button until the **Bluetooth** indicator blinks rapidly.

This unit's **Bluetooth** function turns on, and pairing begins.

4. Turn on the **Bluetooth** function of the **Bluetooth** device.

Example) In the case of iPhone



5. Select "Roland JC-01" that is shown in the **Bluetooth** device screen of your **Bluetooth** device.

When pairing succeeds, this unit's **Bluetooth** indicator is lit.

MEMO

If the **Bluetooth** device's screen asks you to enter a "Pass Key," enter "0000" (four zeros).

Connecting an Already-Paired Bluetooth Device

1. Perform steps 1, 2 of "Registering a Bluetooth Device (Pairing)."
2. Press the [PAIRING] button to turn on this unit's **Bluetooth** function. This unit's **Bluetooth** indicator blinks.
3. Turn on the **Bluetooth** function of the **Bluetooth** device. When connection succeeds, this unit's **Bluetooth** indicator is lit.

MEMO

- If connection does not succeed, select "Roland JC-01" in the **Bluetooth** device screen of the **Bluetooth** device.
- The connection is automatically ended if the **Bluetooth** device does not play for approximately 15 minutes.
- To disconnect, press the [PAIRING] button, or turn off the **Bluetooth** function of the **Bluetooth** device.

Listening to Music

1. Play back music on your **Bluetooth** device.

To adjust the volume, use the [VOLUME] knob or make adjustments on your **Bluetooth** device.

MEMO

The playback from an audio player connected to the AUDIO IN jack can be mixed with the sound of the **Bluetooth** device. To set the volume balance, make adjustments on each device.

Hands-Free Conversation

Using this unit's built-in mic and speaker, you can conduct a hands-free conversation via your smartphone.



Making a call

1. Make a call from your smartphone. To hang up, press the [Talk] button.

Receiving a call

1. When a ring tone occurs, press the [Talk] button. To hang up, press the [Talk] button once again.

Troubleshooting

Problem	Items to check	Action
Power does not turn on	Is the internal lithium-ion rechargeable battery charged?	Charge this unit.
No sound / Insufficient volume	Could the volume be turned down on this unit or on a connected device?	
Bluetooth sound is interrupted / Noise is heard	Could you be using the unit near a microwave oven or a wireless device such as a Wi-Fi router?	Move the unit as far as possible away from microwave ovens or wireless devices such as Wi-Fi routers.
This unit does not appear in the Bluetooth device list of your Bluetooth device.	Did pairing occur successfully?	Press the [PAIRING] button to begin pairing.
Can't connect via Bluetooth	Could this unit and the Bluetooth device be too far apart?	Move this unit and the Bluetooth device closer to each other.
	This unit can connect with a Bluetooth device at a maximum distance of 10 m (30 ft).	
	If this unit is visible as a device in the Bluetooth settings of the Bluetooth device	Delete the device registration for this unit, and then perform pairing once again.
	If this unit is not visible as a device	Turn the Bluetooth function of the Bluetooth device off and then on again; then begin pairing from this unit to pair the devices once again.

Main Specifications

Roland JC-01: Bluetooth Audio Speaker

Speaker	5 cm (2 inches) x 2 Passive radiator	
Bluetooth	Bluetooth technology	Bluetooth Ver 3.0
	Transmitting Power	Specification Power Class 2 (Line of sight range 10 m (30 ft))
	Profile Support	A2DP, HFP
Connectors	Codec	SBC (Support to the content protection of the SCMS-T method)
	AUDIO IN jack (Stereo miniature phone type) (*) 5 V $\overline{\text{---}}$ port (USB micro-B type) *1: This product is not designed to connect a guitar directly.	
Power Supply	Lithium-ion rechargeable battery Supplied from the 5 V $\overline{\text{---}}$ port	
Current Draw	Max. 1.8 A (5 V $\overline{\text{---}}$)	
Continuous playback time using the battery	Approx. 7 hours (Audio playback of the Bluetooth connection) * These figures will vary depending on the actual conditions of use.	
Dimensions	187 (W) x 69 (D) x 97 (H) mm 7-3/8 (W) x 2-3/4 (D) x 3-7/8 (H) inches	
Weight	650 g/1 lbs 7 oz	
Accessories	Owner's manual	
	Leaflet "USING THE UNIT SAFELY"	
	Leaflet "Attaching the Ferrite Core"	
	Micro USB cable for charging (*2)	
	Ferrite core x 2	
	*2: Use a standard USB AC adaptor (5 V $\overline{\text{---}}$ /over 1.8 A) for charging.	

* In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS. About the WARNING and CAUTION Labels. ALWAYS OBSERVE THE FOLLOWING. About the auto-off function. About the power of this unit.

警告 注意 注意 注意. 火災・感電・傷害を防止するには. 小さな部品はお子様の手が届かないところに保管. 電池の取り扱いについて.

ANWEISUNGEN ZUR VERMEIDUNG VON FEUER, ELEKTROSCHLAG ODER PERSONEN-SCHADEN. ACHTUNG. Die Gerät bei unnormalen Verhalten oder Fehlfunktion ausschalten. Die Gerät nicht unter folgenden Umständen verwenden oder lagern.

CONSIGNES À RESPECTER POUR ÉVITER TOUT RISQUE DE BRÛLURE, D'ÉLECTROCUTION, D'INCENDIE ET DE LÉSIONS. ATTENTION. Ne pas laisser l'appareil en fonctionnement.

ATTENTION. Ne pas laisser l'appareil en fonctionnement. Ne pas laisser l'appareil en fonctionnement. Ne pas laisser l'appareil en fonctionnement.

ATTENTION. Ne pas laisser l'appareil en fonctionnement. Ne pas laisser l'appareil en fonctionnement. Ne pas laisser l'appareil en fonctionnement.

ISTRUZIONI PER LA PREVENZIONE DI INCENDI, SCOSSE ELETTRICHE O LESIONI PERSONALI. ATTENZIONE. Evitare di toccare la batteria. Precauzioni aggiuntive. Posizionamento. Avvertenza circa le emissioni di radiazione radio.

INSTRUCCIONES PARA LA PREVENCIÓN DE INCENDIOS, DESCARGAS ELÉCTRICAS O LESIONES PERSONALES. PRECAUCIÓN. Evitar tocar la batería. Precauciones adicionales. Posicionamiento. Advertencia sobre las emisiones de radiación de radio.

INSTRUÇÕES TER PREVENÇÃO DE INCÊNDIOS, CHOQUES ELÉTRICOS OU FERIMENTOS EM PESSOAS. CUIDADO. Evitar tocar a bateria. Precauções adicionais. Posicionamento. Aviso sobre as emissões de radiação de rádio.

INSTRUCTIES TER VERMIDING VAN BRAND, ELEKTROSCHEKEN OF VERWONDINGEN VAN PERSONEN. WAARSCHUWING. Het apparaat veilig gebruiken.

Waarschuwing. Het apparaat veilig gebruiken. Het apparaat veilig gebruiken. Het apparaat veilig gebruiken.

Opgelet. Het apparaat veilig gebruiken. Het apparaat veilig gebruiken. Het apparaat veilig gebruiken.

