

Package Contents

- Rosewill K10 Wireless Keyboard
- User Manual

System Requirements

- Mac OS v10.4 or later
- Devices equipped with Bluetooth transmission function
- 2 x AAA Batteries (not included)
- FCC ID:W6R-K10

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction



Technical Support Information

techsupport@rosewill.com 1-800-575-9885
Please register your product at www.rosewill.com
for complete warranty information and support for your product.





K10_A



K10

Thank you for purchasing a Rosewill wireless keyboard.
Please read the instruction manual before use and retain for future reference.

Product Overview



Instructions

1. Install 2 x AAA alkaline batteries




2. Turn on your K10 Wireless Keyboard.

The power indicator light will turn red for ~3 seconds, then turn off.



3. To assign a Bluetooth device, press and hold one of the keyboard's Bluetooth buttons for ~3 seconds until indicator starts flashing. You can assign up to 4 Bluetooth devices.



1

4. On the host device, look for "Rosewill K10" then connect to pair. The indicator light will stop blinking once pairing is successful.
5. To toggle between connected Bluetooth devices, press Bluetooth #1 through #4 buttons.
6. The power indicator will flash when battery is low. Please be ready to renew your battery.

Specifications

Keyboard Layout	US
Interface	Bluetooth Wireless
Switch Type	Scissor Switch
Weight	1.78 lb (810 g)
Dimensions (L x W x H)	17.3 x 5.03 x 0.66 in (440.1 x 127.7 x 16.7 mm)
Compatibility	iOS and Mac OS Devices
Estimated Working Hours	720 hrs

Operations

	Working Mode	Standby Mode
Inactivity	N/A	After 10 minutes
Power Consumption	3.0 mA	60 µA

Function Keys

	Decrease or increase brightness of the Mac display
	Open Mission Control for a comprehensive view of what's running on your Mac, including Dashboard, Spaces and all open windows
	Open Launchpad to instantly see all of the applications on your Mac. Click an application to open it
	Rewind or go to the previous song, movie or slideshow
	Play or pause songs, movies or slideshows
	Fast-forward or go to the next song, movie or slideshow
	Mute the sound coming from the speakers or headphone port on your Mac
	Decrease or increase the volume of sound coming from the speakers or headphone port on your Mac
	Power button
	4 multi-sync devices