

RoWrite Quick Start Guide



If anything is missing immediately contact the place of purchase



Caring For Your RoWrite

To clean use a slightly damp nonabrasive sponge, or cotton cloth. Avoid getting wet or submersing in water. Keep away from open flames and excessive heat. Notepad guideposts are magnets – it is unlikely they will break off, but dispose immediately if they do.


See RoWrite User and Warranty Guide for more precautions.

RoWrite Writing Area And Pads



The writing area for RoWrite is A5. Pen strokes within the guide marks will be captured. Generic A5 and regular sized paper can be used, but is not recommended. RoWrite notepads are designed with two guide holes and their thickness is optimized to capture every pen stroke.

RoWrite Buttons And LED



Power Button: Press once to turn On and to wake from Sleep Mode. When On, press once to turn Off.

Button A: Data Transmission: Press to send internally saved Pages to the RoWrite App on a paired device.

Button B: Create New Page: Press to have RoWrite place the next strokes on a new page. If you're taking notes and press B you can merge the Pages later in the App.

LED Color	Meaning
Red LED Flickers	Battery Low, Needs Charging
Red LED On (when charging)	RoWrite is Charging
Green LED On (when charging)	RoWrite Charged
Blue LED Flickers	Bluetooth Device Not Paired
Blue LED Flickers Rapidly	Bluetooth Device Pairing
Blue LED On	Bluetooth Device Paired
Green LED On	Pen Strokes Recording
Green LED Flickers Rapidly	Button A pressed, sending Pages

Lightly press the pen to the paper and the LED light will turn green. If it doesn't, check if the pen battery is installed and Rowrite is charged. If the LED still doesn't turn green, change the Pen battery.

Installing The RoWrite App

The RoWrite App digitally captures what is created on paper so you can edit and share with coworkers, friends, and family.

To install, scan the QR Codes below or go to the App or Google Play store.







Google Play™

Pairing RoWrite To Your Mobile Device

Turn RoWrite and the mobile device's Bluetooth® on. In RoWrite App's main screen touch the gear icon in the upper left. Touch "RoWrite Device" and see below.







- 1 If a RY# is highlighted, press "Connect". If there are more than 1 RY#s listed check the back of your RoWrite.
- 2 No RY # and devices are on: Press the bar code icon in the upper right for the Pair Device screen. Turn your RoWrite over and position the bar code in the rectangle to pair device.

RoWrite App Main Screen



٥	Set Profile, Pair a Device, See Battery Level, Check App Version, Set Writing Instrument Defaults, Watch Tutorials, Provide Feedback, Shop On Royole Website
\bigcirc	Sync Pages - Like RoWrite Button A
•••	Rename, Share/Export, and Delete the Page
•	Create New Page - Like RoWrite Button B
Page Thumbnails	Digitized copies of RoWrite notes or sketches
Sung To Manual James To Manual	Press and hold a Page image to merge, move, and delete Pages.
Page (1) Page (2)	Press a Page image to open it and then edit, share/export, or delete.

Editing With RoWrite App

If a device with the RoWrite App is paired before you write or sketch, you can edit in real time. If a device was not paired before starting you can edit after Pages are sent to the App.

To choose a Color press the Color circle.



To select a writing instrument press on an image. You can also change stroke thickness and opacity.























