


The magic is in the app.



TO GET STARTED, INSERT THE RYLO BATTERY.
CONNECT THE SYNC CABLE FROM RYLO TO YOUR PHONE.

[RYLO.COM/START](https://rylo.com/start)



POWER ON RYLO

HOLD THE TOP BUTTON TO POWER ON & OFF



PROTECT LENSES

KEEP RYLO IN POUCH WHEN NOT IN USE




DO NOT DROP RYLO

OR SUBJECT TO SUDDEN FORCE




STOP USE IF OVERHEATING

OR YOU SEE ABNORMAL BEHAVIOR



CHANGE RECORDING MODES

PRESS MODE BUTTON REPEATEDLY



ACCESS BATTERY & STORAGE

PRESS RELEASE BUTTON ON BOTTOM



DO NOT EXPOSE TO WATER

OR EXTREME TEMPERATURE RANGES



STORE IN A SAFE PLACE

AS STATED IN THE ONLINE USER GUIDE

[RYLO.COM/LEGAL](https://rylo.com/legal)



English

Important Safety, Compliance, and Warranty Information

By using this product, you acknowledge that you have read and agree to Rylo's Terms of Service and Privacy Policy (rylo.com/legal). For more information about using Rylo, visit rylo.com/start.

WARNING: This product comes with a lithium-ion battery. Failure to take the following precautions can result in serious injury, death, or damage from electric shock, chemical burn, fire, or explosion. Keep batteries out of reach of children. Do not expose the battery to water or any other liquids. Do not short circuit the terminals of the battery. Do not disassemble the battery. Do not put the battery near a flame or flammable substances. Do not dispose of the battery in fire. Do not store the battery at temperatures above 60°C. Do not puncture, crush, bend, or otherwise deform the battery. Do not place battery in microwave or high-pressure container. Do not put the battery in pockets or containers with other objects which may result in short circuit, puncture, or other damage. Do not use third-party charging devices not manufactured by Rylo Inc.

WARNING: Failure to take the following precautions can result in serious injury or death from electric shock, chemical burn, fire, or explosion. For your safety, please take the following precautions when using Rylo and Rylo accessories. Do not drop the device, subject to sudden force, or expose to water. Take care to protect your lens from contact with other objects or surfaces. Contact may result in scratches which will reduce optical performance. Use only accessories (i.e. batteries, mounts, cases, cables, chargers) manufactured by Rylo Inc. Stop use of the device if you notice anything abnormal such as overheating or smoke. In the event that internal components are exposed after drop or damage, do not touch internal components or circuitry. Do not attempt repair of the device yourself. Comply with all local laws and regulations, including laws applicable to privacy or video/audio recording. Be aware of your surroundings, and only use the device when it is safe to do so. Abide by

operating, storage, and charging temperature ranges as stated in the user guide. Keep out of the reach of children.

NOTICE: Backup or preserve all content and files. Erased, deleted, lost, or stolen data cannot be restored. Data charges may be incurred when uploading, transferring, or backing up files or content. Rylo Inc. is not responsible for such charges.

LIMITED WARRANTY - SUMMARY Rylo Inc. warrants to the original retail purchaser that, when used in accordance with our product guidelines, Rylo will be free from material defects in materials and workmanship under normal use for a period of one (1) year from the original date of purchase (the “Warranty Period”). Our product guidelines include information contained in the user manual, online instructions, technical specifications and written communications regarding use or service of Rylo, each as provided by us to you. Warranty protections are in addition to rights provided under local consumer law and may vary among countries. See fully warranty information at rylo.com/legal to know your consumer rights and the additional protections provided by this product warranty.

For European Union Consumers Only: Rylo Inc. warrants to the original retail purchaser that, when used in accordance with our product guidelines, Rylo will be free from material defects in materials and workmanship under normal use for a period of two (2) years from the original date of purchase (the “Warranty Period”). Our product guidelines include information contained in the user manual, online instructions, technical specifications and written communications regarding use or service of Rylo, each as provided by us to you. Warranty protections are in addition to rights provided under local consumer law and may vary among countries. See fully warranty information at rylo.com/legal to know your consumer rights and the additional protections provided by this product warranty.

For Australia/New Zealand Consumers Only: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

FCC ID: 2AK270101B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected; Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

RF exposure warning: This equipment complies with the FCC RF exposure limits set forth for an uncontrolled environment. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

Warning: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate this equipment.

Manufacturer: Rylo Inc.

Address: PO BOX 77234, San Francisco, CA 94107, USA.

Model: A0101

Hardware Version: M02

Software Version: 238

Operating Frequency Range: 2400- 2483.5 MHz

Max Output Power: <5dBm

This product is Listed by UL. Representative samples of this product have been evaluated by UL and meet applicable safety standards.