

Limited 1 Year Warranty

iHome Products, a division of SDI Technologies Inc., (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one (1) year from the date of original purchase. Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by Customer Service.

If service is required, please call Customer Service at 1-800-288-2792 to obtain a Return Authorization Number and shipping instructions.

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CDs or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI product.

© 2015 SDI Technologies, Inc. All rights reserved.
Questions? Visit www.ihome.com
or call 1-800-288-2792 Toll Free

iBT82-120715A[EN]

Printed in China

iHome



instruction manual

Model: iBT82 Waterproof Rechargeable Bluetooth Speaker with Speakerphone



CHARGE
BEFORE
USE



Consumer Product Safety Guide IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

- Water and Moisture** – DO NOT immerse unit in water. Make sure the seal and surrounding surfaces are completely dry before opening seal to prevent moisture from damaging the internal electronics. Keep seal free of dirt, sand, or other objects that can interfere with proper sealing. If for any reason the seal is not making a tight seal, water may enter the unit.
- Ventilation** – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings.
- Heat** – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
- Power Sources** – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
- Cleaning** – The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.
- Objects and Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
- Attachments** – Do not use attachments not recommended by the product manufacturer.
- Lightning and Power Surge Protection** – Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
- Overloading** – Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- Damage Requiring Service** – The unit should be serviced by qualified service personnel when:
 - the power supply cable or plug has been damaged.
 - objects have fallen into or liquid has been spilled into the enclosure.
 - the unit has been exposed to rain.
 - the unit has been dropped or the enclosure damaged.
 - the unit exhibits a marked change in performance or does not operate normally.
- Periods of Nonuse** – If the unit is to be left unused for an extended period of time, such as a month or longer, fully charge the unit before storing.
- Servicing** – The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

Questions? Visit www.ihome.com
or call 1-800-288-2792 Toll Free

FCC Information

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device complies with RSS-247 of the IC Rules; Operation is subject to the following two conditions:

- This device may not cause interference and
- This device must accept any interference received, including interference that may cause undesired operation

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio RSS-247. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

Declaration ID D025615

Introduction

Thank you for purchasing the iHome iBT82. This product is designed to provide high quality wireless sound for your Bluetooth audio device. Is shockproof, waterproof and dustproof, and should provide long life even in tough conditions.

This instruction booklet explains the basic operation and care of the unit. Please read them carefully and keep for future reference.


IMPORTANT INFORMATION ABOUT WATERPROOF OPERATION

For proper waterproof operation, make sure the waterproof cover on the left side of the unit is completely flush with the unit by pressing along the entire edge of the cover until it is completely and securely in place.


- The unit is IP67 waterproof rated, meaning it is immersible for up to 30 minutes at a depth of 1 meter (3 feet). It will typically withstand rain, snow and being submersed in shallow water. Longer duration or deeper immersion that exceeds the tested limits may cause product failure and void the warranty.
- DO NOT immerse the unit in water for extended periods.
- DO NOT immerse the unit in water deeper than 1 meter (about 3 feet).
- Make sure cover and surrounding surfaces are completely dry before opening cover to prevent moisture from damaging the internal electronics.
- Keep rubber cover free of dirt, sand, or other objects that can interfere with proper sealing. If for any reason the waterproof cover is not making a tight waterproof seal water may enter the unit.
- Rinse with tap water after immersion in salt water or swimming pool.
- DO NOT clean unit with oily soaps or use chemicals or solvents. Clean with damp cloth.

What's Included


- iBT82 speaker
- micro USB charging cable
- carry strap



iBT82 speaker



micro USB charging cable




carry strap

Meet Your iBT82


Upper Left Side

Power Button Bluetooth Pairing Button




Upper Right Side

+ Volume Button - Volume Button




Lower Left Side




USB Charging Port

Reset Button (insert paperclip to reset unit)

Lower Right Side



Play/Pause Button Speakerphone Button




Waterproof Cover

iBT82

Top

TIP: On some iOS (Apple) devices, you can view the iBT82 battery status on your device's screen. When device is paired and connected, look for a vertical battery icon next to the Bluetooth icon on the upper right corner of the device's screen.

Status indicator LED



Microphone


Status indicator	Status
Solid red LED	Unit is charging
Flashing red LED	Unit needs charging
Solid blue LED	Active Bluetooth connection
Quickly flashing blue LED	Unit is attempting to pair with Bluetooth device
Slowly flashing blue LED	Unit is attempting to auto link to already paired Bluetooth device

Using the iBT82

Getting Started: Carry Strap


The iBT82 comes with a carry strap for easy carrying or attaching to a backpack, shower head, etc.

To attach the carry strap, form a small loop in one end of the strap. Insert this loop through the channel on top of the unit, then pull the loop back through the larger loop formed in the carry strap to tighten.



Getting Started: Charging the Unit


Charge unit before use. For first time charge, charge for at least 4 hours. Pull back waterproof seal and connect the included micro USB cable to the USB Charging Port on the left side of the unit and connect the other standard USB plug to a computer, USB AC adaptor (not included) or other USB power source. The status indicator glows solid red while charging and turns off once charged.



Pairing Your Device

Pairing is the setup process to introduce your Bluetooth-capable device to the iBT82. Once your device is paired, the iBT82 can recognize it and you can play your audio through it.

- Make sure your Bluetooth device is fully charged. Turn on your Bluetooth device and make it "discoverable" by turning on Bluetooth mode (check in Options or Settings).
- Press and hold the **Power Button** for 2 seconds to turn on the iBT82. The first time the unit is powered on, it will enter auto-pairing mode and attempt to connect to a Bluetooth device. Otherwise, follow step 3 to begin pairing.
- Press and hold the **Bluetooth Pairing Button** for 2 seconds. The unit will beep twice and the status indicator LED will flash blue, indicating the unit is in pairing mode.
- "iHome iBT82" should appear in your device's Bluetooth menu. If "Not Paired", "Not Connected" or similar message appears, select "iHome iBT82" to connect it. If prompted for a passcode, enter "1234" on your device's keypad.



- Once pairing is successful, a tone will sound and the Bluetooth indicator light will glow solid blue, indicating the iBT82 is ready to play music. There should also be an indication on your device. If no device is successfully paired within 3 minutes the iBT82 will default to previous mode. Once the iBT82 is paired to a device, it will attempt to autolink when the device is within range (about 30 feet).

Using the iBT82

Pairing with a Different Device

When you power ON the speaker, it will automatically link with the previously paired Bluetooth device if that device is still within range (about 30 feet). To pair with a different device follow steps 1 - 4 under "Pairing Your Device" on previous page.

Playing Audio Via Bluetooth

- Press and hold the **Power Button** for 2 seconds to turn on the unit. The status indicator will glow solid blue when a linked device is in range and detected. You can then listen to audio streamed wirelessly from your paired Bluetooth device.
- Press the **Play/Pause Button** to play audio from your device. Press again to pause play and once more to resume play. When Bluetooth audio is active, the status indicator will glow solid blue.
- Use menu and track controls on your Bluetooth device to navigate tracks.
- Press the **+ Button** to adjust the iBT82 volume. The LED will flash 3X when minimum or maximum volume is reached. You can also adjust volume on your device.
- When done listening, press the **Power Button** to turn the unit OFF. Remember to turn off your device, too.

Speakerphone Operation

NOTE: The unit must be powered and linked to a Bluetooth phone to receive a call.

- When a call is received, playing music is muted to hear the ring tone. Press the **Speakerphone Button** to answer the call, or press and hold it to ignore the call. Press the **Speakerphone Button** to switch between incoming calls.
- When a call is completed, press and hold the **Speakerphone Button** to end the call and resume previous function.

Troubleshooting

Unit doesn't respond (no power)

- Check that unit is fully charged.
- Make sure your device is properly paired with the iBT82.
- Make sure the Power is ON.

Unit doesn't respond (locked up or frozen)

If the unit does not respond, insert the end of a paperclip or similar into the Reset Button located under the waterproof cover to reset the unit.

Trouble pairing device/computer with iBT82

Bluetooth implementation varies depending on your device's hardware and operating system. Please see our website for updates on pairing.

- Make sure you have the latest firmware for your device.
- Make sure your device is working properly. Check your device's manual for details on Bluetooth pairing and linking.
- When you power ON the speaker, it will automatically link with the last previously paired Bluetooth device if the device is still within range (approx. 30 feet). To pair with a different device press and hold the **Bluetooth Pairing Button** for 2-3 seconds.

For further information and to see the latest instructions, visit www.ihome.com/support