


iDM5 IB\_US  
Size: 153mm x 120mm (12 pages)  
Printing color: Black  
Mat'l: 90gsm book paper  
Feb. 15, 12.

P1

# iHome®

Model: iDM5  
Bluetooth audio system  
and wireless keyboard  
with speakerphone



Questions? Visit [www.ihomeaudio.com](http://www.ihomeaudio.com)

## Introduction

Thank you for purchasing this unit. This product is designed to provide high quality wireless audio and keyboard input for your iPad, iPhone, iPod, tablet, computer, PDA or other Bluetooth audio device. It also provides handsfree speakerphone functionality.

Along with the included Quick Bluetooth Connection Guide, this instruction booklet explains the basic operation and care of the unit. Please read them carefully and keep for future reference.

## Maintenance

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood or lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as Benzene, thinner or similar materials can damage the surface of the unit.

## Table of Contents

Meet Your Unit /Setup .....	1-2
Special Keys / Functions .....	3
Charging Devices with the USB Ports .....	4
Using Bluetooth: Pairing Your Device.....	5
Playing Audio Via Bluetooth / Using the Speakerphone.....	6
Playing Audio Via Aux / Troubleshooting .....	7
Consumer Product Safety Guide .....	8
Warranty Information .....	9

Built-in Bluetooth (Version 2.1 + EDR, Class 2) system with remote "pairing" of cell phones to the Unit (supports A2DP, AVRCP, HFP, HSP profiles)  
HID Protocol Support: iPad/iPad2, iPhone 3GS or later with the latest iOS and Android platform 3.0 or above.



is a registered trademark of SRS Labs, Inc. TruBass technology is incorporated under license from SRS Labs, Inc.

SRS WOW®, which features TruBass®, significantly improves the playback quality of audio, delivering a dynamic 3D entertainment experience with deep, rich bass and high frequency clarity for crisp detail.

## FCC Information

FCC ID: EMOIDM5 IC: 986B-IDM5

### FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This Device complies with RSS-210 of the IC Rules; Operation is subject to the following two conditions:

- (1) This device may not cause interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.


**QDID:B019111**

## Meet Your Unit

### Top/Front



### Left Side



### Rear




Note:  This switch position for firmware update only (will not charge). Visit [www.ihomeaudio.com/support](http://www.ihomeaudio.com/support) for details

## Meet Your Unit


### Included

- iDM5 system (keyboard)
- 100V-240V universal AC adaptor




### Setup

Attach included power adaptor to working power outlet and the other end to the power jack on the rear of the unit.



### Resetting the Unit

If your unit becomes locked up or otherwise unresponsive, it may require a reset to default factory settings. To reset unit, insert a paper clip or similar into the reset port on the back of the unit and hold briefly. Doing so will lose any paired device information and you must re-pair your devices.









## Special keys/functions

Press to toggle iPad/iPhone on-screen keyboard control on/off.


iPad / iPhone  
keyboard

**Note:** This key is specific to Apple iOS devices, and will have no effect with other devices.

Previous Track	Play/Pause	Next Track	Mute Audio	Lower Volume	Raise Volume
 F7	 F8	 F9	 F10	 F11	 F12

## Charging Devices with the USB Ports


1. The unit can charge two USB devices at once using the two USB charging ports on the left side of the unit. A USB cable is not included.
2. To charge a USB device, connect the standard end of the USB cable to a USB port and the other end to the device you wish to charge.
3. Monitor your device's battery indicator to confirm the device is charging. If the device is NOT charging, try moving the **USB Mode Switch** to a different position (A or B), then unplug the device from the USB port and reconnect it.



## Using Bluetooth: Pairing Your Device

NOTE: See the iDM5 Bluetooth Connection Guide for complete pairing details.

1. Move the **Bluetooth/Aux-in Switch** on the lower right front of keyboard to the Bluetooth position (left).



2. Press and release the **Power Button** to turn on the unit (the **Power** light will turn blue).
3. Turn on Bluetooth capability on your device and make it discoverable (see your device's instructions to add or setup a Bluetooth device).
4. *Press and hold* the **Bluetooth Button** on the unit until it flashes blue and the unit beeps twice to indicate pairing attempt. The blue light will flash while the unit attempts to pair.
5. "iDM5" should appear in your device's list of Bluetooth devices; its status display may indicate "not connected". Select iDM5 to connect. If your device asks for a password, enter **1234** on the keyboard of your device. If no device is paired within 2 minutes, the **Power Button** will change from blue to red. If this occurs, retry steps 2-4.
6. Once paired with a device, the blue **Bluetooth** light will glow steadily. There should be an indication on your device that pairing is complete. On some devices, you must then select "use as a stereo audio device" or similar on the device's Bluetooth menu. Once paired, your device should link to the iDM5 whenever within range. You can now use the keyboard with the active app on your device, play Bluetooth audio and use as a speakerphone.



## Playing Audio Via Bluetooth

1. Move the **Bluetooth/Aux-in Switch** to the Bluetooth position to listen to audio streamed wirelessly from your paired iPad, iPhone, iPod or other Bluetooth device.
2. Press and release the **⏻ Button** to turn on the unit. The blue **⌘** light will flash as the unit searches for a previously paired device, and then turn solid blue when a previously paired device is detected.
3. Press and release the **▶|| Key/Button** to play or pause audio from your Bluetooth device.  
**NOTE:** Play/Pause only works in Bluetooth mode. It does not control aux line-in devices.
4. Use the **◀ or ▶) Keys/Buttons** to adjust volume.
5. When done listening, press the **⏻ Button** to turn the unit off.

## Using the Speakerphone

1. Move the **Bluetooth/Aux-in Switch** to the Bluetooth position to use the speakers as a speakerphone for a linked Bluetooth-capable phone during an incoming or active call. Playing audio is muted during a speakerphone call.
2. Press and release the **⏻ Button** to turn on the unit.
3. Use the **◀ or ▶) Keys/Buttons** to adjust volume. You may wish to adjust the volume on your audio device, too.
4. When a call is received, playing music is muted to hear the ring tone. Press the green **⌘ Button** to answer the call, or press the red **⏻ Button** to ignore it.
5. When the call is completed, press the **⏻ Button** or **⌘ Button** to end the call and resume previous function.

## Playing Audio via Aux

1. Move the **Bluetooth/Aux Switch** to the Aux position to listen to audio via aux line-in.
2. Connect a standard 3.5mm stereo audio cable (not included) to the headphone or line-out jack on your audio device and plug the other end into the aux-in jack located on the back of the keyboard.
3. Press and release the **⏻ Button** to turn on the unit.
4. Use the **◀ or ▶) Keys/Buttons** to adjust volume. You may wish to adjust the volume on your audio device, too.
5. When done listening, press and release the **⏻ Button** to turn the unit off. Remember to turn off your audio device, too.

## Troubleshooting

### Unit doesn't respond (no power)

- Check that all connections are correct and properly plugged in. Make sure your device is properly paired with the iDM5.

### Keyboard doesn't respond (when I type, nothing appears on my tablet/device)

- Touch the tablet/device's screen to activate the app or browser you wish to input text to. When the cursor appears, you should be able to input text using the iDM5 keyboard

### The on-screen keyboard on my iPad/iPhone/iPod isn't accessible

- Press the **iPad/iPhone keyboard key** on unit to toggle the iPad/iPhone/iPod on-screen keyboard on and off.

### Trouble pairing device with iDM5

Bluetooth implementation varies depending on your computer's hardware and operating system.

- Make sure you have the latest firmware for your iPad, iPhone or iPod (update via iTunes if needed).
- Make sure your device is working properly. Check your device's manual for details on Bluetooth pairing and linking.

For further information, visit [www.ihomeaudio.com/support](http://www.ihomeaudio.com/support)

## Consumer Product Safety Guide

# IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. **Water and Moisture** – The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
2. **Ventilation** – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
3. **Heat** – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
4. **Power Sources** – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
5. **Power-Cable Protection** – Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.
6. **Cleaning** – The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.
7. **Objects and Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
8. **Attachments** – Do not use attachments not recommended by the product manufacturer.
9. **Lightning and Power Surge Protection** – Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
10. **Overloading** – Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
11. **Damage Requiring Service** – The unit should be serviced by qualified service personnel when:
  - A. the power supply cable or plug has been damaged.
  - B. objects have fallen into or liquid has been spilled into the enclosure.
  - C. the unit has been exposed to rain.
  - D. the unit has been dropped or the enclosure damaged.
  - E. the unit exhibits a marked change in performance or does not operate normally.
12. **Periods of Nonuse** – If the unit is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or corrosion.
13. **Servicing** – The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

Questions? Visit [www.homeaudio.com](http://www.homeaudio.com)  
or call 1-800-288-2792 Toll Free

## Limited 1 Year Warranty

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI Technologies), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one (1) year from the date of original purchase. Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI Technologies will repair or, at its discretion, replace this product without charge (except for a \$20.00 charge for handling, packing, return UPS/postage, and insurance). This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center listed below. The product must include proof of purchase, including date of purchase. The fee for service without proof of purchase is \$50.00.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box.
2. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period.
3. Enclose a check or money order payable to the order of SDI Technologies, for the sum of \$20.00 (\$50.00 without proof of purchase).
4. Send the unit prepaid and insured, to the Factory Service Center listed below.

### Consumer Repair Department

SDI Technologies Inc.  
1330 Goodyear Drive  
El Paso, TX 79936-6420

### Disclaimer of Warranty

**NOTE:** This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI Technologies or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI Technologies product.

© 2012 SDI Technologies, Inc. All rights reserved

Questions? Visit [www.ihomeaudio.com](http://www.ihomeaudio.com) or call 1-800-288-2792 Toll Free.

iDM5-020912B

Printed in China