SEECODE COLLTE

Rm.308, 1st Woorim E-biz Center, 170-5, Guro-dong, Guro-gu, Seoul, Korea A/S & CALL CENTER: +82-2-853-3194-5



wwww.seecode.com

Bluetooth Headset



| Contents |

In the Package

Part Description	4
How to use	
Charging	5
Power on / off	6
Pairing	6
Call usage	
Making a call	7
Answering a call	. 8
Ending a call	8
Reject a call	8
Volume Control	8
Transfering a Call	9
Appendix	
Precautions for safety	10
Specification & Characteristic	11
Declaration of confirmation	12
Limited Warranty	13



The SHM-612 Bluetooth* Headset is a light weight wireless Headset utilizing Bluetooth* technology. This product can be used as an audio accessory for devices supporting either the Headset or Handsfree Bluetooth* Profiles. Bluetooth* is a trademark owned by Bluetooth* SIG, Inc. and is used by the manufacturer under its license term.

In the Package



Part Description



How to use

Charging |

SHM-612 is built-in rechargeable battery. Before using SHM-612, you need to charge it fully.

1. Plug the charger into the Charging Inlet of headset.

While charging, the LED indicator will show a solid blue light.



2. The charging time is less than 2 hours.

When the charging is complete, the LED indicator will turn off.



Do not use other charger except the supplied charger. It may cause a trouble and damage.

Power on/off

	Action	Sound	LED Indicator
Power on	Press and hold the MULTI BUTTON for more than 2 seconds.	Power on with 4 times beep sound.	LED indicator will flash every 3 sconds
Power off	Press and hold the MULTI BUTTON for more than 5 seconds.	Power off with 3 times beep sound.	LED indicator will turn off. Blue light remains on until MULTI BUTTON is released.

Pairing

- AS the headset turned off, then press and hold the MULTI BUITTON for more than 7 seconds
- 2. You will hear a melody announcing pairable state.
- While the pairable state, the LED indicator will flash every 0.3 second.
- 4. Follow the user's manual of your handset.
- 5. Select SHM-612 from the list of device on your handset.
- When asked for the Pass/Pin code during procedure, enter '0000'(4 Zeros).

7. If the pairing is completed successfully, you will hear a beep. And LED indicator will flash every 3 seconds.

Call usage

Making a call

1. Making a call

When you make a call from your handset, the call will be automatically transferred to the headset. If not automatically transferred, you can transfer the call manually by breifly pressing the MULTI BUTTON.

2. Last number redialing

Press and hold MULTI BUTTON for 2 seconds.

3. Voice dialing

Briefly press MULTI BUTTON and follow your handset.



This is available only when your handset supports the voice dialing function.

Answering a call

During ringing, briefly press MULTI BUTTON.

Ending a call

Briefly press MULTI BUTTON or press end button on your handset.

Reject a call

During ringing, press and hold MULTI BUTTON for more than 2 seconds.



This is available only when your headset is connected with your handset through HANDSFREE profile.

Volume Control

Press VOLUME BUTTON [+] or [-] on the headset side to increse or decrease the speaker volume.

Transfering a Call

From Handset to Headset: Briefly press MULTI BUTTON.

From Headset to Handset: Press VOLUME [+] or [-] BUTTON for more than 2 seconds.



Pay attention not to press MULTI BUTTON for too long time, then headset will turn off.

BLUETOOTH HEADSET USER GUIDE BLUETOOTH HEADSET USER GUIDE

Appendix

Precautions for safety

- Keep a place of safety with turning off headset.
- ① Do not place the headset under over 50 °C high temperature or a direct ray of light, It may cause to lower of performance and reduce battery life.
- Keep the accessory with headset away from humidity & dust.
- Do not drop the headset from high place.
- Do not touch headset and plug with a wet hand.
- Do not touch headset and plug with a wet hand.
- Pay attention that a baby or pet do not be sucking or biting headset.
- Do not modify, repair, take a part at discretion.
- Turn off at the place of banning Headset using
- If possible, do not use while driving.
- Keep the headset away from micro-wave or wireless LAN.
 It may cause a noise.

Specification & Characteristic

Bluetooth ^o version	Bluetooth® Ver2.0 Compatible	
Supported Bluetooth® profile	Headset/Handsfree Profile	
Carrier frequency	2.402 ~ 2.480 GHz	
Operating range	Up to 10m	
Dimmension(mm)	50(L) x 18(W) x 12(H)	
Weight	10.3g	
Operating temperature	-10 °C ~ +60 °C	
Talking Time	Up to 5 hours	
Stand-by time	Up to 120 hours	
Charging time	less than 2 hours	

-10-

Declaration of confirmation

FCC NOTICE TO USERS

This device complies with part 15 of the ECC rules.

Operations is subject to the following two conditions:

- 1. This device may not cause harmful interference and
- This device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device permitted, Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.





This product was produced under strict quality management and inspection.

Free of charge service

- All defective units within the applicable Warranty period/s will be repaired or replaced in the case those faulty goods were handled normally.
- 2. if you use it commercially, the warranty period/s will be reduced half.

Free of charge Warranty shall not apply to

- Defects or damage resulting from use of the unit in other than its normal and intended manner, eg, in excess of their maximum specifications or operating instructions.
- Defects or damage from misuse, accident, neglect, improper testing, installation, alteration or modification of any kind, or spillage of food or liquid.
- 3. Faulty is caused by a nature Disaster.
- 4. The capacity of expendables is exhausted.

Product name		Bluetooth headset	
Model number		SHM-612	
Warrany period		lyear	
Purchases date			
Outlet the unit was puchased			
Tel			
	Address		
Customer	Name		
	Tel		

