
Bluetooth Professional

PTT FULL KIT

User Manual





| Contents |

In the package	5
Part description	6
How to use Bluetooth PTT Full Kit	
Charging	8
Power on / off	9
Pairing	10
Use as walkie-talkie mode	11
oco do i nono mode(i i i i i i i i i	11
When any device works abnormally	12
How to use Bluetooth Headset in separate	
Pairing	13
Making a call	14
Answering a call	14
Ending a call	14
Rejecting a call	15
Volume control	15
Transferring a call	15
Appendix	
Precautions for safety	16
Specifications	17
Declaration of confirmation	18
Warranty	19

BLUETOOTH PTT USER GUIDE BLUETOOTH PTT USER GUIDE


Product overview

Thank you for choosing SEECODE **Bluetooth PTT Full Kit**. This device connect your non-Bluetooth PTT/TRS phone & two-way radio to **Bluetooth Headset** without wire and let you more comfortable to use PTT/TRS phone & two-way radio.


You can place heavy phones on the belt or in the bag and just need to wear **Bluetooth Headset** and hold **PTT Remote Control** instead. This device removes inconvenience and danger especially for construction site, industrial field, transportation business, police activity, guard service, etc.


To use with mobile phone in the car, home and office You can use **Bluetooth Headset** with general mobile phone in separate. You shall pair SCM713 with your mobile phone. Please refer to manual for details.

In the package



Part description





How to use Bluetooth PTT Full Kit

This device connect your non-Bluetooth PTT/TRS phone & two-way radio to **Bluetooth Headset** without wire and let you more comfortable to use PTT/TRS phone & two-way radio.

Charging |

Bluetooth Headset, PTT Dongle and PTT Remote Control have a built-in battery and need to fully charged before you use.

- You can charge Bluetooth Headset, PTT Dongle and PTT Remote Control at the same time with Multi Charging Jack and Charging Adapter.
 - While charging, the LED turns on and it turns off when charging is completed.
- 2. The charging time is less than 2 hours.
- Tips All devices are working normally while charging and you could use them.
- Low Battery State

Bluetooth Headset: Blue LED flashes twice at 1 minute interval and beep sound PTT Remote Control: Red LED flashes at a 10 seconds interval PTT Dongle: Blue and Red LED flashes at 10 seconds interval

Notice Do not use other charger except the supplied charger. It may cause a trouble and damage.

Power on / off

Turning On	Button Action	LED State
Bluetooth Headset	Press 2 seconds	Blue LED turns on for 1 second and turns off
PTT Remote Control	Press 2 seconds	Red LED flashes 5 times
PTT Dongle	Press 2 seconds	Blue LED flashes 5 times
Standby	Button Action	LED State

Standby	Button Action	LED State
Bluetooth Headset	Х	Blue LED flashes at a 3 second interval
PTT Remote Control	X	Red LED flashes at a 5 second interval
PTT Dongle	X	Blue LED flashes at a 5 second interval

Turning Off	Button Action	LED State
Bluetooth Headset	Press 4 seconds	Blue LED turns off/Blue light remains on until Multi Button is released
PTT Remote Control	Press 4 seconds	Red LED turns on for 1 second and turns off
PTT Dongle	Press 4 seconds	Blue LED turns on for 1 second and turns off

8-