

$(198.5 \, \text{mm})$ 



#### A Quick Look at Your Device



- 1. ON/OFF / Answer Call / Play/Pause
- 2. Previous Track / Volume -
- 3. Next Track / Volume +

- 4. LED indicator Light
- 5. Charging Port
- 6. Auxilliary Port

#### 2. When the battery is charging, the LED indicator light will turn red. The LED indicator light will turn blue when the battery is fully charged. Unplug when charging is complete.

**Charging Your Headphones** 

adapter in order to recharge the internal rechargeable battery.

NOTE: Overcharging could reduce the life of the battery. A charged battery will lose its capacity if it is not used on a regular basis.

NOTE: The internal battery of your headphones takes approximately three hours to charge when

Your headphones have a built-in, rechargeable lithium ion battery. To avoid damage, do not attempt to

cycles. Charge the battery fully before first use. To do so, follow the steps below:

remove the battery. The full performance of the battery is only achieved after a few charging-discharging

1. Connect one end of the included Micro USB charging cable to the charging port on your headphones.

Then plug the other end of the charging cable into a USB port on your computer or a suitable power

completely drained.

To avoid a complete discharge of the battery, charge your headphones at least once every six

#### Maintenance and Care

-Before using your headphones, inspect the ports to make sure that they are clear of dust and debris

-Use a soft cloth to clean your headphones. Never use any harsh chemicals or detergents. Make sure your headphones are dry before using.

-When your headphones are not in use, they should be stored in a cool, dry place.

-Never tug or vank on the charging cable while it is connected to your headphones. Connect and disconnect this cable as carefully as possible.

-Never expose your headphones to high temperatures, extreme cold, high humidity or excessive moisture

-Please recycle or dispose of your headphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your headphones for further information.



### **FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Regrient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- -- Consult the dealer or an experienced radio/TV technician for help.

## **Important Safety Precautions**

When using your Targus Bluetooth Headphones, basic safety precautions should always be followed, including the following:

- 1. READ ALL INSTRUCTIONS BEFORE USING YOUR HEADPHONES.
- Do not use your headphones near water. Clean using a dry or slightly moist cloth.
   Do not place your headphones on any wet surfaces.
- Do not allow children or the infirm to play with your headphones without adult supervision.
   Do not expose your headphones to excessive heat, flames or fire.
- 6. Always press all buttons or switches carefully. Do not manhandle your headphones
- 7. Do not use in extremely dry environments, as this can lead to static discharge during usage. 8. Do not expose your headphones to temperatures above 40°C. Keep out of direct sunlight.
- 9. Do not attempt to repair this product yourself. Contact a qualified service center if your headphones are in need of
- Do not drop, puncture or expose your headphones to excessive trauma.
   Your headphones are not intended for commercial use.
- Unplug this device when not in use for long periods of time or during lightning storms.
   Do not place near objects that generate a strong magnetic field.



#### RATTERY WARNING

BATTERY WARNING:

-The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.

-Do not dispose of in fire or expose to excessive heat.

-Do not crush, puncture, incinerate, or short circuit external contacts.

-Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for turther informatics.

## Pairing Your Headphones with a Bluetooth Device

Your headphones can be paired with most Bluetooth devices including iPads, iPhones, iPod Touches, and most smartphones, laptops and tablets. In order to pair your headphones with a phone, follow the

- 1. Press and hold the ON/OFF button in order to power on your headphones. Once your headphones are powered on, the LED indicator light will alternately blink red and blue. This indicates that your headphones are in pairing mode.
- 2. Go to the Bluetooth Manager of your Bluetooth device.
- 3. Search Bluetooth devices and select "Targus headphone" to start connecting
- 4. Enter "0000" if your device asks for the PIN code.
- 5. Once paired, the LED indicator light will stop blinking and steadily shine blue. Note that anytime music is playing, the light will slowly blink blue every few seconds.

#### Introduction

Thank you for purchasing your Targus Bluetooth Headphones, item TA-50011BT. You can use your headphones with iPads, iPhones, iPods and many other types of smartphones and Bluetooth devices to stream music and enjoy hands-free calling. In order to get the best results when using this device, please read this manual first before using.

### Package Contents

-Targus TA-50011BT Bluetooth Headphones

-User's Manual with Warranty Information

## **Specifications**

Bluetooth Specification: V4.2 Bluetooth Range: Up to 33 Feet (10 Meters) Charging Input: DC 5V Battery Type: 320mAh Lithium Ion Battery Charge Time: Approximately 3 Hours Play Time: Approximately 7 Hours\*

\*Applicable at 40% of maximum volume. Results will be lower when volume is higher.

# **Using Your Headphones**

#### Powering Your Headphones On and OFF

- 1. Press and hold the ON/OFF button in order to power on your headphones. If you have paired your headphones to your Bluetooth device previously, they will automatically remain paired each time you power on your headphones.
- 2. Press and hold the ON/OFF button in order to power off your headphones.

#### Listening to Music

- Play/Pause Button : Press to play or pause a track.
- Press and hold the "NEXT TRACK/VOLUME UP" button to advance to the next song in a playlist.
- Press and hold the "PREVIOUS TRACK/VOLUME DOWN" button to go back to the previous song in a
- Quickly tap the "NEXT TRACK/VOLUME UP" button to increase the volume.
- Quickly tap the "PREVIOUS TRACK/VOLUME DOWN" button to decrease the volume.

- Last Number Re-dial: Double tap and the Answer Call button to re-dial the last number called.
- Answering a Call: Quickly press the Answer Call button to answer an incoming call.
- Reject an Incoming Call: Press and hold the Answer Call button to reject an incoming call.
- Ending a Call: Quickly press the Answer Call button to end a call.

## **Auxiliary Input Mode**

To use your headphones with devices that are not Bluetooth enabled, plug one end of a standard 3.5mm audio cable into the Auxiliary Port on your headphones. Plug the other end into the headphone iack on your audio device

## Sakar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable. This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

## What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident

To Obtain Warranty Service and Troubleshooting Information:

Call 1-877-397-8200 in the US or 0-800-917-4831 in the UK or Visit our website at www.sakar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

# **Sakar One Year Warranty (continued)**

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR BEPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFAC-TURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY NOTWITHSTANDING THE FOREGOING CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies