Important Safety Precautions

sing your Vivitar Bluetooth Headphones, basic safety precautions should always be followed, including the

- I. FRAD ALL INSTRUCTIONS BEFORE USING YOUR HEADPHONES.
 2. Do not us your headphones near water. Clear using a dy or algolity moist cloth.
 2. Do not claw ordinate on the Infilm to Delay with your headphones without adult supervision.
 3. Do not allow foldines not be Infilm to Delay with your headphones without adult supervision.
 5. Do not expose your headphones to excessive heat, flames of fire.
 5. Do not expose your headphones to excessive heat, flames of fire.
 5. Do not claw in extremely day environments, as this can lead to static discharge during usage.
 6. Do not expose your headphones to temperatures above 40°C. Keep out of direct surjicht.
 9. Do not expose your headphones to temperatures above 40°C. Keep out of direct surjicht.
 9. Do not extremely to repair this prototty cyturell's Context of a sulfilled service center if your headphones are in

- need of service.

 10. Do not drop, puncture or expose your headphones to excessive trauma.

 11. Your headphones are not intended for commercial use.

 12. Unplug this device when not in use for long periods of time or during lightning storms.

 13. Do not place near objects that generate a strong magnetic field.

↑CAUTION

Charging Your Headphones

BATTERY WARNING:

-The device is equipped with an integrated lithium ion battery. The hartery cannot be replaced. Do not attempt to remove the battery

battery cannot be replaced. Do not attempt to remove the battery from the device. —
Do not dispose of in fire or expose to excessive heat. —
Do not crush puncture. Inclinerate, or short circuit external contacts. —
Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacture for further information.

Introduction

Thank you for purchasing your Vivitar Bluetooth Headphones, item V50043BT. You can use your headphones with most smartphones and Bluetooth devices to stream music and enjoy hands-free calling, in order to get the best results when using this device, please read this manual first before using

Package Contents

-Vivitar V50043BT Bluetooth Headphones -Micro USB Charging Cable -User's Manual with Warranty Information

Specifications

Bluetooth Range: Up to 33 Feet (10 Meters) Charging Input: DC 5V Battery Type: Lithium Ion Battery Charge Time: Approximately 2 Hours

A Quick Look at Your Device

- 2. Next Track / Volume -
- 3 Previous Track / Volume -4. Play/Pause/Answer
- 5 Chaming Port
- 7. Auxilliary Port
- 8 Microphone

The included USB charging cable has a Micro USB plug and a standard USB plug.
 See New York on your headphones.

urns blue once charging is complete







Important: To avoid a complete discharge of the battery, charge your headphones at least once every six months.

Pairing Your Headphones with a Bluetooth Device









Using Your Headphones

Powering Your Headphones On and OFF

1. Press and hold the onloff button in order to power on your headphones. If you have paired your headphones your Bluetooth device previously, they will automatically remain paired each time you power on your headphones.

2. Press and hold the onloff button in order to power off your headphones.

Listening to Music

- Delaylause Button: Press to play or pause a track.

 Press and hold the 'Next Track/Volume -' button to advance to the next song in a playlist.

 Press and hold the 'Previous Track/Volume -' button to go back to the previous song in a playlist.

 Quickly tap the 'Next Track/Volume -' button to increase the volume.
- Ouickly tap the 'Previous Track/Volume -' button to decrease the volume

- Using the Phone Function

 Answering a Call: Quickly press the Answer Call button to answer an incoming call.

 Reject an incoming Call: Press and hold the Answer Call button to reject an incoming call.
- Ending a Call: Quickly press the Answer Call button to end a call.

Auxiliary Input Mode
To use your headphones with devices that are not Bluetooth enabled, plug one end of a standard
35mm audio cable into the Auxiliary Port on your headphones. Plug the other end into the headphone lack on your audio device

Maintenance and Care

Before using your headphones, inspect the ports to make sure that they are clear of dust and debris before charging

-Use a soft cloth to clean your headphones. Never use any harsh chemicals or detergents. Make sure your headphones are dry before using.

-When your headphones are not in use, they should be stored in a cool, dry place.

fred) = Charoino Iblue! - Charging Complete

4. The LED indicator light turns red while the headphones are charging. It

-Never tug or yank on the charging cable while it is connected to your headphones. Connect and disconnect this cable as carefully as possible.

 Never expose your headphones to high temperatures, extreme cold, high humidity or excessive moisture or water.

-Please recycle or dispose of your headphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your headphones for further information.



Changes or modifications not expressly approved by the party responsible for compliance could oid the user's authority to operate the equipmen

This device complies with Part 15 of the ECC Pules. Operation is subject to the following two rms device complies with a fact to the fock refers operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device. Insequence to Part S of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment provide reasonable protection against harmful interference in a residential installation. This equipment propriet against harmful interference in a residential installation. This equipment propriet is sufficiently a resident provides and the provided provided provided provides and the provided provide

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- receivent or relocate the receiving antenna.

 Increase the separation between the equipment and receiver,

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or
malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering modification or accident

To Obtain Warranty Service and Troubleshooting Information: Call 1-800-592-9541 in the U.S. or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the requirement of the procedure of the purchase in the form of a bill of sale or receipted invoice, evidencing that the requirement of the properties of the purchase in the purchase of the products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center of that are not covered by warranty will be returned unrepaired.

Vivitar One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO DISCLAMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL GE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE PORIGINAL PURCHASE PRICE AT DISTRIBUTORS SOLE DISCRETION -ARE THE EXCLUSIVE REMEDIES OF THE ORSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR THE. BE LIABLE FOR ANY INCIDENTIAL, DIRECT, INDIRECT, SPECIAL PUNITIVE OF CONSEQUENTIAL DAMAGES (SUCH AS BUT NOT LIMITED TO DAMAGE SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROPTIS, BUSINESS, SAVINOS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FORECOME, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE

consequential damages or allow limitations on warranties, so limitation or exclusions may not

ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Consept to you and a second of the second of